

9

# Ford

THE UNIVERSAL CAR.

WHOLESALE  
PRICE LIST OF PARTS

MODEL T

Effective November 15, 1923

*Ford Motor Company*  
Detroit, Michigan

# Ford Motor Company

## FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*  
Ford Factory, Ford, Ontario, Canada  
Ford Factory, Manchester, England

## AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Oklahoma City	Salt Lake City
Buffalo	Columbus	Houston	Louisville	Omaha	San Francisco
Cambridge	Dallas	Indianapolis	Memphis	Philadelphia	Seattle
Charlotte	Denver	Jacksonville	Milwaukee	Pittsburgh	Washington
Chicago	Des Moines	Kansas City, Mo.	Minneapolis	Portland	
Cincinnati	Detroit	Kearny, N. J.	New Orleans	St. Louis	

---

## Instructions for Ordering Parts

- 1—Order all parts through the Authorized Ford Dealer.
- 2—Parts may be ordered in the minimum wholesale quantities specified at a discount of  $33\frac{1}{3}\%$  f. o. b. the nearest Ford Branch providing the net amount of the order exceeds \$50.00. Parts delivered from the Dealer's Stock are subject to a discount of 25% regardless of quantity ordered.
- 3—Always give Catalog Number and Name of each part ordered.
- 4—Specify whether shipments are to be made by freight or express.
- 5—Remittance by Draft or Money Order must accompany all parts orders placed shipment from the Ford Branch.

---

## Telegraph Code

We list below a brief General Code covering miscellaneous instructions relative to the shipment of parts.

- |  |   |
|--|---|
| <b>Toperig</b> —Ship to me (us) by express.    | <b>Topfton</b> —When and how did you ship parts called for in my (our) telegram of —    |
| <b>Toperkleur</b> —Ship by express to —        | <b>Topflutch</b> —When and how will you ship parts called for in my (our) telegram of — |
| <b>Topersteen</b> —Ship to me (us) by freight. | <b>Topwasser</b> —When and how will you ship parts called for in my (our) letter of —   |
| <b>Toper</b> —Ship to me (us) by parcel post.  |   |

# WHOLESALE PRICE LIST OF PARTS

FORD MODEL T 1909-1923

EFFECTIVE NOVEMBER 15, 1923

Part No.	Name of Part	Year	Minimum Wholesale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 10	Lots of 100	Lots of 1000				
<b>REAR AXLE</b>										
2500	Rear axle assembly	1909-23	2				\$55 00	MH	95E	1
2501	Axle housing—right	1915-23	2				8 00	MH	7635C	1
2502	Axle housing—left	1915-23	2				8 00	MH	7636C	1
2503B	Axle housing bolt	1913-23	100	\$0 20	\$1 00	\$6 00	03		2854	7
2503B*	Axle housing bolt nut	1909-23	100	15	1 00	6 00	03		44	7
2504	Rear axle case gasket	1912-23	20	15	1 00		02		139	1
2505	Axle shaft	1912-23	6				1 50	MH	2818	2
2506	Axle shaft washer	1909-23	20	15	75		02		39	1
2508	Axle shaft R. B.	1909-23	6	7 50			10		253	4
2509	Axle shaft R. B. sleeve—R	1909-23	6				15		170	2
2509B	Axle shaft R. B. sleeve—L	1909-23	6				15		161	2
2510	Axle housing cap	1909-19	20	25	2 00		05		56A	2
2510 1/2	Axle housing cap	1919-23	20	20	1 80		05		56B	2
2510A	Axle outer roller bearing steel washer	1909-23	20	15	1 00		02		199B	2
2510B	Axle outer roller bearing felt washer	1909-23	20	40	3 00	27 50	05		54	2
2512C	Diff. case—left	1914-23	4				1 40	MH	84	1
2513C	Diff. case—right	1914-23	4				90	MH	81	1
2514B	Diff. case stud	1915-23	20	35	3 00		05		52B	3
2514C	Diff. case bolt	1922-23	20	35	3 00		05		52C	3
2515	Diff. case stud nut	1909-23	100	20	1 50	10 00	03		8	3
2518	Diff. drive gear	1909-23	6				2 50	MH	12B	1
2519	Diff. drive gear screw	1909-23	100	25	2 00	15 00	02		103	10
2519A	Diff. gear lock ring	1909-23	20	15	1 00		03		118	2
2520B	Diff. gear	1909-23	6				90	MH	13B	2
2521B	Diff. gear key	1911-23	10	40	3 50		05		137	2
2524C	Diff. pinion	1915-23	6				35	MH	14D	3
2526B	Diff. spider	1909-23	6				75	MH	15D	1
2528	Diff. thrust washer	1909-23	10				15		30	2
2529	Diff. thrust plate	1909-23	10	1 25	10 00		15	MH	31	4
2530	Diff. thrust plate pin	1909-16	20		1 50		03		37	2
2531	Diff. thrust plate pin	1909-16	20		1 00		03		37	2
2531B	Diff. thrust plate pin	1917-23	20	10	75		02		7640	6
2532	Diff. housing oil plug	1909-23	6				05		817	1
2545	Rear axle grease cup	1909-23	20	60	5 00		1 25		152	1
2547	Rear radius rod—right	1909-23	2	10 00			1 25	MH	158	1
2547B	Rear radius rod—left	1909-23	2	10 00			1 25	MH	158	1
2548	Radius rod nut	1909-23	100	40	3 00	25 00	05		77	2
2549	Radius rod lock nut	1909-23	10	40	3 00		05		78	2
2550	Radius rod lock washer	1909-23	100	15	1 00		02		2823	2
2551	Radius rod bolt	1909-23	20	35	3 00		03		83	4
2551B	Radius rod bolt nut	1909-23	100		2 50	20 00	03		60	4
2557	Hub cam shaft—right	1909-23	6				15	MH	92B	1
2558	Hub cam shaft—left	1909-23	6				15	MH	91B	1
2559	Hub cam shaft bushing	1909-23	10	35	2 50		05		173	2
2562	Cam shaft lever	1909-23	6				10	MH	62	2
2563	Cam shaft lever pin	1909-23	100	10	50		02		65	4
2564	Lever clevis pin	1909-23	100	15	1 00		02		65	4
2566	Hub brake shoe	1909-23	10	3 00			35	MH	2814	2
2567	Brake shoe support bolt	1909-23	20	35	3 00		05		59	2
2568	Brake shoe support nut	1909-23	Order 2551B							
2570B	Brake shoe coil spring	1913-23	20	20	1 50		03		2662	4
2571	Universal joint assembly	1909-23	6				1 50		151B	1
2572	Joint knuckle (male)	1909-23	2				50		45B	1
2573	Joint knuckle (female)	1909-23	2				60		46B	1
2574	Joint knuckle pin	1909-23	20	10	75		02		6	1
2575	Joint ring, complete	1909-23	3	4 00			05		49B	1
2576	Joint ring rivets (per set 4)	1909-23	20	10	50		50		50	4
2577B	Univ. joint housing	1914-23	2				1 00		7609	1
2578	Joint housing plug	1909-23	20	30	2 00		05		75	2
2579	Ball joint grease cup	1909-23	10	1 20	10 00		15		195	1
2580	Ball cap gasket	1909-23	20	40	3 00	25 00	05		1518	1
2581	Drive shaft housing front bushing	1909-23	6				30		69	1
2582	D. S. tubing	1911-23	2				7 00	MH	153B	1
†2583B	D. S. bearing housing	1920-23	2				1 40	MH	191C	1
2584B	D. S. R. B. cap screw	1912-23	20		3 00		05		183B	6
2584C	D. S. R. B. stud nut	1912-23	20	25	2 00		03		184R	6
2584D	D. S. R. B. cap screw lock washer	1912-23	100				doz.		157	6
2586	D. S. R. B. housing set screw	1911-23	20	45	4 00		05		101R	1
2587	D. S. roller bearing	1911-23	6	9 00			1 00		108	1

†When ordered to replace malleable type housing also order 2-2591 and 1-2591B.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car	
				Lots of 10	Lots of 100	Lots of 1000				
<b>REAR AXLE—Continued</b>										
2588	D. S. R. B. distance plate	1911-21	20	\$ 0 15	\$ 1 00		\$ 0 05	MH	106R	1
2589	D. S. ball race	1911-21	6				25		186R	1
2589B	D. S. ball bearing assy	1911-21	6				90		185AR	1
2590	D. S. ball retainer	1911-21	20	20	1 25		03		190AR	1
2591	D. S. ball thrust collar	1911-23	10				25		188	2
2591B	D. S. thrust ball and re- tainer assembly	1920-23	10	2 00			25		162	1
2592	D. S. ball bearing	1911-21	6							
2593	D. S. R. B. sleeve	1911-21	6				1 50		107R	1
2595B	D. S. only	1911-23	3				3 00	MH	87D	1
2596	D. S. sleeve	1911-23	10	4 50			60		163B	1
2597B	D. S. pinion	1911-23	10				1 00	MH	16C	1
2597C	D. S. pinion	1911-23	2				1 00	MH	16D	1
2598	D. S. castle nut	1911-23	10				08		124	1
2598B	D. S. pinion key	1911-23	20	40	3 00		05		57B	1
<b>REAR AXLE—60 INCH TREAD</b>										
2600C	Rear axle housing—right	1915-16	2				12 00	MH	2728C	1
2601C	Rear axle housing—left	1915-16	2				12 00	MH	2729C	1
2602B	Rear axle shaft—tapered	1911-16	2				3 00	MH	2725	2
2604	Rear radius rod	1909-16	2				2 00		1726	2
<b>FRONT AXLE</b>										
2691	Front axle only	1909-23	2				9 00	MH	202B	1
2694B	Spindle body—right	1911-23	2				1 50	MH	280	1
2695B	Spindle body—left	1911-23	2				1 50	MH	281	1
2696	Spindle arm—right or lf	1911-19	4				50	MH	7716	2
2696C	Spindle arm—right	1919-23	4				45	MH	7715B	1
2696D	Spindle arm—left	1919-23	4				45	MH	7716B	1
2697	Spindle arm nut	1911-23	4							
2704	Stationary cone	1909-23	24				15		205A	2
2705	Adj. cone—right thread	1909-23	24				15		206A	1
2706	Adj. cone—left thread	1909-23	24				15		207A	1
2707	Spindle nut—right thread	1909-23	20				05		209B	1
2708	Spindle nut—left thread	1909-23	20				05		208B	1
2709	Spindle washer	1909-23	20	15	1 00	\$ 6 00	02		210	2
2710	Spindle bolt with oiler	1910-23	20	1 60	15 00		20		7708	2
2711	Spindle bolt nut	1909-23	20							
2713	Spindle body bush. (pair)	1909-23	20	1 80	17 00		20		223	2
2714	Spindle arm bushing	1909-23	20	15	1 25	9 00	05		225	2
2715D	Spindle oiler	1919-23	2							
2717	Spindle con. rod	1909-23	2	15 00			1 75	MH	264	1
2718	Spindle con. rod bolt with oiler	1909-23	20	1 20	10 00		15		7706	1
2719	Spindle con. rod bolt nut	1909-23	100		2 50	15 00	03		220	2
2721B	Spindle con rod yoke ball	1919-23	2	1 50			20	MH	226B	1
2721C	Spindle con. rod yoke	1919-23	2	3 50			40	MH	248B	1
2725B	Steering gear con. rod	1909-23	2	7 00			80	MH	289	1
2728	Ball socket cap	1909-23	6				10		254B	2
2729B	Ball socket bolt and nut	1909-23	6							
2733	Front radius rod	1909-19	3				2 00	MH	263A	1
2733B	Front radius rod	1919-23	3				1 50	MH	263B	1
2736	Front radius rod ball cap	1909-23	12				10		217	1
2737	Front radius rod ball socket	1911-23	2				20		809B	1
2741	Radius rod ball cap stud	1911-23	20		2 50		03		4365	2
2741B	Radius rod ball cap stud nut	1911-23	20							
2742	Radius rod ball cap spr'g	1911-23	20	20	1 25	8 00	03		292	2
2760	Front axle only—60"	1911-16	2				10 00	MH	1720B	1
2761	Spindle con. rod—60"	1909-16	2				3 00	MH	1725	1
2762	Steer. gear con. rod—60"	1909-16	2				1 25	MH	2739	1
<b>WHEELS</b>										
2800	Front wheel—clincher	1909-23	2				6 50		291B	2
2800B	Front wheel—dem. less rim and brgs.—Kelsey	1919-23	2				7 25		291D	2
2800C	Front wheel—dem. less rim and brgs.—Hayes	1919-23	2				7 25		291E	2
2800D	Front wheel—clincher— less hub	1909-23	2				4 50		295AR	2
2800E	F. and rear wheel—dem. less rim & hub—Kelsey	1919-23	2				4 75		293AR	4
2800F	F. and rear wheel—dem. less rim & hub—Hayes	1919-23	2				4 75		293BR	4
2800G	Front wheel—dem.—less rim and brgs.—Ford	1919-23	2				7 25	MH	291G	2
2800H	Frt. and rear wheel—dem. less rim & hub—Ford	1919-23	2				4 75	MH	293CR	4
2801	Front wheel complete R. or L.—dem.—Kelsey	1919-23	2				9 75		7697A	2
2801B	Front wheel complete R. or L.—dem.—Hayes	1919-23	2				9 75		7697B	2
2801C	Front wheel complete R. or L.—dem.—Ford	1919-23	2				9 75	MH	7697C	2

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax Each	Fac. Status No.	No- Req- per Car
				of 10 per lot	of 100 per lot	of 1000 per lot			
<b>WHEELS—Continued</b>									
2803	Front hub assy.	1909-23	4				\$1 60	200	2
2803B	Front hub with R B cups	1909-23	2				2 00	219	2
2804	Outer race	1909-23	12		\$ 7 50		10	234	2
2805	Inner race	1909-23	10		11 00		15	235	2
2806	Outer ball retainer	1909-23	20	\$ 0 15	1 00		02	236	2
2807	Inner ball retainer	1909-23	20	20	1 25		03	237	2
2808	Dust ring	1909-23	20	40	2 50		05	238	2
2809	Front & rear hub felt washer	1909-23	20	45	3 50	\$ 30 00	05	239	4
2810	Large balls	1909-23	100		3 00	25 00	04	241	24
2811	Small balls	1909-23	100		1 50	13 50	03	249	22
2814C	Rear wheel—clincher	1912-23	2				7 25	2815	2
2814D	Rear wheel—clincher—less hub	1909-23	2				5 00	2816	2
2814E	Rear wheel complete—dem.—Kelsey	1919-23	2				9 50	7698A	2
2814F	Rear wheel complete—dem.—Hayes	1919-23	2				9 50	7698B	2
2814G	Rear wheel—dem. less rim—Kelsey	1919-23	2				7 00	2815B	2
2814H	Rear wheel—dem. less rim—Hayes	1919-23	2				7 00	2815C	2
2814J	Rear wheel—complete—dem.—Ford	1919-23	2				9 50	MH 7698C	2
2814K	Rear wheel—dem.—less rim—Ford	1919-23	2				7 00	MH 2815E	2
2815C	REAR HUB	1912-23	4				1 25	MH 2819	2
2816B	Rear hub key	1912-23	20	20	1 50	12 00	03	2863	2
2818	Rear hub brake drum	1909-23	4				40	3B	2
2819	Hub cap	1909-23	20	1 40	12 50		15	7727	4
2825	Rear hub bolt	1911-23	100	20	1 50	8 00	03	28B	12
2825B	Hub bolt nut	1911-23	100	15	1 00	6 00	03	29	24
2826	Front hub bolt	1911-23	100	20	1 50	8 00	03	27	12
2827	Hub flange	1911-23	3				20	233B	4
2828	Rear hub lock nut	1912-23	20	45	3 50		05	242	2
2833	Front hub bear. cup inner	1919-23	6	4 50			10	2955	2
2834	Inside cone and rollerassy	1919-23	6				1 50	205B	2
2836	Front hub bearing cup—outer	1919-23	6	3 50			40	2956	2
2837	Outside cone and roller assy.—right thread	1919-23	6	7 00			75	206B	1
2838	Outside cone and roller assy.—left thread	1919-23	6	7 00			75	207B	1
2841	Front hub dust cap assy.	1919-23	12	80	7 00		10	350	2
2845	Demountable rim only—Kelsey	1919-23	2				1 75	8774A	4
2845B	Demountable rim only—Hayes	1919-23	2				1 75	8774B	4
2845C	Demountable rim only—Ford	1922-23	2				1 75	8774C	4
2846B	Demountable rim clamp—Kelsey	1919-23	20	80	5 00		10	8831B	16
2846C	Dem. rim clamp and nut assy.—Ford	1922-23	20				15	8807	16
2847	Demountable rim bolt	1919-23	24	45	4 00		05	8832A	16
2848	Dem. rim nut—Hayes	1919-23	24	45	4 00		05	8834B	16
2848B	Dem. rim nut—Kelsey	1919-23	24	45	4 00		05	8834A	16
2849	Spare rim carrier	1919-23	2				2 00	MH 8848C	1
2849C	Spare rim carrier clamp support and bolt assy.	1921-23	4				15	MH 7511	1
2849D	Spare rim carrier clamp	1921-23	4				05	7312C	1
2870	Spare rim carrier brkt—R	1919-22	2				50	8824AR	1
2870B	Spare rim carrier brkt—R	1922-23	2				50	8824B	1
2871	Spare rim carrier brkt—L	1919-22	2				50	8825AR	1
2871B	Spare rim carrier brkt—L	1922-23	2				50	8825B	1
<b>FRAME</b>									
2850	Frame assembly	1909-23	2				13 00	MH 2916	1
2851B	Side member—right	1914-23	2				4 00	2914	1
2852B	Side member—left	1914-23	2				4 00	2915	1
2853	Front cross member	1909-23	6	8 00			90	303	1
2854B	Rear cross member	1914-23	3				1 20	2913	1
2855	Front corner bracket	1909-23	6				15	305	1
2856	Front corner bracket—L	1909-23	6				15	306	1
2857	Rear corner bracket—R	1909-23	6				15	307	1
2858	Rear corner bracket—L	1909-23	6				15	308	1
2859	Front end spacer—L	1909-23	6				10	318B	1
2860	Front end spacer—R	1909-23	6				10	319B	1
2863	Body bracket	1909-23	6				10	344	4
<b>GASOLINE TANK</b>									
2900B	Gas tank—Sedan	1916-23	2				6 00	MH 7950	1
2900C	Gasoline tank	1909-23	2				4 00	MH 1303B	1
2901	Filling plug	1909-23	20	90	8 00		10	1317	1
2902B	Sediment bulb	1909-23	6				90	2088	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
<b>GASOLINE TANK—Continued</b>										
2908	Pet cock	1909-23		Order 3079						
2909	Feed pipe—40 1/2"	1909-23	4				\$0 20	1364	1	
2909B	Feed pipe—51 1/2"	1916-23	4				25	7965	1	
2909C	Feed pipe—56 1/2"	1918-19	4				40	9775R	1	
2909D	Feed pipe—56 1/2"	1919-23	4				35	8690	1	
2909E	Feed pipe—39 1/2"	1919-23	2				20	TT1364	1	
2910	Feed pipe pack nut	1909-23	20	45	4 00		05	1374	2	
2911	Feed pipe—78"	1915	4				70	1394R	1	
2913	Feed pipe gasket	1909-23	20		1 50		02	5892	1	
2914	Gas tank support—R	1917-20	2				25	2132	1	
2914B	Gas tank support—R	1920-23	2				20	2132B	1	
2915	Gas tank support—L	1917-20	2				20	2133	1	
2915B	Gas tank support—L	1920-23	2				20	2133B	1	
2916	Feed pipe clamp	1921-23	20				01	2118	1	
<b>MOTOR</b>										
12990	Motor assy—with starter	1909-23					*140 00	MH	532C	1
2990B	Motor assy—less starter	1909-23					*110 00	MH	532C	1
12991	Cylinder assy	1909-23	2				55 00	MH	449	1
x3000C	Cylinder	1909-23	2				25 00	MH	400D	1
x3000B	Cylinder (bore 1/2 oversize)	1909-23	2				15 00	MH	400E	1
3001	Cylinder head	1909-23	2				6 00	MH	401C	1
3002	Cyl. head gasket	1909-23	20	2 80	27 00		30	MH	402B	1
3003	Cyl. head cap screw	1909-17	20	35	3 00		05	MH	483B	15
3003B	Cyl. head cap screw	1918-23	20	35	3 00		05	MH	483C	1
3004	Cyl. head outlet con.	1909-16	6				35	MH	446C	1
3004B	Cyl. head outlet con.	1917-23	6				30	MH	8719	1
3005	Cyl. head out. con gasket	1909-23	20	30	2 00		05	MH	445B	1
3006	Cyl. head outlet hose	1909-23	20		14 00		15	MH	448B	1
3007	Cyl. head outlet hose clip	1909-23	20	40	3 50		05	MH	607B	2
3008	Cyl. head out. con. screw	1909-23	20	25	2 00		05	MH	550C	2
3009B	Cyl. front cover	1909-19	2				1 00	MH	690B	1
3009C	Cyl. front cover	1919-23	2				1 00	MH	690C	1
3010	Cyl. cover bolt and nut	1909-23		Order 4808 and 2515						
3011	Cyl. cover cap screw	1909-23	20	20	1 50		03		432	3
3012	Cyl. cover felt	1909-23	20	40	2 50		05		504	1
3013	Cyl. cover liner	1909-19	20	15	1 00		02		505B	1
3013B	Cyl. cover liner	1919-23	20	15	75		02		505C	1
3014	Cyl. cover and crank case bolt and nut	1909-23		Order 3362 and 2515						
3015	Cyl. water inlet con.	1909-23	6				30	MH	442B	1
3016	Cyl. inlet con. screw	1909-23	20	25	2 00		03		597	2
3017	Time gear cover	1919-23	4				80	MH	1754B	1
†3017B	Time gear cover	1919-21	4				80	MH	1754AR	1
3017C	Time gear cover gasket	1919-23	100		60		01		1775	1
3017D	Time gear cover plate	1919-23	6				05	MH	1773	1
3018	Cyl. water inlet gasket	1909-23	20	25	2 00		03	MH	596	1
3019	Cyl. water jacket plug	1909-13	10				05		557	3
3019B	Cyl. water jacket plug	1914-23	20	10	50		02		5919	3
3020	PISTON COMPLETE	1909-23	10				1 60	MH	586C	4
3020C	PISTON COMPLETE	1909-23	10				1 60	MH	586DR	4
3020D	PISTON COMPLETE	1909-23	10				1 60	MH	586E	4
3020E	PISTON COMPLETE	1909-23	10				1 60	MH	586FR	4
3020F	PISTON COMPLETE	1909-23	10				1 60	MH	586GR	4
3021	Piston only	1909-23	10	8 50	80 00		90	MH	418C	4
3021B	Piston only—.0025" O. S.	1909-23	10	8 50	80 00		90	MH	418DR	4
3021C	Piston only—.03125" O. S.	1909-23	10	8 50	80 00		90	MH	418ER	4
3021D	Piston only—.033" O. S.	1909-23	6	8 50	80 00		90	MH	418FR	4
3021E	Piston only—.005" O. S.	1909-23	10	8 50	80 00		90	MH	418GR	4
3021F	Piston and pin assy.	1909-23	10	11 00	105 00		1 15	MH	4473C	4
3021G	Piston and pin assy.	1909-23	10	11 00	105 00		1 15	MH	4473DR	4
3021H	Piston and pin assy.	1909-23	10	11 00	105 00		1 15	MH	4473ER	4
3021J	Piston and pin assy.	1909-23	10	11 00	105 00		1 15	MH	4473FR	4
3021K	Piston and pin assy.	1909-23	10	11 00	105 00		1 15	MH	4473GR	4
3022	Piston pin	1909-23	20				25		419B	4
3022 1/2	Piston pin bushing (pair)	1909-23	10		15 00		20		668	4
3023	Piston ring	1909-23	20	1 35	10 00		15		422C	12
3023B	Piston ring	1909-23	20	1 35	10 00		15		422ER	12
3023C	Piston ring	1909-23	20	1 35	10 00		15		422DR	12
3023D	Piston ring	1909-23	20	1 35	10 00		15		422FR	12
††3024	CONNECTING ROD	1909-23	10				1 20	MH	641B	4
**3024B	Connecting rod	1909-23	8				1 20	MH	641AR	4
3024C	Con. rod (heavy type)	1919-20	4				1 20	MH	641	4
3025	Con. rod cap bolt	1909-23	20	40	3 00	\$20 00	05		489B	8
3026	Con. rod cap bolt nut	1909-23	20	30	2 00	13 00	05		490	8
3029	Con. rod clamp screw	1909-23	20	25	2 00		03		578	4
3030	CRANK SHAFT	1909-23	2				8 00	MH	498B	1
3031	C. S. rear bearing cap	1909-23	6				50		405AR	1
13031B	C. S. rear bearing cap	1909-23	6				50		405AR	1
3032	C. S. front bearing cap	1909-23	6				40		406B	1
13032B	C. S. front bearing cap	1909-23	6				40		406B	1

\*Not subject to regular discount.

xWhen used on car not equipped with starter also order 3017B, 3017C, 3011, 3008 and 3016.

†Used with 3000C cylinder on cars not equipped with starter.

††Connecting rods requiring new bearings will be exchanged by dealers at 60c each.

\*\*Special rod for crankshafts worn .025" undersize.

††Inquire of Branch for price.

‡Rough babbitted.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Wholesale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
<b>MOTOR—Continued</b>										
3033	C. S. center bearing cap	1909-23	6				\$ 0 40		407B	1
*3033B	C. S. center bearing cap	1909-22	6				40		407B	
3034	C. S. bearing bolt—center and front	1909-23	10				10		408	4
3035	C. S. bearing bolt nut	1909-23	10	Order 2551B						
3036	C. S. rear bearing bolt	1909-23	10				10		478	2
3038	C. S. bearing liner—center and front	1909-23	100		\$ 0 40	\$ 2 00	01		502B	8
3039	C. S. rear bearing liner	1909-23	100		40	2 00	01		503B	1
3040	C. S. starting pin	1909-20	20	\$ 0 30	2 00		05		529B	1
3040B	C. S. starting pin	1920-23	20	30	2 00		05		529C	1
3041	CAM SHAFT	1909-23	2				2 50	MH	410	1
3042	Cam shaft front bearing	1909-23	10				25		411	1
3043	Cam shaft center bearing	1909-23	10				25		412B	1
3044	Cam shaft rear bearing	1909-23	10				15		413	1
3045	Cam shaft bearing ring	1909-23	20	15	1 00		03		534	2
3046	Camshaft bearing set screw	1909-23	20	35	3 00		05		414	2
3047B	Time gear—large	1909-23	6	8 00			90	MH	415B	1
3048B	Time gear—small	1909-23	6	5 00			60	MH	416B	1
3049	Cam shaft gear dowel pin	1909-23	20	15	1 25		02		417	2
3050B	Cam shaft gear lock nut	1909-23	10				10		4453	1
3051	Small time gear key	1909-23	20	25	1 75		03		477	1
3052	Valve	1909-23	32		12 00		15	MH	424B	8
3052B	Valve—r. O. S. stem	1909-23	16		12 00		15	MH	424AR	8
3053 1/2	Valve bushing	1909-23	10				20		428	8
3054	Valve spring	1909-23	20		3 50		05		431	8
3056	Valve spring seat	1909-23	100		40	3 00	05		425	8
3057	Valve spring seat pin	1909-23	100		25	2 00	05		429	8
3058	Push rod	1909-23	20	90	7 00		10	MH	426B	8
3058B	Push rod—r. O. S. stem	1909-23	20	90			10	MH	426AR	8
3059 1/2	Push rod bushing	1909-23	6				20		427	8
3060B	Exhaust manifold	1913-23	3				1 25	MH	4483	1
3061	Exhaust pipe pack nut	1909-23	10				20		518	1
3062	Inlet pipe	1909-23	3				1 00	MH	512B	1
3063	Inlet and exh. pipe gasket	1909-23	100	15	1 20	8 00	02	MH	513	6
3064	Inlet and exh. pipe gland	1909-23	100		75	6 00	01		514	6
3065	Inlet and exh. pipe clamp	1909-23	10				10	MH	515	4
3066	Inlet and exh. clamp stud	1909-23	20	30	2 50		05		516	4
3066B	Inlet and exh. clamp stud nut	1909-23	100	20	1 25	7 50	03		517	4
3068	Breather pipe	1909-23	10	80	6 00		10	MH	4468	1
3069B	C. C. front end support	1911-17	2				1 00		801C	1
3069C	C. C. front end support	1917-23	2				50		801D	1
3070B	C. C. & cyl. gasket—L	1909-23	20	35	3 00		05		886	1
3071B	C. C. & cyl. gasket—R	1909-23	20	35	3 00		05		887	1
3072	C. C. & cyl. cover cap screw	1909-23	20	25	1 80		03		1388	2
3073	C. C. arm bolt—side	1909-23	20	30	2 50		05		479	2
3074	C. C. arm bolt—top	1909-23	20	25	2 00		05		940	2
3074B	C. C. arm bolt nut	1909-23	Order 2515							
3075B	C. C. frt. bearing & spring clip Assy	1921-23	2				80		2921B	1
3076B	C. C. front bearing and spring clip	1921-23	6				60		320C	1
3076C	C. C. front bearing and spring clip nut	1921-23	Order 2548							
3077	C. S. front bearing cap	1909-23	6				10		321	1
3078	C. C. front bearing screw	1909-21	20	30	2 50		05		322	2
3078B	C. C. front bearing screw	1921-23	Order 3008							
3078C	C. C. front bearing lock washer	1921-23	20		50		01		5636	2
3079	C. C. oil cock	1909-23	10		12 00		15		1515	2
3080	C. C. drain cup plug	1909-23	Order 2532							
3080B	C. C. drain cup plug gasket	1909-23	20	20	1 75		03	MH	4339	1
3081	C. C. oil tube	1909-23	6				20		543B	11
3083	C. C. arm block	1909-23	6				05		890	2
3084	Engine pan—right	1909-23	6				30	MH	1330	1
3085	Engine pan—left	1909-23	6				30	MH	1331B	1
3088B	Engine pan and hood board bolt	1909-23	100	20	1 50		03		4074	2
3088C	Engine pan and hood board bolt	1909-23	100	20	1 50		03		4073	2
3088D	Engine pan and hood board bolt—Truck	1918-23	20	20	1 50		03		TT4073	2
3088E	Engine pan and hood board bolt nut	1909-23	100		75	5 00	01		1309	
3100	CRANK CASE	1912-23	2				11 00	MH	1526E	1
3101	Crank case lower cover	1912-23	2				35	MH	1582	1
3101B	Crank case lower cover reinforcement	1912-23	4				25		4378-4379	1
3102B	C. C. lower cover gasket	1912-23	20	70	6 00		10		1586	1
3103	C. C. lower cover screw	1912-23	20	15	1 00		03		4328	14
3110	Cylinder valve cover	1912-22	4				15	MH	656A	2
3110B	Cylinder valve cover	1921-23	4				20	MH	656B	1
3111B	Cyl. valve cover gasket	1912-22	20	30	2 50		05		660A	2

\*Rough babbitted.

‡When ordered to replace old style C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664 1-3810 and 2-753 cotter.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.



Part No.	Name of Part	Year	LIST PRICE				Tax	Fac. No.	No. Req. per Car
			Minimum Wholesale sale Quan.	Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
<b>MOTOR—Continued</b>									
3111C.	Cyl. valve cover gasket	1921-23	20	\$ 0 60	\$5 00	\$ 0 10		660B.	1
3112	Cyl. valve cover screw	1912-23	20		1 50		02	654.	2
3114	C. C. arm with rivets	1909-23	6				30	815B.	2
3115	C. C. arm rivet	1909-23	50				05	312.	
<b>COMMUTATOR</b>									
3162	Com. case support bolt	1912-19	10				05	4441.	1
3162B.	Com. case support bolt	1919-23	10				05	1756.	1
3163	Com. case spring	1912-23	10				05	689.	1
3165	Com. brush only	1912-23	20	1 75	15 00		20	4481.	1
3176C.	Com. oiler	1919-23	20	40	3 00		05	480C.	1
3177	Com. felt ring	1912-23	20	15	1 00		02	5930	1
3206	Com. brush cap	1909-23	20	15	1 00		02	468B.	1
3207	Com. brush cap pin	1909-23	100		50		01	466.	1
3210	Com. contact point nut	1910-23	100		50		01	472B.	8
3220	Com. lock nut	1909-23	20	25	2 00		03	471.	1
3221	Com. case with fibre	1912-23	20		45 00		50	5908.	1
3222	Com. shield	1912-23	20		1 50		02	5923.	1
<b>MAGNETO</b>									
3250D.	Magneto coil assembly	1915-23	2			5 00		5941B.	1
3252	Magneto spool support screw	1909-23							
3254	Magnet bolt	1909-23	20	25	2 00		03	537B.	16
3255	Magnet bolt washer	1911-23	20		50		01	624.	16
3257	Magnet support	1909-23	20	30	2 00		05	535C.	16
3260	Magneto contact assy.	1909-23	10		15 00		20	MH 1545	1
3261B.	Magneto contact nut	1909-23	20		50		01	1508.	2
3261C.	Magneto contact screw washer	1909-23	20		50		01	1565.	
3262	Magneto contact spring	1909-23	20	30	2 00		05	1509.	1
3262B.	Magneto contact screw and spring assembly	1919-23	10		7 50		10	4350.	
3266	Magneto contact fibre screw	1909-23	20		50		01	1505.	3
3267	Magneto primary insulating block	1915-23	10				03	4382.	
3267B.	Magneto contact insulator	1919-23	10				05	1503B.	
3267C.	Magneto contact insulator shell	1919-23	10				03	8611.	
3268	Fly wheel ring gear	1919-23	2			1 00	MH 1885		1
3269C.	Fly wheel	1911-19	2			6 00	MH 701B		1
3269G.	Fly wheel	1919-23	2			5 00	MH 701C		1
3269H.	Fly wheel with ring gear and magnets assembled	1919-23	2			15 00	MH 5946B		1
3270	Fly wheel cap screw	1909-23	20	80	7 00		10	721.	4
3271	Fly wheel dowel pin	1909-23	20	40	3 00		05	722.	2
3272	Magneto coil support shim	1909-23	10	40	3 00		05	584.	1
3276B.	Magnet (16)	1915-23	2			4 00		5933.	16
3277	Magnet clamp	1911-23	20	25	1 60	set	03	623.	16
3277B.	Magnet clamp	1913-14	20				10	4499.	16
3278	Magnet clamp screw	1911-23	20		1 60	15 00	02	625.	16
3279	Magneto contact washer	1909-23	20		75		01	560.	1
<b>TRANSMISSION</b>									
3300B.	Transmission assy.	1919-23	2			35 00	MH 744C		1
3301	Trans. reverse plate assy.	1909-23	4			2 30	MH 747		1
3304	Trans. reverse gear bushing	1909-23	6			40		705.	1
3305	Trans. rev. and S. S. rivet	1909-23	60			doz. 05		708.	8
3306	Trans. slow speed plate assy.	1909-23	4			2 20	MH 748		1
3309	Trans. slow speed gear bushing	1909-23	6			30		745.	1
3310	Trans. brake drum rivet	1909-23	60			doz. 05		711.	8
3311	Trans. brake drum assy.	1909-23	4			2 25	MH 750		1
3313	Trans. triple gear assy.	1909-23	3			1 25	MH 751B		3
3314½	Trans. triple gear flanged bushing	1911-23	12			20		716B.	3
3315	Trans. triple gear shaft	1909-23	6			15.	MH 715		3
3316	Trans. triple gear riveting pin	1909-23	36			doz. 05		720.	24
3317	Trans. driven gear	1909-23	3			70	MH 713		1
3318	Trans. driven gear key	1909-23	12			03		714.	2
3320C.	Trans. driven gear sleeve bushing	1909-23	6			20		712.	2
3320D.	Driven gear sleeve washer	1909-23	12	40	3 50		05	776.	3
3321	Trans. driving plate assy.	1909-23	2			3 00	MH 749		1
3323	Trans. driving plate screw	1909-23							
3325	Trans. driving plate rivet	1909-23							
3327B.	Trans. driving plate bush	1909-23	6			doz. 05		736.	8
3328	Trans. clutch disc—small	1909-23	16	90	8 00		10	MH 727	12
3329	Trans. clutch disc—large	1909-23	16	90	8 00		10	MH 728	13
3331	Trans. gear shaft	1909-23	3			1 25	MH 723B		1
3332	Trans. clutch disc drum	1909-23	3			1 25	MH 725B		1
3333	Trans. clutch disc drum key	1909-23	10		3 50		05	726B.	1

††When using short bushing in making repairs remove driving plate key.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.



Part No.	Name of Part	Year	LIST PRICE			Tax	Fac.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 10 per lot	Lots of 100 per lot			
<b>TRANSMISSION—Continued</b>								
3334	Trans. clutch disc drum set screw	1909-23	10		\$3 50	\$ 0 05	752	1
3336	Trans. clutch push ring	1909-23	6			35 MH	770	1
3337	Trans. clutch finger	1909-23	6			15 MH	732B	3
3337 1/2	Trans. clutch finger screw	1909-23	6		3 00	05	756	
3337B	Trans. clutch finger and screw	1909-23	6			20 MH	765	3
3338	Trans. clutch finger pin	1909-23	10			01	735	3
3340	Trans. clutch spring	1909-23	6			25	737	1
3341	Trans. clutch spring support	1909-23	6			10 MH	738	1
3342	Trans. clutch spring thrust ring pin	1909-23	20	\$ 0 25	1 50	03	739	1
3344	Trans. clutch shift	1909-23	6			45 MH	733	1
<b>TRANSMISSION COVER</b>								
3362	Trans. cover bolt	1909-23	100		2 00	\$18 00	03	79
3362B	Trans. cover bolt nut	1909-23	Order 2515					
3363	Trans. cover gasket (front)	1909-23	20	20	1 25		05	872B
3363B	Trans. cover gasket—short	1909-23	20	20	1 00		03	4358
3367	Trans. cover door screw	1909-23	20	15	1 00		02	430
3368	Universal ball cap (rear)	1909-23	4				30 MH	818
3369	Universal ball cap (front)	1909-23	4	7 50			80 MH	819D
3371	Universal ball cap screw	1909-23	20	25	1 75	12 00	03	731
3372	Universal ball cap bolt and nut	1909-23	Order 3362 and 2515					
3375	Trans. cover screw	1909-23	Order 3072					
3376B	TRANS. COVER	1919-23	2				6 50 MH	826E
3377B	Trans. cover gasket	1909-23	20	90	8 00	pr	10	885B
3378	Trans. cover door	1911-23	4				15 MH	1546D
3379B	Trans. cover door gasket	1911-23	20	45	4 00		05	1547C
3380	Bendix cover	1919-23	4				15 MH	1763
3381	Bendix cover gasket	1919-23	20	25	2 00		03	1764
3382	Trans. cover rear plate	1919-23	4				05 MH	1761
3383	Trans. cover front plate	1919-23	4				05 MH	1758
<b>TRANSMISSION CONTROL</b>								
3400	Trans. clutch release ring	1909-23	4				20 MH	741
3402D	Clutch lever and shaft	1913-23	4				30 MH	1548
3403	Clutch lever screw	1909-23	Order 3973					
3403B	Clutch lever screw nut	1909-23	Order 3066B					
3405	Clutch lever pin	1909-23	10		60		01	1553
3406B	Clutch release fork—RorL	1913-23	4				15 MH	4345
3406C	Clutch release fork pin	1913-23	Order 3405					
3408	Clutch release fork key	1909-14	10		3 00		05	836
3409	Clutch release fork clamp screw	1909-14	10				05	835
3411	Clutch lever clevis pin	1909-23	Order 2564					
3413	TRANSMISSION BAND ASSEMBLY	1909-23	6				60 MH	838B
(Bands will be exchanged by dealers at 45 cents each)								
3415	Trans. band washer	1909-23	20	20	1 50		03	840
3416	Trans. band lining	1909-23	24				20 MH	1562
3416B	Trans. band lining—set of 3 inc. rivets—in carton	1909-23	8			set	70	1564
3419	Trans. band adj. screw	1909-23	12		7 50		10	1533
3420	Trans. band adj. screw nut	1909-23	20	30	2 50		05	1532
3421B	Trans. band ear iron rivet	1909-23	100			2 00 doz.	05	843
3422B	Trans. band brass rivet	1909-17	1000			3 60 doz.	05	844B
3423B	Trans. band brass rivet	1909-23	1000			2 50 doz.	05	845B
3425	Trans. band spring	1909-23	20	25	1 50		03	841B
3426	Trans. band adj. nut	1909-23	20	25	2 00		05	851
3427	Slow speed shaft	1909-23	6				15 MH	848B
3428	Slow speed notch	1909-23	6				25 MH	4327
3429	Slow speed notch pin	1909-23	10		60		01	1560
3432	Speed lever	1909-23	2				10 MH	862B
3434	Reverse pedal	1909-23	2				50 MH	4324
3435	Brake and rev. pedal shaft	1909-23	10				15 MH	849B
3436	Brake and rev. pedal support	1909-23	6				15	4325
3437	Brake and rev. support bolt	1909-23	20	25	2 00		05	1534
3437B	Brake and rev. support bolt nut	1909-23	Order 2515					
3439	Brake pedal	1909-23	2				50 MH	4323
3440	Clutch pedal	1909-23	2				50 MH	854B
3441	Pedal pin	1909-23	Order 3405					
3442	Clutch pedal support	1909-23	6				15	4326
3443	Clutch pedal support bolt	1909-23	20	25	2 00		05	1536
3443B	Clutch pedal support bolt nut	1909-23	Order 2515					

†When ordered to replace cover on cars below 2044100 also order 3402D clutch lever and shaft.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car	
			Minimum Wholesale Quan.	Lots of 10 per lot	Lots of 100 per lot				Lots of 1000 per lot
<b>TRANSMISSION CONTROL—Continued</b>									
3445	Slow speed connection	1909-23	6	\$0 40	\$3 50	05	1540	1	
3446	Slow speed con. lock nut	1909-23	Order 2503F						
3447	Slow speed con. clevis	1909-23	6	80	6 00	10	802	1	
3448	Controller quadrant	1909-23	3			20	309B	1	
3449	Con.shaft with speed lever	1909-23	2			60	MH 1557	1	
3450	Controller shaft bracket	1909-23	3			15	MH 311	2	
3452	Controller shaft bracket bolt	1909-23	20	25	2 00	\$15 00	03	315	4
3452B	Controller shaft bracket bolt nut	1909-23	20	15	1 25	9 00	02	316	4
3455	Hand brake lever	1909-23	2			1 00	MH 1550	1	
3456B	Hand brake lever pin	1909-23	Order 2574						
3457	Hand brake lever key	1909-17	6			05	874	1	
3458	Hand brake lever pawl	1909-23	10			05	875	1	
3459	Hand brake lever pawl pin	1909-23	100		50	01	876	1	
3460	Hand brake lever pawl rod	1909-23	2			10	MH 877	1	
3462	Hand brake lever pawl lift assembly	1909-23	4			10	4363	1	
3463	Hand brake lever pawl lift spring	1909-23	10			02	888	1	
3465	Hub brake lever	1909-23	6			15	MH 864	1	
3466	Hub brake lever pin	1909-23	Order 3405						
3467	Hub brake lever clevis	1909-23	Order 3447						
3468	Hub brake pull rod—R	1909-23	6			30	MH 891B	1	
3469	Hub brake pull rod—L	1909-23	6			30	MH 1513B	1	
3470	Brake rod support—R	1909-23	6	60	5 00	10	137C	1	
3471	Brake rod support—L	1909-23	6	60	5 00	10	1398C	1	
3472	Brake rod support bolt	1909-23	100		75	5 00	01	1308	2
3472B	Brake rod sup. bolt nut	1909-23	Order 3088E						
<b>STEERING GEAR</b>									
3500C	Steering gear assy.	1911-23	2			10 00	MH 5044	1	
3501C	St. gear rim	1920-23	2			70	901C	1	
3502	St. gear rim screw	1909-23	24			01	6849	4	
3503D	St. gear spider	1920-23	2			55	MH 902C	1	
3503E	St. gear spider and rim	1909-23	2			1 25	MH 995A2	1	
3504	St. gear cover	1909-23	2			35	MH 5039	1	
3505	St. gear cover screw	1909-23	24		50	01	910	1	
3506	St. gear cover bushing	1909-23	6			15	914	1	
3506B	St. gr. driv. pinion washer	1909-23	10			03	5026	1	
3507	St. gr. int. gear case and bushing	1909-23	2			1 25	MH 5036	1	
3509	St. gear quadrant	1909-23	2			10	MH 906B	1	
3510	St. gear quadrant rivet	1909-23	24		50	01	5041	2	
3511	St. gear wheel nut	1909-23	12	90	7 50	10	913	1	
3512C	St. gear tubing assy.	1912-23	2			4 00	MH 5016	1	
3513C	St. tubing flange screw	1913-23	20	15	1 00	03	5018	3	
3514	St. tub. flange screw nut	1913-23	100	15	75	5 00	02	926	1
3516C	St. gear post	1912-21	2			1 75	MH 5043	1	
3516D	St. gear post	1921-23				1 75	MH 5043B	1	
3517	St. gear pinion	1909-23	10			15	MH 916	3	
3518	St. gear pinion pin—short	1909-23	10			02	917	2	
3518B	St. gear pinion pin—long	1921-23	6			02	918	1	
3519	St. gear drive pinion	1909-23	3			30	MH 911	1	
3520	St. gear drive pinion key	1909-23	10	20	1 00	03	909	1	
3523	St. gear post castle nut	1909-23	Order 2551B						
3524E	Throttle rod	1912-23	2			30	MH 5038	1	
3525E	Lead rod	1912-23	2			30	MH 5037	1	
3527	Lead & throttle rod spring	1909-23	10			02	935	2	
3528	Lead & throttle rod collar	1909-23	10	15	1 00	02	936	2	
3529	Lead & throttle rod pin	1909-23	10		50	01	937	5	
3530	Lead rod lever	1909-23	6	80	6 00	10	MH 946	1	
3531	Throttle rod lever	1909-23	6	80	6 00	10	MH 947	1	
3532	Lead & throttle rod guide	1909-23	6			05	938	1	
3534B	Commutator pull rod	1912-23	6			10	MH 2082	1	
3535	Carburetor pull rod	1909-23	6		6 00	10	MH 1329	1	
3536	Ball and socket joint	1909-21	20	85	7 50	10	1326	1	
3537	Ball and socket joint nut	1909-21	20	15	1 00	62	1327	1	
3539B	St. brkt. with bushing	1911-23	3			75	MH 996	1	
3539C	St. brkt. with bushing—truck	1918-23	2			75	MH TT996	1	
3540	Brkt. bolt and nut—long	1909-23	Order 3073 and 2515						
3541	Brkt. bolt and nut—short	1911-23	Order 3074 and 2515						
3544	St. brkt. felt washer	1909-23	12		1 00	02	943	1	
3545	St. brkt. bushing	1909-23	4			20	944-5027	1	
3546	St. brkt. block	1909-23	6			10	945	1	
3546B	St. brkt. block—Truck	1918-23	4			05	TT945	1	
3547	St. gear ball arm	1909-23	6			40	MH 929B	1	
3548	St. gear ball arm key	1909-23	20	25	1 50	03	930	1	
3549	St. brkt. dust cap—Truck	1918-23	10			05	TT5044	1	
<b>BODY PARTS</b>									
3601B	Body brkt. on body	1910-23	10			10	1624	6	
3601C	Body brkt.—front—R	1921-23	10			20	7267B	1	
3601D	Body brkt.—front—L	1921-23	10			20	7268B	1	

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Wholesale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
<b>BODY PARTS—Continued</b>										
3601E	Body bracket—rear	1913-23	10				\$0 05	5650	2	
3601F	Body bracket—rear—R	1921-23	10				25	7137C	1	
3601G	Body bracket—rear—L	1921-23	10				25	8601E	1	
3602E	Body brkt. con. bolt	1916-23	30				03	2431	6	
3602F	Body brkt. con. bolt nut	1916-23		Order 2719						
3624E	Front floor rubber mat	1915-23	4				90	7299	1	
3626C	Floor board with plate (first)	1915-23	2				50	MH 4200		
3627C	Floor board with plate (second)	1915-23	2				50	MH 4201		
3628B	Floor board with plate (thlrd)	1915-23	2				65	MH 7104		
3630	Floor board forward plate for pedals	1909-23	2				10	MH 1400C	1	
3632	Floor board rear plate for pedals	1909-23	2				10	MH 1095C	1	
3633	Floor board plate for side lever	1909-23	2				05	MH 1094B	1	
3634D	Dash	1913-14	2				7 00	5336	1	
3634E	Dash	1915-16	2				5 00	7462	1	
3634G	Dash	1917-22	2				2 50	MH 8754AR	1	
3634H	Dash—(steel)	1923	2				2 00	MH 8754B	1	
3634J	Dash—steel	1923	2				2 25	MH 8754C	1	
3638B	Dash shield	1919-22	4				10	5432B	1	
3639	Dash weatherstrip—side	1917-22	6				05	8747	2	
3639B	Dash weatherstrip—top	1917-22	6				15	8752R	1	
†3640C	Dash brkt.—left	1917-22	6				15	8722	1	
*3640D	Dash brkt.—left	1923	6				15	8722B	1	
†3641C	Dash brkt.—right	1917-22	6				15	8721	1	
*3641D	Dash brkt.—right	1923	6				15	8721B	1	
3642B	Dash brkt. to dash bolt	1917-22	20	\$0 25	\$2 00		03	8740	4	
3642C	Dash brkt. to dash nut	1917-22		Order 3514						
3645	Dash brkt. to dash bolt	1909-16	30				03	2427	2	
3645B	Dash brkt. to dash nut	1909-16		Order 4805C						
3653B	Dash to body brkt. bolt	1915-23	20	15	1 00		03	4248	2	
3653C	Dash to body brkt. nut	1915-23		Order 4805C						
3654	Dash to body gasket	1918-23	12		3 50		05	8769		
3660C	Lamp & license brkt. assy	1915-23	4				25	MH 7506AR	1	
3660D	Lamp & license brkt. assy	1915-23	4				25	MH 7505	1	
†3660E	Lamp & license brkt. sup- port assy	1923	4				75	MH 7506B	1	
†3661	Lamp & license brkt. sup.	1923	4				25	MH 8767B	1	
*3661B	Lamp & license brkt. sup.	1923	4				15	MH 8768B	1	
3662	Front license brkt.—R	1920	4				10	MH 287	1	
3663	Front license brkt.—L	1920	4				10	MH 288	1	
3664	Front license bracket	1921-23	4				10	MH 493	1	
3667E	Front seat cushion	1909-21	2				6 00	MH 8076A	1	
3667F	Front seat cushion	1921-23	2				6 00	MH 8076B	1	
3670D	Rear seat cushion	1909-21	2				6 50	MH 7032A	1	
3670E	Rear seat cushion	1921-23	2				6 50	MH 7032B	1	
3676B	Rear floor mat	1911-21	2				1 00	1606B	1	
3676C	Rear floor mat	1921-23	2				85	1606C	1	
<b>SPRINGS</b>										
3800	Front spring	1909-23	4				2 50	MH 332	1	
3801	First leaf (main leaf)	1909-23	6				80	2943	1	
3802B	Second leaf	1909-23	6				45	2935	1	
3803	Third leaf	1909-16	2				50	356	1	
3803B	Third leaf	1916-23	6				40	2936	1	
3804	Fourth leaf	1909-16	2				40	357	1	
3804B	Fourth leaf	1916-23	6				30	2937	1	
3805	Fifth leaf	1909-16	2				35	358	1	
3805B	Fifth leaf	1916-23	6				25	2938	1	
3806	Sixth leaf	1909-16	2				30	359	1	
3806B	Sixth leaf	1916-23	6				20	2939	1	
3807	Seventh leaf	1909-16	2				25	360	1	
3807B	Seventh leaf	1916-23	6				15	2947	1	
3808	Front spring clip	1909-20	10				20	325C	2	
3809	Front spring clip nut	1909-23		Order 2551B						
3810	Front spring clip bar	1921-23	6	2 00			25	342	1	
3811	Front spring tie bolt	1909-23	20	20	1 50		04	1362	1	
3811B	Front spring tie bolt nut	1909-23	20	15	1 00		02	1363	1	
3813	Front spring hanger	1909-23	12	1 25	10 00		15	246B	4	
3813B	Front spring hanger	1923	12	2 25	20 00		25	246C	2	
3814	Front spring hanger bar	1923	12				05	7648	2	
3815	Spring hanger nut	1909-23		Order 2719						
3818	Front spring perch—right	1909-19	4				80	MH 274A	1	
3818B	Front spring perch—right	1909-23	6				50	MH 274B	1	
3819	Front spring perch—left	1909-19	4				80	MH 275A	1	
3819B	Front spring perch—left	1919-23	6				50	MH 275B	1	
3820	Front spring perch bush	1909-23	20	25	2 00		05	230	4	

†When used on 1911-16 cars redrill frame.

\*Used with steel dash.

†Used on Touring Cars and Roadster without starter and demountable rims.

†Used on Touring Car with starter without demountable rims.

\*\*Used on Roadster with starter without demountable rims.

††Substitute 3634H—steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
				Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
<b>SPRINGS—Continued</b>									
3821	Front spring perch nut.	1909-21	Order 2828						
3821B	Front spring perch nut.	1921-23	12				\$0 05	240	1
3823	Front spring pad.	1909-23	20	\$0 45	\$4 00			262	1
3824	REAR SPRING	1909-23	3				6 50	MH 333	1
*3824B	REAR SPRING	1922-23	2				6 75	MH 388	1
3825	First leaf (main leaf)	1909-19	2				1 50	361A	1
3825B	First leaf (main leaf)	1918-23	3				1 35	355	1
*3825C	First leaf (main leaf)	1922-23	2				1 35	389	1
3826	Second leaf	1909-19	2				1 25	362A	1
3826B	Second leaf	1918-23	3				1 10	362B	1
*3826C	Second leaf	1922-23	2				1 10	391	1
3827	Third leaf	1909-19	2				1 10	363A	1
3827B	Third leaf	1918-23	3				95	363B	1
*3827C	Third leaf	1922-23	2				95	392	1
3828	Fourth leaf	1909-19	2				95	364A	1
3828B	Fourth leaf	1918-23	3				85	364B	1
*3828C	Fourth leaf	1922-23	2				85	393	1
3829	Fifth leaf	1909-19	2				80	365A	1
3829B	Fifth leaf	1918-23	4				75	365B	1
*3829C	Fifth leaf	1922-23	2				75	394	1
3830	Sixth leaf	1909-19	2				75	366A	1
3830B	Sixth leaf	1918-23	4				60	366B	1
*3830C	Sixth leaf	1922-23	2				60	395	1
3831	Seventh leaf	1909-19	2				70	367A	1
3831B	Seventh leaf	1918-23	4				45	367B	1
*3831C	Seventh leaf	1922-23	2				45	396	1
3832B	Eighth leaf	1909-23	4				35	368B	1
*3832C	Eighth leaf	1922-23	2				35	397	1
*3832D	Ninth leaf	1922-23	2				30	398	1
3833	Rear spring clip	1909-23	10				20	326	2
*3833B	Rear spring clip	1922-23	5				20	1737	2
3834	Rear spring clip nut	1909-23	Order 2548						
3835	Rear spring clip bar	1909-23	10				05	329	2
3837	Rear spring tie bolt	1909-23	20	20	1 50		04	1352	1
3837B	Rear spring tie bolt nut	1909-23	20	15	1 00		02	1353	1
*3838	Rear spring tie bolt	1922-23	10				04	1355	1
3840	Rear spring hanger	1909-23	10	1 25	10 00		15	91 1/2B	4
3840B	Rear spring hanger	1923	10	2 25	20 00		25	91 1/2C	2
3841	Rear spring hanger bar	1923	10				05	7649	2
3842	Rear spring leather pad	1909-23	10				05	94	1
3843	Rear spring perch	1909-23	6	3 50			40	MH 2804	2
3844	Rear spring perch bush	1909-23	20	35	3 00		05	172	4
3845	Rear spring perch nut	1909-23	20		4 00		05	174	2
3846	Spring perch roller	1917-23	20	35	3 00		05	2944	4
3847	Front spr'g clamp assembly with bolt and nut	1909-16	20	75	6 00		10	374	2
3847B	Front spr'g clamp assembly with bolt and nut	1916-23	20	75	6 00		10	2953	2
3848	Rear spr'g clamp assembly with bolt and nut	1909-17	20	75	6 00		10	376	2
3848B	Rear spr'g clamp assembly with bolt and nut	1918-23	20	75	6 00		10	378	2
<b>REAR SPRING—60 INCH TREAD</b>									
3850	Rear spring	1909-16	2				9 00	MH 1704	1
3851	Rear spring clip	1909-16	Order 3833B						
3852	Rear spring tie bolt	1909-16	2				10	1738	1
3852B	Rear spring tie bolt nut	1909-16	Order 3837B						
3853	First leaf (main leaf)	1909-16	2				1 80	1739	1
3854	Second leaf	1909-16	2				1 60	1740	1
3855	Third leaf	1909-16	2				1 40	1741	1
3856	Fourth leaf	1909-16	2				1 20	1742	1
3857	Fifth leaf	1909-16	2				1 00	1743	1
3858	Sixth leaf	1909-16	2				90	1744	1
3859	Seventh leaf	1909-16	2				75	1745	1
3860	Eighth leaf	1909-16	2				60	1746	1
<b>STARTING CRANK</b>									
3900	Starting crank only	1909-22	2				40	MH 519B	1
3901	Starting crank handle	1909-22	5				20	520	1
3902	Starting crk. handle bolt	1909-22	20	60	5 00		10	521	1
3903	Starting crank sleeve	1909-22	6	80	5 00		10	523	1
3905	Starting crk. ratchet pin	1909-23	6	25	2 00		05	4491	1
3906	Starting crank ratchet	1909-23	2				20	MH 528B	1
3908	Starting crank spring	1909-23	20	20	1 20		03	626	1
3909	Starting crk handle spring	1915-22	20	15	1 00		02	5911	1
3910	Starting crank assy.	1909-23	2				50	MH 5931	1
<b>RADIATOR—THERMO-SYPHON</b>									
3925	Radiator	1909-16	2				20 00	MH 1100C	1
3925B	Radiator	1917-23	2				17 00	MH 8700B	1
3925C	Radiator less shell	1917-23	2				15 75	MH 8736B	1
3925D	Radiator	1923	2				17 00	MH 8700D	1
3925E	Radiator—less shell	1923	2				15 75	MH 8736E	1
3926	Radiator cap	1909-23	10	1 35	12 00		15	MH 8714	1

\*Nine-leaf spring for Sedan.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax	Fac. No.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
<b>RADIATOR—THERMO SYPHON—Continued</b>									
3928	Radiator pad	1909-19	10				\$0 05	1105	2
3929	Radiator stud	1909-19	10				05	1162A	2
3929B	Radiator stud	1919-23	20	\$0 45	\$4 00		05	1162B	2
3929C	Radiator stud nut	1909-23	20	25	2 00		03	1154	2
3930	Radiator stud spring	1909-23	Order 2742						
3931 1/2	Radiator stud washer nut	1909-23	20	25	2 00		03	1161	2
3932	Radiator rod	1909-23	6				15 MH	1111B	1
3934	Radiator rod nut	1909-23	Order 3066B						
3939	Outlet connection pipe	1909-23	6				25	1121	1
3940	Outlet connection cock	1909-23	Order 3079						
3944	Outlet connection hose	1909-23	20	90	8 00		10	507B	2
3945	Outlet con. hose clip	1909-23	20	40	3 50		05	554B	4
3947B	Radiator shell	1917-23	4				1 25 MH	8737B	1
3947C	Radiator shell	1923	4				1 25 MH	8737C	1
3975	Rad. stud spring upper thimble	1919-23	20				02	1115	1
3976	Rad. stud spring lower thimble	1919-23	20				03	1114	1
3977	Radiator apron	1923	10				40 MH	8016	1
<b>RADIATOR FAN</b>									
3960	Fan and pulley assembly	1909-20	4				1 25 MH	619	1
3961	Fan blade	1909-20	6				10	611	4
3961B	Fan blade rivets	1909-20	1000				05	1566	16
3961C	Fan blade assembly	1920-23	4				25 MH	620	1
3962B	Dr. fan pulley with bush	1920-23	4	6 00		\$1 50 doz.	70 MH	618B	1
3963	Fan drive pulley	1909-20	6				25 MH	602A	1
3963B	Fan drive pulley	1920-23	4				30 MH	602B	1
3964	Fan belt—23" fabric	1909-16	6				35	609A	1
3964C	Fan belt—26" fabric	1917-20	12				35	609B	1
3964D	Fan belt—fabric	1920-23	12		30 00		35	609C1	1
3964E	Fan belt—rubber	1920-23	20		30 00		35	609C2	1
3966	Fan shaft	1909-20	10				25 MH	606A	1
3966B	Fan shaft	1920-23	10	1 75	15 00		20 MH	606B	1
3967	Fan bracket	1909-16	2	3 00			40 MH	604A	1
3967B	Fan bracket	1917-23	4	2 50			30 MH	604B	1
3968	Fan bracket bolt	1909-23	20	85	7 50		10	605	1
3970	Fan grease cup	1909-23	12	85	7 00		10	601	1
3973	Fan adjusting screw nut	1909-23	20	15	1 25		02	645	1
3973B	Fan adjusting screw nut	1909-23	Order 3066B						
3974	Fan driven pulley bush	1917-20	4				15	8757A	1
3974B	Fan driven pulley bush	1920-23	6				15	8757B	2
3980	Fan pulley plug	1920-23	20	25	2 00		03	633	1
3981	Fan pulley gasket	1920-23	20	15	1 20		02	634	1
3982	Fan shaft cap	1920-23	20	15	1 00		02	635	1
3983	Fan shaft felt washer	1920-23	20	15	1 00		02	637	1
3984	Fan blade screw	1920-23	20		60		01	652	4
3985	Fan blade screw washer	1920-23	Order 3261C						
3986	Fan shaft nut	1920-23	Order 2719						
<b>MUFFLER</b>									
4025	Muffler assembly	1909-20	4				2 25 MH	1200BR	1
4025B	Muffler assembly	1921-23	2				2 25 MH	1200C	1
4026B	Muffler head—front	1917-20	2				35	1202C	1
4026C	Muffler head—front	1921-23	2				10	1202D	1
4027	Muffler shell—outer	1909-23	6				25	1203	1
4028	Muffler shell—middle	1909-23	6				20	1204	1
4029	Muffler shell—inner	1909-23	6				15	1205	1
4030	Muffler rod	1909-17	6				10	1206A	3
4030B	Muffler rod	1917-20	6				10	1206B	1
4031	Muffler rod nut	1909-20	Order 2503F						
4032	Muffler head retainer	1921-23	10				02	1210	1
4033	Muffler head retainer bolt and nut	1921-23	Order 4819B and 3514						
4035	Muffler head bolt washer	1921-23	20				doz.	925	1
4037B	Long exhaust pipe	1909-20	3				1 25	1214A	1
4037C	Long exhaust pipe	1920-23	2				1 40 MH	1214B	1
4040B	Muffler head—rear	1917-21	2				35	1201D	1
4040C	Muffler head—rear	1921-23	2				20	1201E	1
4041B	Muffler head to frame bolt and nut	1921-23	Order 3074 and 2515						
<b>HOOD</b>									
4050	Hood	1909-16	4				8 00	1300	1
4050B	Hood	1917-23	4				6 00 MH	8726	1
4050C	Hood	1923	4				6 00 MH	8726B	1
4051	Hood handle	1909-23	6				05	1314	2
4052	Hood clip	1909-16	6				10	1310	4
4052B	Hood clip	1917-23	6				05	8731	4
4053	Hood clip spring	1909-16	20				02	1311	4
4053B	Hood clip spring	1917-23	20	15	1 25		02	8734	4
4056	Hood board—left	1909-16	6				25	1339	1
4056B	Hood board—left	1917-23	6				20	8742	1
4056C	Hood board—left	1923	6				20	8742B	1
4057	Hood board—right	1909-16	6				25	1340	1

†Substitute 4025B.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 10 per lot	Lots of 100 per lot			

**HOOD—Continued**

4057B.	Hood block—right.	1917-23	6			\$0 20	8741	1
4057C.	Hood block—right.	1923	6			20	8741B.	1
4060B.	Hood support on dash.	1915-16	6			1 50	7464	1
4060C.	Hood pad (on dash).	1917-23	6	\$0 70	\$6 00	08	MH 8711AR.	2
4060D.	Hood pad (on rad. shell).	1917-23	6	1 35	12 00	15	MH 8710	1
4060E.	Hood pad (on dash).	1923	6	70	6 00	08	MH 8711B.	2
4061B.	Hood clasp (on dash).	1917-23	6	35	2 50	05	8720AR.	1
4061C.	Hood clasp (on dash) screw	1917-23	20			02	8763	2
4061D.	Hood clasp (on dash)	1920-23	6	35	2 50	05	8720BR.	1
4061E.	Hood clasp (on dash)	1923	6	35	2 50	05	8720C.	1
4061F.	Hood clasp (on dash)		6	35	2 50	05	8720D.	1
4073.	Hood bl support—front	R1917-23	12			05	8743	1
4073B.	Hood bl support—frt.	R1923	12			05	8743B.	1
4074.	Hood bl support—front	L1917-23	12			05	8744	1
4074B.	Hood bl support—frt.	L1923	12			05	8744B.	1
4075.	Hood bl support—rear	R1917-23	12			05	8745	1
4075B.	Hood bl support—rear	R1923	12			05	8745B.	1
4076.	Hood bl support—rear	L1917-23	12			05	8746	1
4076B.	Hood bl support—rear	L1923	12			05	8746B.	1

**FORD CARBURETOR PARTS (MODEL "G")**

4451A.	Float with lever	1914-21	6			25	6333AR.	1
4452A.	Spray needle assembly.	1914-21	6			15	6335AR.	1
4453A.	Gasoline Inlet needle.	1914-21	6			15	6324A.	1
6041.	Mix chamber.	1914-20	4			2 50	6340AR.	1
6042.	Mix chamber top.	1912-14-20	4			40	4801R.	1
6043.	Mix chamber top screw.	1912-20	10			02	4808R.	1
6044.	Mix chamber top gasket.	1914-20	10			01	6317R.	1
6044B.	Mix chamber bottom gasket.	1912-20	10			03	6367AR.	1
6045.	Mix chamber nut.	1912-20	6			07	4810AR.	1
6046.	Float chamber & bush.	1914-20	4			50	6318AR.	1
6047.	Float lever pin.	1914-20	10			03	6320AR.	1
6048.	Float valve seat.	1914-20	6			10	6321AR.	1
6049.	Float valve seat gasket.	1914-20	10			01	6322A.	1
6051.	Spray needle clamp nut.	1912-20	6			05	4812AR.	1
6052.	Spray nozzle.	1914-20	6			30	6341AR.	1
6053.	Spray nozzle gasket.	1912-14-20	10			01	4820AR.	1
6055.	Gas Inlet elbow.	1913-20	6			15	4859	1
6057.	Low speed tube with nut.	1915-20	4			15	6360R.	1
6058.	Low speed tube retaining screw.	1912-14-20	6			03	4814R.	1
6060.	Low speed boss screw.	1912-14-20	10			03	4816B.	1
6061.	Strangling tube.	1912-14-20	6			15	4817B.	1
6062.	Strangling tube retainer.	1912-14-20	10			02	4818B.	1
6064.	Throttle lever stop screw.	1911-21	10			02	4819B.	1
6065.	Throttle lever clamp scr.	1911-19	10			02	4521AR.	1
6068.	Throttle plate.	1912-14-20	6			10	4517AR.	1
6070.	Throttle lever.	1912-14-20	6			10	4836B.	1
6070B.	Throttle lever—over-size.	1912-14-20	6			10	4836AR.	1
6071.	Throttle lev. adj. lock nut	1911-20	10			02	4528R.	1
6074.	Aux. throttle plate.	1915-20	10			03	6337AR.	1
6076.	Aux. throttle lever spring.	1914-20	10			02	6342A.	1
6077.	Aux. throttle lever assy.	1914-21	6			15	6327A.	1
4463.	Float lever holding screw nut.	1912-19	10			02	4805AR.	1
4464.	Float lever holding screw.	1913-19	10			03	4853AR.	1
6081A.	Drain valve plug assy.			Order T-6216				

Parts for 1909-13 Carburetors supplied by Holley Kerosene Carburetor Co., Detroit, Mich.

**KINGSTON CARBURETOR PARTS (MODEL "L-2")**

6101A.	Carburetor float assy.	1917-21	6			60	6333FR.	1
6101.	Float with lever.	1915-16	6			60	6335ER.	1
6102.	Throttle lever.	1913-20	6			30	4836CR.	1
6103A.	Constant air supply lever.	1913-20	6			30	6327CR.	1
6104.	Gas valve cap.	1910-16	6			20	3005	1
6105A.	Air valve cap.	1915-16	6			30	6357AR.	1
6105B.	Air valve cap.	1917-20	6			30	6357BR.	1
6106A.	Float chamber.	1917-20	2			1 00	4802DR.	1
6107A.	Mix chamber.	1917-20	2			2 50	6340FR.	1
6108.	Mix chamber gasket.	1913-16	6			15	6367CR.	1
6108A.	Mix chamber gasket.	1917-20	10			05	6367DR.	1
6109.	Throttle gate.			Use 6068				
6110.	Constant air supply gate.	1913-14	6			05	6337BR.	1
6110A.	Constant air supply gate.	1915-20	6			10	6337CR.	1
6111.	Mix chamber nut.	1913-20	6			10	4810BR.	1
6114.	Gas valve retainer nut.	1910-16	6			10	3027	1
6115.	Spray needle assembly.	1910-21	6			40	6335D.	1
6118.	Float to lever and throttle gate screw.	1910-16	10			02	3014	1
6118A.	Float to lever screw.	1917-20	10			03	4853B.	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
<b>KINGSTON CARBURETOR PARTS (MODEL "L-2")—Continued</b>										
6120	Throttle lever adj. screw	1913-20	10				\$0 03		4520B	
6121	Throttle lev. clamp screw	1910-20	10				03		4521BR	
6122	Gas valve operating lever shaft	1913-16	6				15		6320DR	
6123	Air valve shaft	1915-20	6				20		6381AR	
6124A	Spray needle sleeve									
6125	Constant air supply spring	1913-20	10				03		6342C	
6126	Float valve seat	1915-16	6				15		6321CR	
6126A	Float valve seat	1917-20	6				20		6321DR	
6127	Gas valve	1910-16	6				30		6324BR	
6127A	Gasoline valve	1917-21	6				30		6324CR	1
6128	Air valve	1915-20	6				30		6355AR	
6129	Float valve seat gasket	1915-16	10				03		6322DR	
6129A	Float valve seat gasket	1917-20								
Order 6049										
Parts for 1909-16 Carburetors supplied by Bryne Kingston Co., Kokomo, Ind.										
<b>KINGSTON CARBURETOR (MODEL "L-4")</b>										
6150	Carburetor	1921-23	4				4 50		553A1	1
6151	Drain valve body	1921-23	6				15		6328C	
6152	Float chamber	1921-23	4				50		4802E	
6153	Mixing chamber	1921-23	4				2 50		6340G	
6154	Carb. inlet elbow									
6155	Float with lever	1921-23	6				50		6333G	1
6156	Float chamber gasket	1921-23	6				05		555D	
6157	Mix chamber gasket	1921-23	10				05		6367E	
6158	Float valve seat gasket	1921-23	10				03		6322F	
6159	Constant air supply lever assy.	1921-23	6				30		6327D	
6160	Throttle lever assy.	1921-23	6				30		4836D	
6161	Spray needle assembly	1921-23								
6162	Drain valve body clamp nut	1921-23	6				05		6395	
6163	Mix. chamber nut	1921-23	6				10		4810C	
6164	Constant air supply spring									
6165	Spray needle sleeve	1915-23	6				20		4812C	
6166	Float lever pin	1915-23	10				02		6320C	
6167	Constant air supply plate	1921-23								
6168	Throttle plate	1921-23								
6169	Drain valve plug assy.	1915-23	6				10		6329B	
6170	Throttle lever adj. screw									
6171	Air valve stop assy.	1921-23	6				15		6397	
6172	Float valve seat	1921-23	6				20		6321E	
6173	Air valve shaft assy.	1921-23	6				20		6381B	
6174	Air valve	1921-23	6				30		6355B	
6175	Gasoline valve	1921-23	6				30		6324D	1
<b>FORD CARBURETOR (MODEL "NH")</b>										
6200B	Carburetor	1920-23	4	40 00			4 50	MH	553A4	
6201	Float with lever	1920-23	6				25		6333B	1
6202B	Float chamber and bush									
	ing assy.	1920-23	6				50		6318B	
†6202C	Float chamber	1923	6				30		4802F	
6203	Float chamber gasket	1920-23	10				03		555B	
6204	Spray nozzle gasket	1920-23	10				01		4820B	
6205	Mixer chamber gasket	1920-23	10				02		6367B	
6206	Throttle lever									
6206B	Aux. throttle lever									
6207B	Mixer chamber	1920-23	4				2 50		6343R	
6208	Adj. needle clamp nut	1920-23	6				05		4812B	
6209	Throttle plate	1920-23	6				02		4517B	
6210	Float lever pin	1920-23	10				01		6320B	
6211	Float chamber screw	1920-23	6				05		6284	
6212	Float valve seat	1920-23	6				05		6321B	
6213	Spray needle assembly	1920-23	6				15		6335B	1
6214B	Spray nozzle	1920-23	6				20		6341C	
6215	Air passage vent plug	1920-23	6				05		6273R	
6216	Drain valve plug assy.	1916-23	6				10		6329	
6217	Throttle lever stop screw									
6218	Aux. throttle lever spring									
6219	Float valve seat gasket	1920-23	10				01		6322C	
6220	Gasoline inlet needle	1920-23								
†6221	Drain valve body	1923	6				15		6328D	
<b>CARBURETOR ATTACHMENTS</b>										
4127A	Carburetor adj. rod brkt.	1909-23	6				05		1357R	1
4129A	Carb. adjusting rod	1909-23	6				10	MH	7920	1
4130	Carb. flange bolt	1909-23								
4130B	Carb. flange bolt nut	1909-23								
4134	Carb. flange gasket	1909-23	20	\$0 25	\$2 00		05	MH	1380B	1
4431	Carb. priming rod	1909-23	12				05	MH	2000	1
4582	Carb. hot air pipe	1912-23	6				20	MH	686	1
4583	Priming bell crank	1919-23	6				05	MH	7691	1
4585	Priming rod plate—Coupe	1919-20	6				10		7664	1
4586	Priming rod plate—Sedan	1919-20	6				10		7665	1
4587B	Priming rod—17 1/4"	1919-22	6				15	MH	6629BR	1
4588B	Priming rod—13 1/4"	1919-22	6				15	MH	6627AR	1

†Used with mixing chamber having slots at bottom.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.



Part No.	Name of Part	Year	LIST PRICE				Tax	Fac. No.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 10	Lots of 100 per lot	Lots of 1000 per lot			
<b>CARBURETOR ATTACHMENTS—Continued</b>									
*4588C.	Priming rod—16 3/8"	1922	4				\$0 15	MH .6630AR	1
14588D.	Priming rod—13 1/2"	1923	6				15	MH .6627B	1
14588E.	Priming rod—17 1/2"	1923	6				15	MH .6629C	1
*4588F.	Priming rod—16 1/2"	1923	6				15	MH .6630B	1
4589	Priming rod—20 1/2"	1919-23	6				05	MH .8797B	1
4589B.	Priming rod—14 1/2"	1922-23	6				05	MH .8797A	1
<b>FENDERS—56 INCH TREAD</b>									
4800B.	Front fender—right	1917-23	4				4 00	MH .7976	1
4800C.	Front fender—right	1923	4				4 00	MH .7976B	1
4801B.	Front fender—left	1917-23	4				4 00	MH .7977	1
4801C.	Front fender—left	1923	4				4 00	MH .7977B	1
4802F.	Rear fender—right	1917-23	4				3 50	MH .8850	1
*4802G.	Rear fender—right	1922-23	2				3 50	MH .7730	1
4802H.	Rear fender—right	1923	4				3 75	MH .8850B	1
4803F.	Rear fender—left	1917-23	4				3 50	MH .8851	1
*4803G.	Rear fender—left	1922-23	2				3 50	MH .7731	1
4803H.	Rear fender—left	1923	4				3 75	MH .8851B	1
4804D.	Rear fender iron—R. & L.								
	—T. C.	1913-23	6				15	5405	2
4804E.	Rear fender iron—right								
	Cp. & Rbt.	1913-23	2				50	5563	1
4804F.	Rear fender iron—left								
	Cp. & Rbt.	1913-23	2				50	5390	1
4804G.	Rear fender iron—R. or L.—Sedan	1916-17	2				25	8154A	2
4804K.	Fender iron—R. or L.—Sedan	1918-23	2				15	8154B	2
4804L.	Rear fender iron—T. C.	1921-23	2				10	7395	2
4804-M.	Rear fender iron—right	1923	2				50	5563B	1
4804-N.	Rear fender iron—left	1923	2				50	5390B	1
4805B.	Rear fender iron bolt	1915-23	20	\$0 20	\$1 50		03	7171	6
4805C.	Rear fender iron bolt nut	1915-23	100	15	1 00	\$6 00	02	341	
4806B.	Fender eye bolt	1909-23	20				05	1942	4
4806C.	Fender eye bolt washer	1909-23	20		50	4 00	01	1943	4
4806D.	Fender eye bolt nut	1909-23	20						
								Order 2825B	
4808.	Front fender iron bolt (side)	1910-23	20	25	2 00	15 00	03	1323	2
4808B.	Front fender iron bolt (bottom)	1910-23	20	25	2 00	15 00	03	347	2
4808D.	Front fender iron bolt nut	1910-23						Order 2515	
4808C.	Front fender apron to frame bolt	1915-23	20	15	1 25	8 00	03	4088	4
4808E.	Front fender apron to frame bolt nut	1915-23						Order 3088E	
4809	Front fender iron—R or L	1909-23	2				60	343	2
4850	Frt.fender apron brkt.—R	1917-23	2				10	8854	1
4851	Frt.fender apron brkt.—L	1917-23	2				10	8855	1
4852	Frt. fender iron brkt.—R	1915-23	2				15	7984	1
4853	Frt. fender iron brkt.—L	1915-23	2				15	7998	1
4854	Rear fender iron bracket	1915-23	4				15	7483	2
4855	Rear fdr to R.B.shield bkt	1915-23	4				05	7994	2
<b>RUNNING BOARD AND SHIELDS—56 INCH TREAD</b>									
4812.	Running board—R.	1909-23	4				1 25	MH .5418	1
4813.	Running board—L.	1909-23	4				1 25	MH .5480	1
4814C.	R. B. shield—R.	1917-23	4				2 40	MH .7986	1
*4814D.	R. B. shield—L.	1922-23	2				2 40	MH .7747	1
4815C.	R. B. shield—L.	1917-23	4				2 40	MH .7987	1
*4815D.	R. B. shield—R.	1922-23	2				2 40	MH .7748	1
4816.	R. B. truss rod—front with nuts	1909-21	4				35	MH .5804	1
4817.	R. B. truss rod—rear with nuts	1909-21	4				35	MH .5805	1
4817B.	Truss rod nut	1909-21	100	25	2 00		03	339	4
4818B.	R. B. bracket assy.	1909-21	4				1 10	2926	2
4819.	R. B. to rear fender bolt	1909-20	20	15	1 25		03	1344B	4
4819B.	R. B. to rear fender bolt	1921-23	20	20	1 50		03	8161	4
4819C.	R. B. to rear fender nut	1909-23	20					Order 3088E	
4819D.	R. B. to rear fender nut	1909-23	20					Order 3514	
4820.	R. B. to front fender bolt and nut	1909-20						Order 4808C and 3088E	
4820C.	R. B. to front fender bolt	1921-23						Order 4805B	
4821.	R. B. to shield clamp		6				05	5478	
<b>RUNNING BOARD—TRUCK</b>									
4830	Running board—R. or L.	1918-23	2				50	MH.TT5418	2
4831.	R. B. bracket	1918-23	2				35	TT2926	4
4832.	R. B. bracket brace	1918-23	2				15	TT2927	2
4833.	R. B. bracket rear brace	1918-23	2				30	TT2929	1
4834.	R. B. bracket—rear	1918-23	2				35	TT2925	
4835.	R. B. bracket and brace assy.—frt.	1918-23	2				50	TT2928	
4836.	R. B. bracket and brace assy.—rear	1918-23	2				1 10	TT2930	

\*For Four-door Sedan.

†Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum Wholesale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
<b>FORD SPARK COIL</b>										
5000	Coil (includes switch)	1909-22	2				\$ 8 65	MH	1383	1
5001	Coil (less switch)	1909-23	2				7 90	MH	1383B	1
5002	Coil box with cover	1914-22	2				2 25	MH	5858	1
5003	Coil box with cover	1919-23	2				1 50	MH	5858B	1
5004	Coil box cover	1915-23	2				25		7910	1
5005B	Switch cover	1918-22	4				10		5835B	1
5006	Switch plug	1914-22	20	\$0 25	\$2 00		05		5815A	1
5007	Coil unit	1914-23	6				1 60	MH	5845	4
5008	Vibrator	1914-23	20	60	5 00	\$40 00	10		6797	4
5009	Vibrator bridge	1914-23	20	80	7 00	60 00	10		6702	4
<b>SWITCH</b>										
5010	Switch assembly (on coil)	1914-22	6				65		5873	1
5012	Ignition switch (on instrument board)	1919-23	6	9 00			1 00		7675E	1
5013B	Switch key—give serial number	1919-23	6	50			10		5815C	1
5014	Starting switch (on floor bd)	1919-23	6	5 00			65	MH	8792	1
5014B	Starting switch bracket bolt—long	1920-23	10				03		8760	1
5014C	Starting switch brkt assy	1923	4				30		8696	1
5014E	Starting switch cover and plunger assy	1923	2				25		8698	1
5015	Starting switch plunger extension	1919-23	6	50			10		8793	1
<b>AMMETER</b>										
5016	Ammeter	1919-23	6	7 00			80		7680	1
5017	Ammeter lens & rim	1919-23	6	1 50			20		8105	1
5017B	Ammeter lens	1919-23	6				05		8121	1
<b>BENDIX DRIVE</b>										
5018	Bendix	1919-23	4				5 00		1883	1
5019	Bendix head	1919-23	4				50		2007	1
5020	Bendix key	1919-23	20		1 50		02		1751	1
5021	Bendix shaft & gear	1919-23	6				4 00		2026	1
5022	Bendix spring	1919-23	6				45		2006	1
5023	Bendix shaft spring screw	1919-23	20	20	1 00		03		1983	1
5024	Bendix head spring screw	1919-23	100	30	2 00		05		1781	1
5025	Bendix spring screw lock washer	1919-22	20		50		01		1782	2
<b>WIRING</b>										
5026	Spark plug wire 14 1/8"	1909-23	20	70	6 50		10	MH	1365	1
5027	Spark plug wire (also magneto to coil) 10 1/2"	1909-23	20	65	6 00		10	MH	1366	1
5028	Spark plug wire, 7"	1909-23	20	60	5 00		10	MH	1376	2
5030	Commutator wire	1909-23	10				70	MH	7502AR	1
*5030B	Commutator wire	1922-23	10				1 00	MH	7502C	1
5031	Com. wire (starter type)	1919-23	10				1 00	MH	7502B	1
5033	Com. wire loom support	1909-23	10				03		1390	2
5033B	Com. wire term. retainer	1921-23	10				01		2124	2
5033C	Wire on dash clip	1919-23	20				01		7688	7
5034	Ammeter to cutout wire—Sedan 33"	1919	6				15	MH	7683A	1
5035	Ammeter to cutout wire—Sedan 49"	1919-23	6				20	MH	7683B	1
5036	Ammeter to cutout wire—Coupe 23"	1919	6				15	MH	7684A	1
5037	Ammeter to cutout wire—Coupe 41"	1919-23	6				20	MH	7684B	1
5038	Ammeter to ignition switch wire	1919-23	6				10	MH	7681	1
5039	Gen. to cutout wire	1919	6				15	MH	7687	1
5040	Terminal block to switch wire	1919-23	6				05	MH	8894B	1
5041	Lighting wire	1919-23	6				90	MH	7682B	1
5041B	Lighting wire—truck	1921-23	2				1 00	MH	TT7682	1
*5041C	Lighting wire	1922-23	6	5 00			55	MH	7661	1
5042	Switch wire—Sedan	1919-23	6				75	MH	7685B	1
5043	Switch wire	1919-23	6				75	MH	7686B	1
*5043B	Switch wire	1922-23	6	4 00			50	MH	7660	1
5044	Terminal block	1919-23	6				05		1950AR	1
5044B	Terminal block	1923	6				10		1950B	1
*5044C	Terminal block	1922	6				05		1951AR	1
*5044D	Terminal block	1923	6				10		1951B	1
5045	Terminal block to dash screw	1919-23	12				01		2073	2
5046	Battery to switch cable—28 1/4"	1919-23	4				80	MH	1889B	1
5046C	Battery to switch cable—truck	1921-23	2				80	MH	TT1889	1

\*Used on cars without starter, with switch on instrument panel.

‡Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 10 per lot	Lots of 100 per lot			
<b>WIRING—Continued</b>								
5047	Battery to switch cable —34	1920	4			\$0 75	MH 1889C	1
5047B	Battery to switch cable support—truck	1920-23	2	50		10		2116
5047C	Battery to switch cable support	1920-23	2			10		2112
5047D	Battery to switch cable support bush	1920-23	2			05		2113
5047E	Battery to switch cable sleeve	1921-23	2			05		2120
5048	Ground cable—20'	1919	4			70	MH 1890A	1
5049	Ground cable—9'	1919-23	4			45	MH 1890B	1
5049B	Ground connector	1919-23	1			30	MH 1890B	1
5049C	Ground connector	1919-23	2			40	MHTT 1890	1
5050	Ground cable—11 1/2'	1920	4			60	MH 1890C	1
5051	Switch to motor cable	1919-23	4			60	MH 1891	1
5051B	Switch to motor cable sleeve	1921-23	2			30		2119
5052	Battery cable terminal bolt	1919-23	10			02		1937
5052B	Battery cable terminal bolt nut	1919-23	10			01		1938
<b>CUT-OUTS</b>								
5054	Cut-out (electric) on dash	1919	2			1 10	MH 7677AR	1
5055	Cut-out (electric)	1919-23	12	8 50		1 00	MH 7677B	1
<b>STARTER PARTS</b>								
5056	Motor mount'g gasket	1919-23	20		\$1 50	02		1768
5057	Gen. head gasket	1919-23	20	15	1 00	02		1774
5058	Gen. m't'g short screw	1919-23	24	20	1 50	03		1755
5059	Bendix cover screw	1919-23	24		50	01		1765
5060	Term. blk. to wire screw	1919-23	24		50	01		2015
5061	Ammeter to plate screw	1919-23	24		50	01		5819
5062	Motor mounting screw	1919-23	100	15	1 00	02		5510
<b>STARTING MOTOR AND PARTS</b>								
5099	Starting motor	1919-23	2			17 00	MH 1877	
5100	Armature	1919-23	2			5 00		1940
5101	Cover band	1919-23	4			10		1801C
5102	Brush end bracket	1919-23	6			35		1868
5103	Bracket assy. mounting	1919-23	4			1 30		2037
5104	Brush	1919-23	12			25		1806
5105	Shaft rear bushing	1919-23	6			30		1759
5106	Shaft front bushing	1919-23	6			10		1789
5107	Field coil assembly	1919-23	2			2 50		1871
5108	Brush holder assembly	1919-23	6			50		1864B
5109	Terminal outer insulator	1919-23	20	15	1 00	02		1795
5110	Terminal inner insulator	1919-23	20		50	02		1794
5112	Terminal nut	1919-23	20	20	1 50	03		1791
5113	Field screw	1919-23	24	15	1 00	02		1788
5114	Brush end bracket to yoke screw	1919-23	24			doz. 05		1808
5115	Brush tension spring	1919-23	20	35	3 00	05		1809
5116	Terminal washer	1919-23	24		50	01		1792
5117	Terminal inner steel washer	1919-23	24		50	01		1798
5118	Motor yoke assembly	1919-23	2			3 50		1852
<b>GENERATOR AND PARTS</b>								
5119	Generator	1919-23	2			17 00	MH 1879	
5120	Armature (less bearings)	1919-23	6			5 00		1925
5121	Small bearing	1919-23	6			1 10		1838
5122	Large bearing	1919-23	6			1 25		1841
5123	Terminal bolt	1919-23	24		1 50	03		1836
5124	Brush end bracket	1919-23	6			30		1894
5125	Large brush	1919-23	24	1 35	12 00	15		1844
5126	Small brush	1919-23	24	1 35	11 50	15		1845
5127	Large bearing disc	1919-23	12			03		1847
5128	Small bearing felt	1919-23	12	15	1 00	02		2033
5130	Head	1919-23	4			50		2044
5131B	Small brush holder	1919-23	12	1 25	10 00	15		1821
5132B	Brush holder ring	1919-23	12			05		1996
5132C	Brush holder assembly	1919-23	6			40		1865
5132D	Brush holder assembly less small brush holder	1919-23	6			35		1920
5133	Terminal outer insulator	1919-23	20	25	2 00	03		1827
5134	Terminal nut	1919-23	24	20	1 50	03		1818
5134B	Brush holder stud nut	1919-23	24			01		6754
5135	Oiler	1919-23	20			05		1837
5136	Pinion to shaft pin	1919-23	24			doz. 05		1750
5137	Pinion	1919-23	6			35		1752
5138	Small brg. felt retainer	1919-23	24		1 20	02		1832

†Also for generator.

‡Armature may be exchanged with dealer at \$4.00.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Each	Tax Status	Fac. No.	No. Req. per Car
			Minimum Whole-sale Quan.	Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
<b>GENERATOR AND PARTS—Continued</b>										
5139	Large brush spring	1919-23	20	\$0 35	\$3 00		\$0 05		1967	
5140	Small brush spring	1919-23	20	35	3 00		05		1988	
5141B	Small brush holder stud	1919-23	20	15	1 00		02		1823C	
5142	Terminal washer	1919-23	100		50		01		1831	
5142B	Small brush holder stud washer	1919-23	24		30	doz.	05		2058	
5143	Field winding assembly	1919-23	2				1 50		1978	
5144	Brush to terminal wire	1919-23	6				05		1851	
5145	Gen. yoke assembly	1919-23	1				3 00		1887	
<b>BATTERY BRACKET AND PARTS</b>										
5150	Bracket assembly	1919-23	2				90	MH	8841AR	
*5150B	Battery bracket assy.	1923	2				90	MH	8841B	1
5151	Clamp bolt	1919-23	24				03		8846	
5151B	Clamp bolt nut	1919-23	24							
5152	Clamp	1919-23	6			Order 2825B	05		8844AR	
*5152B	Battery clamp	1921-23	6				05		8844B	2
5153	Battery support angle—truck	1921-23	2				15		TT8816	1
5154	Battery box support—truck	1921-23	6				20		TT8817	2
5155	Battery clamp support—rear—truck	1921-23	2				15		TT8818	1
5156	Battery clamp support—front—truck	1921-23	2				15		TT8819	1
5158	Battery box—less cover	1921-23	2				75		7671	1
5159	Battery box cover assy.	1921-23	2				60		5491	1
5160	Battery box cover door	1921-23	2				10		5493	
<b>BATTERY (FORD)</b>										
5175	Battery	1919-23	4				18 00	MH	7670	1
5176	Battery case assy.	1919-23	2				1 25		5434	
5177	Cell connector	1919-23	6		1 00		15		5435	
5178	Cell cover	1919-23	6				30		5436AR	
5178B	Cell cover	1921-23	6				30		5436B	
5179	Terminal post gasket	1919-23	20				01		5437AR	
5179B	Terminal post gasket	1921-23	20				01		5437B	
5180	Rubber jar	1919-23	6				65		5438	
5181	Terminal post nut	1919-23	20		30		04		5439AR	
5181B	Terminal post nut	1921-23	20		30		04		5439B	
5182	Negative group assy.	1919-23	6				2 00		5440AR	
5182B	Negative group assy.	1921-23	6				2 00		5440B	
5183	Positive group assy.	1919-23	6				2 00		5441AR	
5183B	Positive group assy.	1921-23	6				2 00		5441B	
5184	Filler plug with gasket	1919-23	10				15		5444AR	
5184B	Filler plug with gasket	1921-23	10				15		5444B	
5184C	Filler plug	1923	10				10		5442C	
5185	Plate separator	1919-23	100		\$2 50	\$20 00	05		5445	
5186	Positive plate	1919-23	20				30		5427AR	
5186B	Positive plate	1921-23	20				30		5427B	
5187	Negative plate	1919-23	20				30		5428AR	
5187B	Negative plate	1921-23	20				30		5428B	
5188	Negative terminal post	1919-23	10				20		5425AR	
5188B	Negative terminal post	1921-23	10				15		5425B	
5189	Positive terminal post	1919-23	10				20		5426AR	
5189B	Positive terminal post	1921-23	10				15		5426B	
<b>SPARK PLUGS</b>										
5201	Spark plug "Ford" (Champion)	1909-23	20	4.50 net.	40.00 net.		60		1386A3	4
5203B	Spark plug porcelain "Ford" (Champion)	1909-23	20	2.20 net.	20.00 net.		30		3760C	4

\*Used with steel battery box.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Co. 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Minimum Whole-sale Quan.	List Price Each	Tax Status	Fac. No.
<b>REPAIR TOOLS</b>					
1349	Hub cap wrench	6	\$0 15		1349
1387	Adjustable wrench	6	40		1387
1903	Pliers	6	25		1903
1917	Double end wrench	6	15		1917
2335	Spark plug and cyl. head bolt wrench	6	40		5893
2336	Tool roll	6	25		1979
2337	Oil can	6	20		1384
2338	Tire pump	6	1 30	MH	1368
2340	Tire irons, each	6	15		4069
2343	Jack	6	1 50		3389
TT4069	Tire iron (large)	6	45		
5Z-152	Rear axle housing bolt nut wrench	6	40		
5Z-153	Socket wrench for crank shaft bear. bolt nut	6	60		
5Z-154	Body bracket con. bolt R. & L. wrench	6	30		
5Z-155	3/8" L socket wrench	6	45		
5Z-156	Crank shaft bearing bolt wrench	6	50		
5Z-157	Con. rod cap bolt nut L wrench (Cyl. No. 4)	6	50		
5Z-158	D/S housing stud nut wrench for 1/2" nut	6	50		
5Z-159	Connecting rod T wrench	6	55		
5Z-160	3/8" T socket wrench	6	75		
5Z-161	Body bracket connecting bolt T wrench, front and center	6	55		
5Z-162	Large cam gear lock nut wrench	6	55		
5Z-163	Generator third brush adjusting wrench	6	20		
5Z-165	Drive shaft pinion T wrench	6	65		
5Z-193	Spindle cone adjusting open end wrench	6	25		
5Z-195	3/8" open end wrench	6	25		
5Z-196	Rear axle entering wrench	6	30		
5Z-204	Exhaust pack nut open end wrench	6	1 00		
5Z-206	Rear axle nut open end wrench	6	65		
5Z-209	Connecting rod clamp screw wrench	6	45		
5Z-210	Fly wheel cap screw wrench	6	75		
5Z-212	Body bracket connecting bolt holding open end wrench	6	25		
5Z-232	Spindle arm bushing driver	6	40		
5Z-249	Generator third brush adj. wrench—new style	6	20		
5Z-280	Valve grinder	6	75		
5Z-285	1 1/2" hex. brace wrench	6	75		
5Z-286	Rear axle nut and housing plug brace wrench	6	80		
5Z-287	Rear wheel puller assembly	4	1 00		
5Z-289	1 1/2" brace socket wrench	6	75		
5Z-290	Piston ring squeezer	6	30		
5Z-314	Transmission clutch disc drum puller	3	75		
5Z-319	Valve spring lifter	6	30		
5Z-323	Bendix shaft head puller	2	1 00		
5Z-324	Trans. band ratchet wrench	6	50		
5Z-325	Con. rod cap bolt nut brace wrench with universal joint for No. 4 connecting rod	2	2 50		
5Z-326	Small time gear and trans. driven gear puller	2	1 50		
5Z-361	Large time gear puller	2	9 00		
5Z-362	Cam gear puller (3-spoke design)	2	6 50		
5Z-457	Valve seat reamer—Old No. 20Z-340	2	2 50		
20Z-340-1	Valve seat reamer cutter	2	1 50		
21Z-356	Valve seat reamer handle	2	1 00		

**REPAIR TOOLS—TRUCK**

5Z-288	Rear wheel puller assembly	2	1 20		
3389X	Jack	2	2 50		

**COTTER PINS**

	Fac. No.		Fac. No.
5/16" x 1" cotter pins	421	5/16" x 1 1/2" cotter pins	66
5/16" x 3/4" cotter pins	753	5/16" x 1 1/4" cotter pins	544
3/8" x 1" cotter pins	82	5/16" x 3/8" cotter pins	88
Price, per dozen			05.
Price, per gross			25.
Price, per thousand			75.

Part No.	Name of Part	Year	LIST PRICE			Tax Status
			Minimum Wholesale Quan.	Lots of 10 per lot	Lots of 100 per lot	
<b>ELECTRIC HORN</b>						
6432BRX	Electric horn complete	2				\$1 60
6432CX	Electric horn complete—battery type	2				1 60
7915X	Electric horn terminal wire 9'	6				05 MH
7917BX	Electric horn to switch wire 35½"	6				10 MH
8028X	Horn switch assembly	6				30 MH
6437CX	Battery horn bracket					10
<b>ELECTRIC HEADLAMPS (STANDARD 1915-23)</b>						
6511HX	Headlamp assembly	2 pr.		pr		6 00
6511KX	Headlamp assembly	2 pr.		pr		6 00
6594AX	Door assembly—used with 6511DX	6				6
6594HX	Door assembly with refracting lens	6				65
6589X	Switch assembly—with screws	6				35 MH
8650X	Headlamp and horn switch assembly	6				40 MH
8892ARX	Dimmer resistance coil with wires	2				50 MH
*8892BX	Dimmer assembly	2				50 MH
*8890X	Dimmer cover	2				10
6572AX	Headlamp bulb—9 volt—18 c.p.—double contact—used with magneto without dimmer	1915-18	20		\$27 50	30
6572HX	Headlamp bulb—6-8 volt—bright, 21 c.p., dim, 6/10 c.p.—double contact—double filament—used with T6576HX lens	1922-23	20		36 00	40
6572KX	Headlamp bulb—6-8 volt—21 c.p.—double contact—used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens	1922-23	20			35
6578X	Door lens gasket	10				03
6576HX	Headlamp lens—refracting—in carton (Pair)	10 pr.		45 00		50
6592X	Plug—with thimble	10		8 00		10
6585AX	Reflector	6				75
6585BX	Reflector (dimmer type)	6				90
6580X	Focusing screw	10				03
6591X	Focusing screw spring	10				01
6574X	Bulb socket	10				15
6574BX	Head lamp plug socket	10				15
6586X	Reflector spring	10				05
7487X	Switch to terminal wire—11½" long	10				05 MH
7489X	Lamp to lamp wire—40" long	10				10 MH
7490X	Lamp to ground wire—10½" long	10				05 MH
2122X	Head lamp wire bushing	10				03
4082X	Head lamp and tail lamp wire bushing	10				01
<b>SIDE OIL AND TAIL LAMPS—1915-23</b>						
6561X	Side oil lamp, per pair	2 pr.				4 50
6568X	Tail lamp	2				2 50
6568BX	Oil tail lamp	1923	2			2 50
7669X	Electric tail lamp assembly	1915-23	4	8 00		90
6484AX	Tail lamp red lens	10				15
6484BX	Electric tail lamp red lens	10		10 00		15
6484CX	Oil tail lamp door lens (white) Edmunds & Jones design	1923	4			15
6484DX	Oil tail lamp door lens (white) J. W. Brown design	1923	4			15
6485B	Oil tail lamp side lens (red)	1923	4			10
6406X	Electric tail lamp white lens retainer	1923	4			05
6520X	Bulb (tail lamp and headlamp dimmer) 6-8 volt—2¼ c.p.—single contact	1919-23	20			20
6495X	Electric tail lamp bulb socket	6				15
2107X	Tail lamp wire clip	10				01
2108X	Tail lamp wire spring	10				03
6409X	Tail lamp wire bushing assembly	10				03
6410X	Tail lamp wire bushing support	10				01
T78821X	Tail lamp to ground wire assembly	6				15 MH
6599X	Side oil and tail lamp fount	2				50
6956X	Side oil lamp door	2				50
6957X	Tail lamp door	2				50
6957BX	Tail lamp door	2				50
6966X	Tail lamp white lens and frame	2				20
6460X	Lamp burner	2				25
6483X	Side oil lamp door lens	2				15
6392X	Lamp wick	6				05
<b>TOURING CAR AND TORPEDO WINDSHIELDS—1915-22</b>						
7840ARX	Windshield assembly, less glass	1917-22	2			4 00
7818BX	W/S hinge assembly—right	1917-22	2			30
7819BX	W/S hinge assembly—left	1917-22	2			30
7820BX	W/S frame assembly—upper	1917-22	2			1 50
7822BX	W/S upper half assembly—less glass	1917-22	2			1 40
7823ARX	W/S lower half assembly—less glass	1915-22	2			1 65
7802ARX	W/S lower frame only	1915-22	2			1 00

\*Used on cars without starter with switch on instrument panel.

†Order 7845X-7846X extra for 1915-16 cars.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status
			Minimum Wholesale Quan.	of 10	of 100	Each	
<b>TOURING CAR AND TORPEDO WINDSHIELDS—1915-22—Continued</b>							
7803ARX.	W/S lower frame filler block	1915-22	2				\$0 20
7839X.	W/S frame filler block	1915-17	2				15
7888ARX.	W/S block (frame filler)—upper	1917-22	2				20
7810X.	W/S hinge bolt	1915-16	10				03
7845ARX.	W/S bracket—right	1915-22	2				50
7845BX.	W/S bracket—right	1919-22	2				50
7846ARX.	W/S bracket—left	1915-22	2				50
7846BX.	W/S bracket—left	1919-22	2				50
7824ARX.	W/S glass clamp	1915-22	6				02
7887X.	W/S frame—upper	1917-22	2				75
3827X.	W/S top snap loop	1915-22	2				02
1154X.	W/S hinge bolt nut	1915-22			Order 3929C		
2449BX.	W/S glass clamp screw	1915-22	10				01
2257BX.	W/S hinge to frame screw	1915-22	10				02
292X.	W/S hinge spring	1915-22			Order 2742		
7851ARX.	W/S upper glass stop—nickel	1915-22	6				20
7852ARX.	W/S lower glass stop—nickel	1915-22	6				20
7808X.	W/S hinge thimble	1915-22	6				03
<b>TOURING CAR AND ROADSTER WINDSHIELDS—1922-23</b>							
7836X.	Anti-rattler (windshield)	1922-23	4				15
6645X.	Bolt (W/S bracket to instrument panel)	1922-23	12				03
7837X.	Bracket (windshield) assembly—R. H.	1922-23	2				75 MH
7838X.	Bracket (windshield) assembly—L. H.	1922-23	2				75 MH
*7891X.	Bracket (side oil lamp)	1922-23	4				30
9066X.	Channel (windshield) center	1922-23	4				35
7816X.	Cone (W/S frame)	1922-23	4				10
7802BX.	Frame (windshield) assembly—lower	1922-23	2				1 00
7887CX.	Frame (windshield) assembly—upper	1922-23	2				1 00
7888BX.	Filler (windshield upper frame)—lower	1922-23	4				05
7847X.	Filler (windshield upper frame)—upper	1922-23	4				05
7803BX.	Filler (windshield lower frame)	1922-23	4				10
7825X.	Nut (windshield clamp stud wing)	1922-23	6				15
7842X.	Nut (windshield cone lock)	1922-23	12				02
1307X.	Nut (windshield bracket to instrument panel bolt) lower	1922-23	12				05
7851BX.	Retainer (windshield glass) upper	1922-23	6				20
7852BX.	Retainer (windshield glass) lower	1922-23	6				20
7826X.	Stud (windshield frame clamping)	1922-23	12				03
7833X.	Washer (windshield clamp stud nut)	1922-23	12				01
7840BX.	Windshield assembly—less glass	1922-23	2				5 25 MH
7822CX.	Windshield (upper half) ass'y.—less glass	1922-23	2				1 90
7823BX.	Windshield (lower half)—less glass	1922-23	2				1 40
*8064X.	Windshield bracket to body bolt	1922-23	12				02

\*Used on cars without starter with switch on instrument panel.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.



Part No.	Name of Part	Year	Minimum Whole- sale Quan.	List Price Each	Tax Status
<b>TOURING CAR TOPS—1915-22</b>					
7940ARX	Touring car top complete.....	1915-22		*\$27 00	MH
6882ARX	T. C. storm curtain—R. H.	1915-22	2	2 00	MH
6883ARX	T. C. storm curtain—L. H.	1915-22	2	2 00	MH
4966BRX	T. C. side curtain—R. H.	1915-22	2	2 50	MH
4967BRX	T. C. side curtain—L. H.	1915-22	2	2 50	MH
6894ARX	T. C. center deck complete.....	1915-22	2	7 00	MH
6815ARX	T. C. side quarter pad.....	1915-22	2	1 00	
6940ARX	T. C. back stay and curtain assembly.....	1915-22	3	3 00	MH
3897X	T. C. wood bow.....	1913-17	2	60	
8973ARX	T. C. front and rear extension rib.....	1918-22	2	40	
8974ARX	T. C. front and rear upright rib.....	1918-22	2	40	
4596X	T. C. bow separator—male.....	1913-17	6	05	
4597X	T. C. bow separator—female.....	1913-17	6	05	
6832X	T. C. bow separator.....	1918-22	6	05	
6860ARX	T. C. front extension bow socket—R. H.	1915-17	2	1 00	
6860BRX	T. C. front extension rib socket—R. H.	1918-22	2	1 00	
6861ARX	T. C. front extension bow socket—L. H.	1916-17	2	1 00	
6861BRX	T. C. front extension rib socket—L. H.	1918-22	2	1 00	
3884ARX	T. C. rear extension bow socket—R. H.	1913-17	2	1 00	
3884BRX	T. C. rear extension rib socket—R. H.	1918-22	2	1 00	
3885ARX	T. C. rear extension bow socket—L. H.	1913-17	2	1 00	
3885BRX	T. C. rear extension rib socket—L. H.	1918-22	2	1 00	
6862ARX	T. C. front upright bow socket—R. H.	1915-17	2	1 00	
6862BRX	T. C. front upright rib socket—R. H.	1918-22	2	1 00	
6863ARX	T. C. front upright bow socket—L. H.	1915-17	2	1 00	
6863BRX	T. C. front upright rib socket—L. H.	1918-22	2	1 00	
3882ARX	T. C. rear upright bow socket—R. H.	1913-17	2	1 00	
3882BRX	T. C. rear upright rib socket—R. H.	1918-22	2	1 00	
3883ARX	T. C. rear upright bow socket—L. H.	1913-17	2	1 00	
3883BRX	T. C. rear upright rib socket—L. H.	1918-22	2	1 00	
7831ARX	Curtain to windshield hook.....	1915-22	10	02	
7832X	Curtain to body hook.....	1915-22	10	02	
892X	Rib socket cotter.....	1918-22	10	02	
3924ARX	T. C. top to windshield strap assembly.....	1915-22	6	25	
3629ARX	T. C. rear strap assembly complete.....	1913-21	6	40	
3629BRX	Strap strap assembly.....	1921-22	4	40	
6829AX	T. C. duquesne clip—upper.....	1914-17	10	10	
6829BX	T. C. extension support—upper.....	1918-22	10	10	
6830AX	T. C. duquesne clip—lower.....	1914-17	10	10	
6830BX	T. C. extension support—lower.....	1918-22	10	05	
8937X	T. C. top snap fastener—single.....	1917-22	10	05	
8938X	T. C. top snap fastener—double.....	1917-22	10	05	
3314ARX	T. C. top prop rest with strap.....	1913-22	4	60	
3858X	T. C. top prop rest arm.....	1913-21	4	25	
3624X	T. C. bow socket to seat iron japanned nut.....	1913-22	6	03	
6682X	Curtain celluloid 20" x 50"—.015 thick (old No. 3383X)	1913-22	2	20	
6682X	Curtain celluloid 10" x 18"—.015 thick (old No. 3383X)	1913-22	2	40	
4981ARX	Touring car top visor.....	1920-22	2	50	
48940X	Curtain fastener eyelet.....	1917-22	10	01	
48943X	Curtain fastener eyelet washer.....	1917-22	10	01	
<b>TOURING CAR TOPS—1922-23</b>					
3573X	Brace (top extension)—R. H.	1922-23	2	35	
3574X	Brace (top extension)—L. H.	1922-23	2	35	
**3588X	Top clamping bracket assembly.....	1922-23	2	25	
**6902X	Glove fastener button.....	1922-23	12	02	
††6940BRX	Curtain (rear) assembly.....	1922-23	2	2 50	MH
6940CX	Curtain (rear) assembly.....	1922-23	2	2 50	MH
††4966CRX	Curtain (rear side) assembly—R. H.	1922-23	2	2 00	MH
4966DX	Curtain (rear side) assembly—R. H.	1922-23	2	2 00	MH
††4967CRX	Curtain (rear side) assembly—L. H.	1922-23	2	2 00	MH
4967DX	Curtain (rear side) assembly—L. H.	1922-23	2	2 00	MH
6882BX	Curtain (front side) assembly—R. H.	1922-23	2	2 00	MH
6883BX	Curtain (front side) assembly—L. H.	1922-23	2	2 00	MH
††6894BRX	Deck (top) assembly.....	1922-23	2	6 50	MH
6894CX	Deck (top) assembly.....	1922-23	2	6 50	MH
**6903X	Eyelet (slide curtain rear glove fastener)	1922-23	12	02	
**6904X	Fastener (rear curtain glove)	1922-23	12	02	
**7831BX	Hook (curtain to windshield)	1922-23	12	02	
6815BX	Pad (top slide quarter) assembly.....	1922-23	2	1 00	
**3314BX	Rest (prop) and strap assembly.....	1922-23	6	40	
8975X	Rib (top) center and rear.....	1922-23	2	40	
8973BX	Rib (top) front.....	1922-23	2	40	
8974BX	Rib (top) center ext.....	1922-23	2	40	
**3548X	Screw (front socket fastener)	1922-23	12	doz. 05	
6860CX	Socket (top rib) front—R. H.	1922-23	2	1 00	
6861CX	Socket (top rib) front—L. H.	1922-23	2	1 00	
3882CX	Socket (top rib) center—R. H.	1922-23	2	1 00	
3883CX	Socket (top rib) center—L. H.	1922-23	2	1 00	
††3884CRX	Socket (top rib) rear—R. H.	1922-23	2	1 25	
3884DX	Socket (top rib) rear—R. H.	1922-23	2	1 00	
††3885CRX	Socket (top rib) rear—L. H.	1922-23	2	1 25	
3885DX	Socket (top rib) rear—L. H.	1922-23	2	1 00	
6862CX	Socket (top rib) center ext.—R. H.	1922-23	2	1 00	
6863CX	Socket (top rib) center ext.—L. H.	1922-23	2	1 00	

\*Not Subject to Regular Discount

†Quantity price \$0.50 per hundred.

\*\*Also used on 1922 Roadster Top.

††Used on tops with straight side quarters.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents the excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	List Price Each	Tax Status
<b>TOURING CAR TOPS—1922-23—Continued</b>					
6844BX	Top center strainer	1922-23	4	\$0 40	
6846X	Top quarter strainer	1922-23	4	40	
**3629CX	Strap (stay)	1922-23	4	20	MH
**6901X	Stud (rear curtain glove fastener)	1922-23	12	02	
3551X	Center support on rear socket	1922-23	6	05	
3564X	Center ext. support—on center socket	1922-23	6	05	
3572X	Center ext. to brace support	1922-23	6	05	
7940BX	Top assembly	1922-23		†27 00	MH
**4981BX	Visor (top) assembly	1922-23	2	75	
**6905X	Washer (side curtain rear glove fastener)	1922-23	12	02	
<b>TORPEDO TOP PARTS—1915-22</b>					
7941ARX	Torpedo top complete	1915-22		†22 00	MH
4971X	Torpedo top—second and third wood bows	1914-18	2	50	
6929X	Torpedo top—first bow	1915-18	2	50	
8772X	Rib—upright	1918-22	2	40	
8988X	Rib—front extension	1918-22	2	40	
8989X	Rib—rear extension	1918-22	2	40	
6870AX	Torp. bow socket—upright—(R. H.)	1915-18	2	1 25	
6870BX	Torp. rib socket—upright—(R. H.)	1918-22	2	1 00	
6871AX	Torp. bow socket—upright—(L. H.)	1915-18	2	1 25	
6871BX	Torp. rib socket—upright—(L. H.)	1918-22	2	1 00	
6872AX	Torp. bow socket—front extension—(R. H.)	1915-18	2	1 00	
6872BX	Torp. rib socket—front extension—(R. H.)	1918-22	2	1 00	
6873AX	Torp. bow socket—front extension—(L. H.)	1915-18	2	1 00	
6873BX	Torp. rib socket—front extension—(L. H.)	1918-22	2	1 00	
4907AX	Torp. bow socket—rear extension—(R. H.)	1913-18	2	1 00	
4907BX	Torp. rib socket—rear extension—(R. H.)	1918-22	2	1 00	
4908AX	Torp. bow socket—rear extension—(L. H.)	1913-18	2	1 00	
4908BX	Torp. rib socket—rear extension—(L. H.)	1918-22	2	1 00	
6937AX	Torp. side curtain—rear—(R. H.)	1915-22	2	1 50	MH
6938AX	Torp. side curtain—rear—(L. H.)	1915-22	2	1 50	MH
6935AX	Torp. side curtain—front—(R. H.)	1915-22	2	2 00	MH
6936AX	Torp. side curtain—front—(L. H.)	1915-22	2	2 00	MH
6950AX	Torp. back curtain assembly	1915-22	3	2 50	MH
6965AX	Torp. center deck complete	1915-22	2	4 50	MH
6806AX	Torp. side quarter pad	1914-22	2	60	
3877X	Torp. prop rest with strap	1913-22	6	60	
4955AX	Torp. top visor	1920-22	2	50	
<b>†ROADSTER TOP—1922-23</b>					
6935BX	Curtain (front side) assembly—R. H.	1922-23	2	2 00	MH
6936BX	Curtain (front side) assembly—L. H.	1922-23	2	2 00	MH
6937BX	Curtain (rear side) assembly—R. H.	1922-23	2	1 25	MH
6938BX	Curtain (rear side) assembly—L. H.	1922-23	2	1 25	MH
6950BX	Rear curtain assembly	1923	2	2 50	MH
6965BX	Top deck assembly	1922-23	2	4 00	MH
6806BX	Top side quarter pad assembly	1922-23	2	60	
8988BX	Top rib—front	1922-23	2	40	
8989BX	Top rib—center and rear	1922-23	2	40	
4907CX	Top rib socket, rear—R. H.	1922-23	2	1 00	
4908CX	Top rib socket, rear—L. H.	1922-23	2	1 00	
6872CX	Top rib socket, front	1922-23	2	1 00	
6870CX	Top rib socket, center—R. H.	1922-23	2	1 00	
6871CX	Top rib socket, center—L. H.	1922-23	2	1 00	
7941BX	Top assembly	1922-23	2	†22 00	MH

†Not Subject to Regular Discount

\*\*Also used on 1922 Roadster Top.

†For additional 1922 Roadster top parts see 1922 Touring Car top parts marked with adouble asterisk(\*\*)

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

# Price List of Parts for Model T One Ton Truck

Part No.	Name of Part	Year	LIST PRICE			Tax	Model No.	No. Fac. Req. per Car
			Minimum Whole-sale Quan.	Lots of 10 per lot	Lots of 100 per lot			
<b>REAR AXLE</b>								
1000	Rear axle assembly	1918-23	2		\$110 00	MH	TT	95... 1
1001	Axle housing—right	1918-23	2		15 00	MH	TT	4... 1
1002	Axle housing—left	1918-23	2		15 00	MH	TT	5... 1
1003	Axle housing bolt	1918-23	20		03		TT	52... 13
1003B	Axle housing bolt nut	1918-23	Order 2719					
1004	Axle housing cap	1918-23	6		50	MH	TT	133... 1
1005	Axle housing cap gasket	1918-23	20		\$1 50	02	TT	134... 1
1006	Axle housing cap screw	1918-23	20		05		TT	72... 4
1007	Axle housing cap screw lock wire	1918-23	20		01		TT	140... 1
1008	Axle housing gasket—upper	1918-23	10		02		TT	138... 1
1009	Axle housing gasket—lower	1918-23	10		05		TT	139... 1
1010	Axle brake housing plate—right	1918-23	6		35	MH	TT	147... 1
1011	Axle brake housing plate—left	1918-23	6		35	MH	TT	148... 1
1012	Axle housing drain plug	1918-23	10		05		TT	136... 2
1013	Axle shaft	1918-23	2		4 00	MH	TT	48... 2
1014	Axle shaft cotter	1918-23	24		doz.	05	TT	165... 2
1015	Axle shaft nut	1918-23	20	\$0 90	8 00	10	TT	166... 2
1016	Axle shaft washer	1918-23	20	25	2 00	03	TT	135... 2
1017	Axle shaft dust cap	1918-23	10		03		TT	56... 2
1018	Axle shaft inner ball bear. assy	1918-23	2		5 00		TT	125... 2
1019	Axle shaft outer roller bearing	1918-23	2		1 25		TT	253... 2
1020	Axle shaft outer R. B. sleeve—R.	1918-23	2		35		TT	170... 2
1020B	Axle shaft outer R. B. sleeve—L.	1918-23	2		35		TT	161... 1
1021	Axle shaft bearing felt	1918-23	20	1 35	12 00	15	TT	143... 4
1022	Axle shaft bearing retainer	1918-23	10		05		TT	20... 2
1023	Axle shaft bear. retainer washer	1918-23	20		1 50	02	TT	23... 2
1024	Axle shaft felt retainer assembly	1918-23	10		20		TT	144... 1
1025	Axle shaft felt retainer cup	1918-23	10		03		TT	145... 2
1026	Axle shaft felt retainer plate	1918-23	10		03		TT	146... 2
1027	Diff. gear	1918-23	2		1 15	MH	TT	13... 2
1028	Diff gear case R. or L. half	1918-23	2		2 00	MH	TT	11... 2
1029	Diff gear case bolt	1918-23	Order 1003					
1031	Diff. gear lock ring	1918-23	10		02		TT	118... 2
1032	Diff. pinion	1918-23	2		50	MH	TT	14... 2
1033	Diff. pinion shaft	1918-23	2		20	MH	TT	15... 1
1034	Drive shaft	1918-23	2		7 00	MH	TT	87... 1
1036	D. S. tube assembly	1918-23	2		10 00	MH	TT	153... 1
1037	D. S. tube flange gasket	1918-23	20	15	1 25	02	TT	194... 1
1038	D. S. tube flange screw	1918-23	Order 1006					
1039	D. S. felt	1918-23	10		10		TT	109... 1
1040	D. S. felt container	1918-23	10		03		TT	110... 1
1041	D. S. to worm coupling	1918-19	2		1 00		TT	85A... 1
1041B	D. S. to worm coupling	1920-23	2		70		TT	85B... 1
1042	D. S. to worm coupling pin	1918-23	10		01		TT	86... 2
1043	Worm—7/8 to 1	1918-23	2		6 00	MH	TT	16A... 1
1043B	Worm—5/8 to 1	1918-23	2		6 00	MH	TT	16B... 1
1044	Worm gear—7/8 to 1	1918-23	2		10 00	MH	TT	12A... 1
1044B	Worm gear—5/8 to 1	1918-23	2		10 00	MH	TT	12B... 1
1045	Worm cotter	1918-23	Order 1014					
1046	Worm roller bearing	1918-23	2		90		TT	108... 2
1047	Worm roller bearing retainer	1918-23	10		02		TT	106... 1
1048	Worm roller bearing sleeve	1918-23	2		1 50		TT	107... 2
1049	Worm roller bear. housing screw	1918-23	10		03		TT	101... 2
1050	Worm thrust bearing collar	1918-23	2		90		TT	114... 2
1051	Worm thrust ball and sep. assy.	1918-23	2		75		TT	123... 1
1052	Worm thrust bearing plate	1918-23	2		15		TT	22... 1
1053	Worm thrust bearing retainer	1918-23	2		15		TT	111... 1
1054	Worm thrust bear. retainer nut	1918-23	Order 1015					
1055	Worm thrust bear. retainer pin	1918-23	10		50	01	TT	112... 1
1056	Brake shoe	1918-23	4		1 50	MH	TT	281A... 2
1057	Brake shoe lining, each	1918-23	10		25	MH	TT	58... 4
1058	Brake shoe lining rivet	1918-23	100		doz.	10	TT	68... 40
1059	Brake shoe spring	1918-23	10		05		TT	67... 2
1060	Brake shoe bolt	1918-23	10		10		TT	59... 2
1060B	Brake shoe bolt nut	1918-23	Order 2828					
1061	Brake expander	1918-23	4		40	MH	TT	61... 2
1062	Brake expander lever	1918-23	4		15	MH	TT	62... 2
1064	Brake expander adj. collar	1918-23	4		15		TT	175... 2
1065	Brake expander bushing	1918-23	4		10		TT	173... 2
1066	Brake expander pin	1918-23	4		01		TT	7... 2
1067	Brake expander link	1918-23	10		08	MH	TT	176... 4
1068	Brake expander link pin	1918-23	20		03		TT	177... 8
1069	Brake rod	1918-23	4		30	MH	TT	119... 2
1070	Brake rod support—right	1918-23	6	60	5 00	10	TT	120... 2
1071	Brake support—left	1918-23	6	60	5 00	10	TT	121... 1
1072	Brake rod support bolt	1918-23	10		02		TT	7181... 2
1072B	Brake rod support bolt nut	1918-23	Order 3088E					
1073	Rear radius rod—right	1918-23	2		2 80		TT	152... 1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

Part No.	Name of Part	Year	Minimum		LIST PRICE		Tar	Status	Car
			Whole-sale	Quan.	Lots of 10	Lots of 100			

REAR AXLE—Continued

1073B.	Rear radius rod—left.	1918-23	2					\$2 80.	TT.	158.	1
1074.	Rear radius rod bolt—front.	1918-23	10					10.	TT.	84.	1
1075.	Rear radius rod bolt—rear.	1918-23	10					10.	TT.	83.	4
1075B.	Rear radius rod bolt nut.	1918-23									
1076.	Universal joint bushing.	1918-23	2	Order 2828				50.	TT.	69.	1

SPRINGS

1077.	Rear spring—right or left, each.	1918-23	2					4 00.	MH.	TT.	333.	2
1078.	Spring left No. 1.	1918-23	2					90.	TT.	354.	2	
1079.	Spring leaf No. 2.	1918-23	2					50.	TT.	362.	2	
1080.	Spring leaf No. 3.	1918-23	2					45.	TT.	363.	2	
1081.	Spring leaf No. 4.	1918-23	2					40.	TT.	364.	2	
1082.	Spring leaf No. 5.	1918-23	2					35.	TT.	365.	2	
1083.	Spring leaf No. 6.	1918-23	2					30.	TT.	366.	2	
1084.	Spring leaf No. 7.	1918-23	2					25.	TT.	367.	2	
1085.	Spring leaf No. 8.	1918-23	2					20.	TT.	368.	2	
1086.	Spring leaf No. 9.	1918-23	2					20.	TT.	331.	2	
1087.	Spring bushing.	1918-23	2					20.	TT.	332.	2	
1088.	Spring clip.	1918-23	2					45.	TT.	326.	2	
1089.	Spring clip nut.	1918-23	10					05.	TT.	327.	2	
1091.	Spring clip plate.	1918-23	4					20.	TT.	329.	4	
1092.	Spring tie bolt.	1918-23	4					20.	TT.	330.	2	
1093.	Spring tie bolt nut.	1918-23		Order 1089								
1094.	Spring tie bolt cotter.	1918-23	24					*doz. 05.	TT.	328.	2	
1095.	Spring clamp.	1918-23	4					10.	TT.	375.	2	
1096.	Spring clamp bolt.	1918-23	4					03.	TT.	376.	2	
1096B.	Spring clamp bolt nut.	1918-23		Order 3514								
1097.	Spring perch.	1918-23	2					80.	MH.	TT.	2804.	2
1098.	Spring perch nut.	1918-23		Order 1015								
1099.	Spring perch cotter.	1918-23		Order 1014								
1100.	Spring perch bushing.	1918-23	4					25.	TT.	172.	2	
1101.	Spring perch bushing spacer.	1918-23	10					05.	TT.	169.	4	
1102.	Spring hanger assembly.	1918-23	6					30.	TT.	91.	4	

WHEELS

1105B.	Rear wheel—dem.—Kelsey.	1919-23	2					18 50.	TT.	7698.	2
1105C.	Rear wheel—dem.—Hayes.	1919-23	2					18 50.	TT.	7698B.	2
1105D.	Rear wheel—dem.—less rim and hub—Kelsey.	1919-23	2					9 00.	TT.	2817AR.	2
1105E.	Rear wheel—dem.—less rim and hub—Hayes.	1919-23	2					9 00.	TT.	2817BR.	2
1106C.	Dem. rim only—Hayes.	1919-23	2					3 50.	TT.	8774B.	2
1106D.	Dem. rim only—Kelsey.	1922-23	2					3 50.	TT.	8774C.	2
1106E.	Dem. rim retainer ring—Kelsey.	1922-23	2					45.	TT.	178.	2
1107B.	Clamp and nut assy.—Kelsey.	1919-23	20					15.	TT.	8807.	12
1108B.	Clamp bolt.	1919-23	20					05.	TT.	8832.	12
1109.	Rear wheel complete, less tire.	1918-20	2					17 50.	TT.	99.	2
1109B.	Rear wheel—solid tire design—less hub and tire.	1919-23	2					13 25.	TT.	2816.	2
1110.	Rear wheel com., with solid tire.	1918-20							TT.	7645.	2
1111.	Rear hub.	1918-23	2					2 25.	TT.	40.	2
1112.	Rear hub flange.	1918-23	2					40.	TT.	149.	2
1113.	Rear hub brake drum.	1918-23	2					1 25.	TT.	3.	2
1114.	Rear hub bolt.	1918-23	20	40	3 00			05.	TT.	28.	12
1114B.	Rear hub bolt nut.	1918-23	20		1 50			02.	TT.	29.	12
1116.	Rear hub cap.	1918-23	6					25.	TT.	150.	2
1117.	Rear hub key.	1918-23	10					03.	TT.	26.	2
1118.	Rear hub felt.	1918-23	10	45	4 00			05.	TT.	162.	2

FRAME

1119.	Frame assembly.	1918-23	2					30 00.	MH.	TT.	300.	1
1120.	Side member—right.	1918-23	2					10 00.	TT.	301.	1	
1121.	Side member—left.	1918-23	2					10 00.	TT.	302.	1	
1122.	Front cross member.	1918-23	2					1 00.	TT.	303.	1	
1123.	Rear cross member.	1918-23	2					4 00.	TT.	304.	1	
1124.	Front corner bracket—right.	1918-23	2					15.	TT.	305.	1	
1125.	Front corner bracket—left.	1918-23	2					15.	TT.	306.	1	
1125B.	Front end spacer—right.	1918-23	2					15.	TT.	319.	1	
1125C.	Front end spacer—left.	1918-23	2					15.	TT.	318.	1	
1126.	Rear cross member gusset plate.	1918-23	2					25.	TT.	307.	2	
1127.	Rear cross member reinforce.	1918-23	2					35.	TT.	325.	2	

TRANSMISSION CONTROL

1133.	Speed lever.	1918-23	2					10.	MH.	TT.	862.	1
1134.	Control shaft with speed lever.	1918-23	2					60.	MH.	TT.	1557.	1

\*\$0.25 gross, \$0.75 per thousand.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Motor Company, 20/21 represents the price of the goods and 1/21 represents excise tax.

