

Ford

THE UNIVERSAL CAR,

WHOLESALE

PRICE LIST OF PARTS

MODEL T

Effective January 1, 1925

Ford Motor Company
Detroit, Michigan

Ford Motor Company

FORD FACTORIES AND BRANCHES

Ford Factory, Detroit—*Parent Plant*

Ford Factory, Ford, Ontario, Canada

Ford Factory, Manchester, England

AMERICAN WHOLESALE BRANCHES

Atlanta	Cleveland	Fargo	Los Angeles	Norfolk	St. Louis
Buffalo	Columbus	Houston	Louisville	Oklahoma City	Salt Lake City
Cambridge	Dallas	Indianapolis	Memphis	Omaha	San Francisco
Charlotte	Denver	Jacksonville	Milwaukee	Philadelphia	Seattle
Chicago	Des Moines	Kansas City, Mo.	Minneapolis	Pittsburgh	Washington
Cincinnati	Detroit	Kearny, N. J.	New Orleans	Portland	

Instructions for Ordering Parts

- 1—Order all parts through the Authorized Ford Dealer.
- 2—On parts delivered from Dealers' stocks, regardless as to quantity ordered, the Wholesale Trade is entitled to a discount of 25% from list price. Parts may be obtained f. o. b. the nearest Ford Branch at a discount of 30% from list price, providing the net amount of the order exceeds \$200.00. The above discounts apply to the ten, hundred and thousand lot prices as well as to prices on individual items.
- 3—Always give Catalog Number and Name of each part ordered.
- 4—Specify whether shipments are to be made by freight or express.
- 5—Remittance by Draft or Money Order must accompany all parts orders placed for shipment from the Ford Branch.

Telegraph Code

We list below a brief General Code covering miscellaneous instructions relative to the shipment of parts.

Toperig—Ship to me (us) by express.

Toperkleur—Ship by express to —

Topersteen—Ship to me (us) by freight.

Toper—Ship to me (us) by parcel post.

Topfton—When and how did you ship parts called for in my (our) telegram of —

Topflutch—When and how will you ship parts called for in my (our) telegram of —

Topwasser—When and how will you ship parts called for in my (our) letter of —

WHOLESALE PRICE LIST OF PARTS

FORD MODEL T 1909-1924

EFFECTIVE JANUARY 1, 1925

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
REAR AXLE								
2500	Rear axle assembly	1909-25				\$55 00	MH.	95E. 1
2501	Axle housing—right	1915-25				8 00	MH.	7635D. 1
2502	Axle housing—left	1915-25				8 00	MH.	7636D. 1
2503E	Axle housing bolt	1913-25	\$0 20	\$1 00	\$6 00	03		2854. 7
2503F	Axle housing bolt nut	1909-25	15	1 00	6 00	02		44. 7
2504	Rear axle case gasket	1919-25	15	1 00	8 00	03	MH.	139. 1
2505	Axle shaft	1912-25	14 00			1 50	MH.	2818. 2
2506	Axle shaft washer	1909-25	15	75	5 00	02		39. 1
2507	Axle shaft nut	1909-25	45	3 50	30 00	05		242. 2
2508	Axle shaft R. B.	1909-25	6 00	55 00		75		253. 4
2509	Axle shaft R. B. sleeve—R	1909-25		13 50		15		170. 2
2509B	Axle shaft R. B. sleeve—L	1909-25		13 50		15		161. 2
2510	Axle housing cap	1909-19	25	2 00		05		56A R. 2
2510 1/2	Axle housing cap	1919-25	20	1 80		05		56B. 2
2510A	Axle outer roller bearing steel washer	1909-25	15	1 00	7 50	02		199B. 2
2510B	Axle outer roller bearing felt washer	1909-25	40	3 00	27 50	05		54. 2
2512C	Diff. case—left	1914-25	14 00			1 50	MH.	84. 1
2513C	Diff. case—right	1914-25	8 00			90	MH.	81. 1
2514B	Diff. case stud	1915-21	35	3 00		05		52BR. 3
2514C	Diff. case bolt	1922-25	35	3 00		05		52C. 3
2515	Diff. case stud nut	1909-25	20	1 50	10 00	03		8. 3
2518	Diff. drive gear	1909-25	24 00			2 50	MH.	12B. 1
2519	Diff. drive gear screw	1909-25	25	2 00	15 00	03		103. 10
2519A	Diff. gear lock ring	1909-25	15	1 00		02		118. 2
2520B	Diff. gear	1909-25	9 50			1 00	MH.	13B. 2
2521B	Diff. gear key	1911-25	40	3 50	30 00	05		137. 2
2524C	Diff. pinion	1915-25				35	MH.	14D. 3
2526B	Diff. spider	1909-25				75	MH.	15D. 1
2528	Diff. thrust washer	1909-25				15		30. 2
2529	Diff. thrust plate	1909-25	1 25	10 00		15	MH.	31. 4
2530	Diff. thrust plate pin	1909-16		1 50		03		17. 4
2531	Diff. thrust plate pin	1909-16		1 00		03		37. 2
2531B	Diff. thrust plate pin	1917-25	10		5 00	02		7640. 6
2532	Diff. housing oil plug	1909-25		3 50		05		817. 1
2545	Rear axle grease cup	1909-25	60	5 00		10		76A2. 1
2547	Rear radius rod—right	1909-25	10 00			1 25	MH.	152. 1
2547B	Rear radius rod—left	1909-25	10 00			1 25	MH.	158. 1
2548	Radius rod nut	1909-25	40	3 00	25 00	05		77. 2
2549	Radius rod lock nut	1909-25	40	3 00	20 00	05		78. 2
2550	Radius rod lock washer	1909-25	15	1 00	7 50	02		2823. 2
2551	Radius rod bolt	1909-25	35	3 00	25 00	05		83. 4
2551B	Radius rod bolt nut	1909-25		2 50	20 00	03		60. 4
2557	Hub cam shaft—right	1909-25		7 50		10	MH.	92B. 1
2558	Hub cam shaft—left	1909-25		7 50		10	MH.	61B. 1
2559	Hub cam shaft bushing	1909-25	35	2 50		05		173. 2
2562	Cam shaft lever	1909-25				10	MH.	62. 2
2563	Cam shaft lever pin	1909-25	10	50	2 50	02		7. 4
2564	Lever clevis pin	1909-25	15	1 00		02		65. 4
2566	Hub brake shoe	1909-25		30 00		35	MH.	2814. 2
2567	Brake shoe support bolt	1909-25		3 00	25 00	05		59. 2
2568	Brake shoe support nut	1909-25						
2570B	Brake shoe coil spring	1913-25	20	1 50	10 00	03		2862. 4
Order 2551B								
UNIVERSAL JOINT								
2571	Universal joint assembly	1909-25	14 00			1 50		151B. 1
2572	Joint knuckle (male)	1909-25				50		45B. 1
2573	Joint knuckle (female)	1909-25				60		46B. 1
2574	Joint knuckle pin	1909-25		75	5 00	02		6. 1
2575	Joint ring, complete	1909-25	4 00			50		49B. 1
2576	Joint ring rivets	1909-25	10	50		05 (per set 4)		50. 4
2577B	Univ. joint housing	1914-25				1 00		7609. 1
2578	Joint housing plug	1909-25	30	2 00		05		75. 2
2579	Ball joint grease cup	1909-25	1 20	10 00		15		195. 1
2580	Ball cap gasket	1909-25	30	2 50	20 00	05	MH.	1518. 1
DRIVE SHAFT								
2581	Drive shaft housing front bushing	1909-25				30		69. 1
2582	D. S. tubing	1911-25				7 00	MH.	153B. 1
†2583B	D. S. bearing housing	1920-25				1 40	MH.	191C. 1
2584B	D. S. R. B. cap screw	1912-25	40	3 00	25 00	05		183B. 6
2584C	D. S. R. B. stud nut	1912-21	25	2 00		03		184R. 6

†When ordered to replace malleable type housing also order 2-2591 and 1-2591B.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot	Each			

REAR AXLE—Continued

DRIVE SHAFT—Continued

2584D.	D. S. R. B. cap screw lock washer	1912-25		\$0 30		doz.	\$0 05	157	6	
2586	D. S. R. B. housing set screw	1911-21	\$0 45	4 00			05	101R	1	
2587	D. S. roller bearing	1911-25	6 00				75	108	1	
2588	D. S. R. B. distance plate	1911-21		15	1 00		05	MH	106R	1
2589	D. S. ball race	1911-21					25	186R	1	
2589B.	D. S. ball bearing assy.	1911-21					90	185AR	1	
2590	D. S. ball retainer	1911-21		20	1 25		03	190AR	1	
2591	D. S. ball thrust collar	1911-25		1 70	15 00		20	188	2	
2591B.	D. S. thrust ball and retainer assembly	1920-25		1 50	14 00		20	162	1	
2592	D. S. ball bearing	1911-21					1 50	107R	1	
2593	D. S. R. B. sleeve	1911-21					3 00	MH	87D	1
2595B.	D. S. only	1911-25					50	163B	1	
2596	D. S. sleeve	1911-25		4 00			1 25	MH	16C	1
2597B.	D. S. pinion	1911-25		10 00			1 25	MH	16D	1
2597C.	D. S. pinion	1911-25		10 00			08	124	1	
2598	D. S. castle nut	1911-25		70	6 00		05	57B	1	
2598B.	D. S. pinion key	1911-25		40	3 00	\$27 50				

REAR AXLE—60 INCH TREAD

2600C.	Rear axle housing—right	1915-16					12 00	MH	2728C	1
2601C.	Rear axle housing—left	1915-16					12 00	MH	2729C	1
2602B.	Rear axle shaft—tapered	1911-16					3 00	MH	2725	2
2604	Rear radius rod	1909-16					2 00		1726	2

FRONT AXLE

2691	Front axle only	1909-25					9 00	MH	202B	1
2694B.	Spindle body—right	1911-25		14 00			1 50	MH	280	1
2695B.	Spindle body—left	1911-25		14 00			1 50	MH	281	1
2696	Spindle arm—right or lf.	1911-19					50	MH	7716	2
2696C.	Spindle arm—right	1919-25					45	MH	7715B	1
2696D.	Spindle arm—left	1919-25					45	MH	7716B	1
2697	Spindle arm nut	1911-25								
2704	Stationary cone	1909-25					15		205A	2
2705	Adj. cone—right thread	1909-25					15		206A	1
2706	Adj. cone—left thread	1909-25					15		207A	1
2707	Spindle nut—right thread	1909-25					05		209B	1
2708	Spindle nut—left thread	1909-25					05		208B	1
2709	Spindle washer	1909-25		15	1 00	6 00	02		210	2
2710	Spindle bolt with oiler	1910-25		1 60	15 00		20		7708	2
2711	Spindle bolt nut	1909-25								
2713	Spindle body bush. (pair)	1909-25		1 80	17 00	150 00	20		223	2
2714	Spindle arm bushing	1909-25		15	1 25	9 00	05		225	2
2715D.	Spindle oiler	1919-25								
2717	Spindle con. rod	1909-25		12 50			1 75	MH	264	1
2718	Spindle con. rod bolt with oiler	1909-25		1 20	10 00		15		7706	1
2719	Spindle con. rod bolt nut	1909-25			2 00	15 00	03		220	2
2721B.	Spindle con rod yoke ball	1919-25		1 50			20	MH	226B	1
2721C.	Spindle con. rod yoke	1919-25		3 50			40	MH	248B	1
2725B.	Steering gear con. rod	1909-25		6 00			80	MH	289	1
2728	Ball socket cap	1909-25		1 20	10 00		15		254B	2
2729B.	Ball socket bolt and nut	1909-25								
*2733B.	Front radius rod	1919-25		14 00			1 50	MH	263B	1
2736	Front radius rod ball cap	1909-25		1 20	10 00		15		217	1
2737	Front radius rod ball socket	1911-25					20		809B	15
2737B.	Front radius rod ball socket	1924-25					20		809C	
2741	Radius rod ball cap stud	1911-25		30	2 00	19 00	05		4365	2
2741B.	Radius rod ball cap stud nut	1911-25								
2741C.	Front radius rod ball cap bolt	1924					05		251	2
2742	Radius rod ball cap spr g	1911-25		20	1 25	8 00	03		292	2
2760	Front axle only—60"	1911-16					10 00	MH	1720B	1
2761	Spindle con. rod—60"	1909-16					3 00	MH	1725	1
2762	Steer. gear con. rod—60"	1909-16					1 25	MH	2739	1

WHEELS

WHEELS (Clincher)

2800	Front wheel—clincher	1909-25					6 00	MH	291B	2
2800D.	Front wheel—clincher—less hub	1909-25					4 00	MH	295AR	2
2814C.	Rear wheel—clincher	1912-25					6 50	MH	2815	2
2814D.	Rear wheel—clincher—less hub	1909-25					4 25	MH	2816	2

* Substitute 2733B, with spring perches, for 2733

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car	
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
WHEELS—Continued									
WHEELS (Demountable)									
2800B.	Front wheel—dem. less rim and brgs.—Kelsey	1919-24	\$ 55 00.			\$6 00.	MH.	291D.	2
2800C.	Front wheel—dem. less rim and brgs.—Hayes	1919-24	55 00.			6 00.	MH.	291E.	2
2800G.	Front wheel—dem.—less rim and brgs.—Ford.	1919-25	55 00.			6 00.	MH.	291G.	2
2800E.	F. and rear wheel—dem. less rim & hub—Kelsey	1919-24	35 00.			3 80.	MH.	293AR.	4
2800II.	Frt. and rear wheel—dem. less rim & hub—Ford.	1919-25	35 00.			3 80.	MH.	293CR.	4
2801.	Front wheel complete R. or L.—dem.—Kelsey	1919-25	72 50.			8 00.	MH.	7697A.	2
2801B.	Front wheel complete R. or L.—dem.—Hayes	1919-25	72 50.			8 00.	MH.	7697B.	2
2801C.	Front wheel complete R. or L.—dem.—Ford.	1919-25	72 50.			8 00.	MH.	7697C.	2
2814E.	Rear wheel complete—dem.—Kelsey	1919-24	72 50.			7 75.	MH.	7698A.	2
2814F.	Rear wheel complete—dem.—Hayes	1919-24	72 50.			7 75.	MH.	7698B.	2
2814J.	Rear wheel—complete—dem.—Ford.	1919-25	72 50.			7 75.	MH.	7698C.	2
2814G.	Rear wheel—dem. less rim—Kelsey	1919-24	55 00.			5 75.	MH.	2815B.	2
2814K.	Rear wheel—dem.—less rim—Ford.	1919-25	55 00.			5 75.	MH.	2815E.	2
HUBS AND PARTS									
2803.	Front hub assy.	1909-25				1 60.	MH.	200.	2
2803B.	Front hub with R B cups.	1909-25	16 00.			1 80.	MH.	219.	2
2804.	Outer race.	1909-25		\$ 7 50.		10.		234.	2
2805.	Inner race.	1909-25		11 00.		15.		235.	2
2806.	Outer ball retainer.	1909-25	15	1 00.		02.		236.	2
2807.	Inner ball retainer.	1909-25	20	1 25.		03.		237.	2
2808.	Dust ring.	1909-25	25	1 50.		03.		238.	2
2809.	Front & rear hub felt washer	1909-25	45	3 50	\$30 00	05.		239.	4
2810.	Large balls.	1909-25		3 00	25 00	04.		241.	24
2811.	Small balls.	1909-25		1 50	13 50	03.		249.	22
2815C.	REAR HUB.	1912-25				1 25.	MH.	2819.	2
2816B.	Rear hub key.	1912-25	20	1 50	12 00	03.		2863.	2
2818.	Rear hub brake drum.	1909-25	3 50			40.	MH.	3B.	2
2819.	Hub cap.	1909-25	1 30	12 00.		15.		7727.	4
2825.	Rear hub bolt.	1911-25	20	1 50	8 00	03.		28B.	12
2825B.	Hub bolt nut.	1911-25	15	1 00	6 00	03.		29.	24
2826.	Front hub bolt.	1911-25	20	1 50	8 00	03.		27.	12
2827.	Hub flange.	1911-25	1 75.			20.	MH.	233B.	4
2833.	Front hub bear. cup inner	1919-25	4 00.	35 00.		50.		2955.	2
2834.	Inside cone and rollersassy	1919-25	10 00.	95 00.		1 10.		205B.	2
2836.	Front hub bearing cup—outer	1919-25	3 50.	32 50.		40.		2956.	2
2837.	Outside cone and roller assy.—right thread.	1919-25	6 50.			75.		206B.	1
2838.	Outside cone and roller assy.—left thread.	1919-25	6 50.			75.		207B.	1
2841.	Front hub dust cap assy.	1919-25	80.	7 00	60 00	10.		350.	2
RIM AND RIM CARRIER									
2845.	Demountable rim only—Kelsey	1919-24	13 50.			1 50.	MH.	8774A.	4
2845B.	Demountable rim only—Hayes	1919-24	13 50.			1 50.	MH.	8774B.	4
2845C.	Demountable rim only—Ford.	1922-25	13 50.			1 50.	MH.	8774C.	4
2846B.	Demountable rim clamp—Kelsey	1919-24	50	4 25	32 50	0 10.	MH.	8831B.	16
2846C.	Dem. rim clamp and nut assy.—Ford.	1922-23	1 30.	12 00.		15.	MH.	8807.	16
2847.	Demountable rim bolt.	1919-25	35	2 50.	23 00	05.		8832A.	16
2848.	Dem. rim nut—Hayes.	1919-24	35	2 50.	23 00	05.		8834B.	16
2848B.	Dem. rim nut—Kelsey & Ford.	1919-25	35	2 50	23 00	05.		8834A.	16
2849.	Spare rim carrier.	1919-25				2 25.	MH.	8848C.	1
2849B.	Spare rim carrier clamp bolt.	1921-25				02.		7509B.	1
2849C.	Spare rim carrier clamp support and bolt assy.	1921-25		10 00.		15.	MH.	7511.	1
2849D.	Spare rim carrier clamp.	1921-25		7 50.		10.		7312C.	1
2870.	Spare rim carrier brkt—R	1919-22				50.		8824AR.	1
2870B.	Spare rim carrier brkt—R	1922-25				50.		8824B.	1
2871.	Spare rim carrier brkt—L	1919-22				50.		8825AR.	1
2871B.	Spare rim carrier brkt—L	1922-25				50.		8825B.	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	Minimum Whole- sale Quan.	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
				Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
FRAME										
2850	Frame assembly	1909-25					\$13 00	MH	2916	1
2851B	Side member—right	1914-25					4 00		2914	1
2852B	Side member—left	1914-25					4 00		2915	1
2853	Front cross member	1909-25		\$8 00	\$70 00		1 20		303	1
2854B	Rear cross member	1914-25					1 20		2913	1
2855	Front corner bracket—R	1909-25					15		305	1
2856	Front corner bracket—L	1909-25					15		306	1
2857	Rear corner bracket—R	1909-25					15		307	1
2858	Rear corner bracket—L	1909-25					15		308	1
2859	Front end spacer—L	1909-25					10		318B	1
2860	Front end spacer—R	1909-25					10		319B	1
2863	Body bracket	1909-25					10		344	4

GASOLINE TANK

2900B	Gas tank—Sedan	1916-25					6 00	MH	7950	1
2900C	Gasoline tank	1909-25		35 00			4 00	MH	1303B	1
2901	Filling plug	1909-25		90	7 50	\$60 00	10	MH	1317	1
2902B	Sediment bulb	1909-25					90		2088	1
2908	Pet cock	1909-25								
Order 3079										
2909	Feed pipe—40 3/4"	1909-25		2 00			25	MH	1364	1
2909B	Feed pipe—51 3/4"	1916-25		2 50			30	MH	7965	1
2909C	Feed pipe—66 1/2"	1918-19					35	MH	9775R	1
2909D	Feed pipe—56 1/4"	1919-25		2 75			35	MH	8690	1
2910	Feed pipe pack nut	1909-25		45	3 00		65		1374	2
2911	Feed pipe—78"	1915					00	MH	1394R	1
2913	Feed pipe gasket	1909-25			1 00		02	MH	5892	1
2914	Gas tank support—R	1917-20		1 75			20		2132	1
2914B	Gas tank support—R	1920-25		1 75			20		2132B	1
2915	Gas tank support—L	1917-20		1 75			20		2133	1
2915B	Gas tank support—L	1920-25		1 75			20		2133B	1
2916	Feed pipe clamp	1921-25			75		01		2118	1

MOTOR

CYLINDER

*2990B	Motor assy—less starter	1909-25					*110 00	MH	532C	1
2991B	Cyl. assy—std.	1909-25					65 00	MH	449	1
3000C	Cylinder	1909-25	2				25 00	MH	400D	1
3001	Cylinder head	1909-25					6 00	MH	401C	1
3002	Cyl. head gasket	1909-25		2 70	25 00		30	MH	402B	1
3003	Cyl. head cap screw	1909-17		35	2 50		05		483B	15
3003B	Cyl. head cap screw	1918-25		35	2 00	16 00	05		483C	1
3004	Cyl. head outlet con.	1909-16					35	MH	446C	1
3004B	Cyl. head outlet con.	1917-25					30	MH	8719	1
3005	Cyl. head out. con gasket	1909-25		25	1 50		05	MH	445B	1
3006	Cyl. head outlet hose	1909-25		1 35	12 50		15	MH	448B	1
3007	Cyl. head outlet hose clip	1909-25		40	3 00		05		607B	2
3008	Cyl. head out. con. screw	1909-25		25	2 00	12 50	05		550C	2
3009B	Cyl. front cover	1909-19					1 00	MH	690B	1
3009C	Cyl. front cover	1919-25		8 50			1 00	MH	690C	1
3010	Cyl. cover bolt and nut	1909-25								
3011	Cyl. cover cap screw	1909-25		20	1 50	10 00	03		432	3
3012	Cyl. cover felt	1909-25		40	2 50	20 00	05		504	1
3013	Cyl. cover liner	1909-19		15	1 00	7 50	02		505B	1
3013B	Cyl. cover liner	1919-25		15	75	6 00	02		505C	1
3014	Cyl. cover and crank case bolt and nut	1909-25								
3015	Cyl. water inlet con.	1909-25					30	MH	442B	1
3016	Cyl. inlet con. screw	1909-25		25	2 00	17 50	03		597	2
3017	Time gear cover	1919-25					90	MH	1754B	1
13017B	Time gear cover	1919-21					90	MH	1754AR	1
3017C	Time gear cover gasket	1919-25			60	4 00	01		1775	1
3017D	Time gear cover plate	1919-25		40			05	MH	1773	1
3018	Cyl. water inlet gasket	1909-25		20	1 50		03	MH	596	1
3019B	Cyl. water jacket plug	1914-25		10	50		02		5919	3
Order 4808 and 2515										
Order 3362 and 2515										

PISTON AND CONNECTING ROD

3021	Piston only	1909-24		9 50			1 00	MH	418CR	4
3021B	Piston only—.0025" O. S.	1909-24		9 50			1 00	MH	418DR	4
3021C	Piston only—.03125" O. S.	1909-24		9 50			1 00	MH	418ER	4
3021D	Piston only—.033" O. S.	1909-24		9 50			1 00	MH	418FR	4
3021E	Piston only—.005" O. S.	1909-24		9 50			1 00	MH	418GR	4
3021F	Piston and pin	1909-24		12 50			1 30	MH	4473C	4
3021G	Piston and pin—.0025" O. S.	1909-24		12 50			1 30	MH	4473DR	4
3021H	Piston and pin—.03125" O. S.	1909-24		12 50			1 30	MH	4473ER	4
3021J	Piston and pin—.033" O. S.	1909-24		12 50			1 30	MH	4473FR	4

*Not subject to regular discount.

Used with 3000C cylinder on cars not equipped with starter.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
MOTOR—Continued								
PISTON AND CONNECTING ROD—Continued								
3021K...	Piston and pin—.005" O. S.	1909-24	\$12 50			\$1 30	MH 4473G R.	4
3021L...	Piston only	1909-25	9 50			1 00	MH 418H	4
3021M...	Piston only—.0025" O. S.	1909-25	9 50			1 00	MH 418IR	4
3021N...	Piston only—.005" O. S.	1909-25	9 50			1 00	MH 418JR	4
3021P...	Piston only—.03125" O. S.	1909-25	9 50			1 00	MH 418KR	4
3021Q...	Piston only—.033" O. S.	1909-25	9 50			1 00	MH 418LR	4
3021R...	Piston and pin	1909-25	12 50			1 30	MH 4473H	4
3021S...	Piston and pin—.0025" O. S.	1909-25	12 50			1 30	MH 4473IR	4
3021T...	Piston and pin—.005" O. S.	1909-25	12 50			1 30	MH 4473JR	4
3021U...	Piston and pin—.03125" O. S.	1909-25	12 50			1 30	MH 4473KR	4
3021V...	Piston and pin—.033" O. S.	1909-25	12 50			1 30	MH 4473LR	4
3021W...	Piston and pin—.010" O. S.	1909-25	12 50			1 30	MH 4473MR	4
3022...	Piston pin	1909-25				30	419B	4
3022½...	Piston pin bushing (pair)	1909-23		\$17 50		20	668AR	4
3022C...	Piston pin bushing (pair)	1923-25		17 50		20	668B	4
3023...	Piston ring	1909-25	1 35	12 00		15	422C	12
3023B...	Piston ring 031" O. S.	1909-25	1 35	12 00		15	422ER	12
3023C...	Piston ring 010" O. S.	1909-25	1 35	12 00		15	422DR	12
3023D...	Piston ring 038" O. S.	1909-25	1 35	12 00		15	422FR	12
3024...	CONNECTING ROD	1909-25	11*00			1 20	MH 641B	4
3024B...	Connecting rod	1909-25	11 00			1 20	MH 641AR	4
3025...	Con. rod cap bolt	1909-25	40	3 00	\$20 00	05	489B	8
3026...	Con. rod cap bolt nut	1909-25	30	1 50	12 00	05	490	8
3029...	Con. rod clamp screw	1909-25	25	2 00		03	578	8
CRANK SHAFT AND CAM SHAFT								
3030...	CRANK SHAFT	1909-25				8 00	MH 498B	1
3031...	C. S. rear bearing cap	1909-25	4 50			50	405AR	1
3031B...	C. S. rear bearing cap	1909-25	4 50			50	405AR	1
3032...	C. S. front bearing cap	1909-25	3 50			40	406B	1
3032B...	C. S. front bearing cap	1909-25	3 50			40	406B	1
3033...	C. S. center bearing cap	1909-25	3 50			40	407B	1
3033B...	C. S. center bearing cap	1909-25	3 50			40	407B	1
3034...	C. S. bearing bolt—center and front	1909-25	90	7 50		10	408	4
3035...	C. S. bearing bolt nut	1909-25						
3036...	C. S. rear bearing bolt	1909-25	90	7 50		10	478	2
3038...	C. S. bearing liner—center and front	1909-25		40	2 00	01	502B	8
3039...	C. S. rear bearing liner	1909-25		40	2 00	01	503B	1
3040...	C. S. starting pin	1909-20	30	2 00		05	529B	1
3040B...	C. S. starting pin	1920-25	30	2 00		05	529C	1
3041...	CAM SHAFT	1909-25	22 50			2 50	MH 410	1
3042...	Cam shaft front bearing	1909-24				40	411AR	1
3042B...	Cam shaft front bearing	1924-25				40	411B	1
3043...	Cam shaft center bearing	1909-25				40	412B	1
3044...	Cam shaft rear bearing	1909-25				15	413	1
3045...	Cam shaft bearing ring	1909-25	15	1 00	7 50	03	534	2
3046...	Camshaft bear'g set screw	1909-25	35	3 00	25 00	05	414	2
3047B...	Time gear—large	1909-25	7 50			90	MH 415B	1
3048B...	Time gear—small	1909-25	5 00			60	MH 416B	1
3049...	Cam shaft gear dowel pin	1909-25	15	1 25		02	417	2
3050B...	Cam shaft gear lock nut	1909-25	80	7 50		10	4453	1
3051...	Small time gear key	1909-25	25	1 50	12 00	03	477	1
VALVES, PUSH RODS, EXHAUST AND INLET MANIFOLDS								
3052...	Valve	1909-25		12 00		15	MH 424B	8
3052B...	Valve—.4" O. S. stem	1909-25		12 00		15	MH 424AR	8
3053½...	Valve bushing	1909-25				25	428	8
3054...	Valve spring	1909-25		3 50	30 00	05	Set 431	8
3056...	Valve spring seat	1909-25		50	4 00	05	425	8
3057...	Valve spring seat pin	1909-25		25	2 00	05	of 8 429	8
3058...	Push rod	1909-25	90	7 00		10	MH 426B	8
3058B...	Push rod—.4" O. S. stem	1909-25	90			10	MH 426AR	8
3059½...	Push rod bushing	1909-25				25	427	8
3060B...	Exhaust manifold	1913-25				1 25	MH 4483	1
3061...	Exhaust pipe pack nut	1909-25		18 00		20	518	1
3062...	Inlet pipe	1909-25				1 00	MH 512B	1

†Used with 3000C cylinder on cars not equipped with starter.

††Connecting rods requiring new bearings will be exchanged by dealers at 60c each.

**Special rod for crankshafts worn .025" undersize.

*O. D. .934"

††O. D. .872"

‡Light type piston.

‡Rough babbitted.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10	Lots of 100	Lots of 1000				

MOTOR—Continued

VALVES, PUSH RODS, EXHAUST AND INLET MANIFOLDS—Continued

3063	Inlet and exh. pipe gasket	1909-25	\$ 15	\$1 20	\$8 00		\$ 02	MH	513	6
3064	Inlet and exh. pipe gland	1909-25		75	6 00		01		514	6
3065	Inlet and exh. pipe clamp	1909-25					10	MH	515	4
3066	Inlet and exh. clamp stud	1909-25	30	2 50			05		516	4
3066B	Inlet and exh. clamp stud nut	1909-25	20	1 25	7 50		03		517	4
3068	Breather pipe	1909-25	80	6 00			10	MH	4468	1

CRANK CASE AND CYLINDER VALVE COVER

3069B	C. C. front end support	1911-17				1 00			801C	1	
3069C	C. C. front end support	1917-25	6 00			75			801D	1	
3070B	C. C. & cyl. gasket—L	1909-25	30	2 50			05	MH	886	1	
3071B	C. C. & cyl. gasket—R	1909-25	30	2 50			05	MH	887	1	
3072	C. C. & cyl. cover cap screw	1909-25	25	1 50	10 00		03		1388	2	
3073	C. C. arm bolt—side	1909-25	30	2 25	20 00		05		479	2	
3074	C. C. arm bolt—top	1909-25	20	1 75	15 00		05		940	2	
3074B	C. C. arm bolt nut	1909-25									
3075B	C. C. frt. bearing & spring clip assy	1921-25				80			2921B	1	
3076B	C. C. front bearing and spring clip	1921-25				60			320C	1	
3076C	C. C. front bearing and spring clip nut	1921-25									
3077	C. C. front bearing cap	1909-25	80	7 00		10			321	1	
3078	C. C. front bearing screw	1909-21	35	3 00		05			322	2	
3078B	C. C. front bearing screw	1921-25									
3078C	C. C. front bearing lock washer	1921-25		50	3 50	01			5636	2	
3079	C. C. oil cock	1909-25		12 00		15			1515	2	
3080	C. C. drain cup plug	1909-25									
3080B	C. C. drain cup plug gasket	1909-25		1 50	10 00	02	MH		4339	1	
3081	C. C. oil tube	1909-25	1 50			20	MH		543B	1	
3083	C. C. arm block	1909-25				05			890	2	
3084	Engine pan—right	1909-25	2 50			30	MH		1330	1	
3085	Engine pan—left	1909-25	2 50			30	MH		1331B	1	
3088B	Engine pan and hood board bolt	1909-25	20	1 50	10 00	03			4074	2	
3088C	Engine pan and hood board bolt	1909-25	20	1 50	10 00	03			4073	2	
3088D	Engine pan and hood board bolt—Truck	1918-25	20	1 50		03			TT4073	2	
3088E	Engine pan and hood board bolt nut	1909-25		75	5 00	01			1309		
3100	CRANK CASE	1912-25				1 00			MH	1526E	1
3101	Crank case lower cover	1912-24				05			MH	1584	1
3101B	Crank case lower cover reinforcement	1912-24				25	MH		4378-4379	1	
3101C	C. C. lower cover	1924-25				35	MH		1582B	1	
3101D	C. C. lower cover reinforcement	1924-25				25	MH		4378B-		
3102B	C. C. lower cover gasket	1912-24	70	6 00		10			4379B	1	
3102C	C. C. lower cover gasket	1924-25				10	MH		1586B	1	
3103	C. C. lower cover screw	1912-25	15	1 00	6 00	02			4328	41	
3110	Cylinder valve cover	1912-21				15	MH		656A	2	
3110B	Cylinder valve cover	1921-25	1 75	15 00		20	MH		656B	2	
3111B	Cyl. valve cover gasket	1912-21	30	2 50	320 00	05	MH		660A	1	
3111C	Cyl. valve cover gasket	1921-25	60	4 50	40 00	10	MH		660B	2	
3112	Cyl. valve cover screw	1912-25		2 00		03			654	1	
3114	C. C. arm with rivets	1909-25				30			815B	2	
3115	C. C. arm rivet	1909-25				05		doz.	312		

COMMUTATOR

3162	Com. case support bolt	1912-19				05			4441	1
3162B	Com. case support bolt	1919-25				05			1756	1
3163	Com. case spring	1912-25				05			689	1
3165	Com. brush only	1912-25	1 75	15 00		20			4431	1
3176C	Com. oiler	1919-25	40	2 50		05			480C	1
3177	Com. felt ring	1912-25	15	75		02			5930	1
3206	Com. brush cap	1909-25	15	1 00		02			468B	1
3207	Com. brush cap pin	1909-25				01			466	1
3210	Com. contact point nut	1910-25		50		01			472B	1
3220	Com. lock nut	1909-25	25	2 00		03			471	1
3221	Com. case with fibre	1912-25		55 00		60			5908	1
3223	Com. shield	1912-25		1 25		02			5923	1

†When ordered to replace old style C. C. front frame bearing also order 2-3008, 2-3076C, 2-3078C, 1-3664 1-3810 and 2-753 cotter.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
MAGNETO AND FLY WHEEL									
3250D.	Magneto coil assembly	1915-25				\$ 6 00		5941B	1
3252	Magneto spool support screw	1909-25							
3254	Magnet bolt.	1909-25	Order 3371	\$0 25	\$0 2 00	\$15 00	03	537B.	16
3255	Magnet bolt washer	1911-25			50		01	624	16
3257	Magnet support	1909-25		30	2 00		05	535C.	16
3260	Magneto contact assy	1909-25		1 50	13 50		20	MH	1545
3261B	Magneto contact nut	1909-25			50		01	1508	2
3261C	Magneto contact screw washer	1909-25			50		01	1565	
3262	Magneto contact spring	1909-25		30	2 00		05	1509	1
3262B	Magneto contact screw and spring assembly	1919-25			7 50		10	4350	
3266	Magneto contact fibre screw	1909-25			50		01	1505	3
3267	Magneto primary insulating block	1915-25					03	4382	
3267B	Magneto contact insulator	1919-25			3 00		05	1503B.	
3267C	Magneto contact insulator shell	1919-25					03	8611	
3268	Fly wheel ring gear	1919-25		8 00			90	MH	1885
3269C	Fly wheel	1911-19					6 00	MH	701B.
3269G	Fly wheel	1919-25					5 00	MH	701C.
3269H	Fly wheel with ring gear and magnets assembled	1919-25					15 00	MH	5946B.
3270	Fly wheel cap screw	1909-25		80	7 00		10	721	4
3271	Fly wheel dowel pin	1909-25		40	3 00		05	722	2
3272	Magneto coil support shim	1909-24		40	3 00		05	584AR.	1
3272B	Mag. coil support steel shim — small (.025" thick)	1909-25			75		01	584B	4
3273	Mag. coil support steel shim — small (.015" thick)	1909-25			75		01	590	
3274	Mag. coil support paper shim—large	1909-25			50		01	589	
3275	Mag. coil support paper shim—small	1909-25			25		01	4487	
3276B	Magnet (16)	1915-25				set	4 00	5933	16
3277	Magnet clamp	1911-25		25	1 60		03	623	16
3278	Magnet clamp screw	1911-25			1 50	14 00	02	625	16
3279	Magneto contact washer	1909-25			75		01	560	1
TRANSMISSION									
3300B.	Transmission assy	1919-25				30 00	MH	744C.	
3301	Trans. reverse plate assy.	1909-25				2 40	MH	747	1
3304	Trans. reverse gear bushing	1909-25				40		705	1
3305	Trans. rev. and S. S. rivet	1909-25				doz. 05		708	8
3306	Trans. slow speed plate assy	1909-25				2 30	MH	748	1
3309	Trans. slow speed gear bushing	1909-25				30		745	1
3310	Trans. brake drum rivet	1909-25				doz. 05		711	8
3311	Trans. brake drum assy.	1909-25				2 40	MH	750	1
3313	Trans. triple gear assy.	1909-25				1 40	MH	751B	3
3314 1/2	Trans. triple gear flanged bushing	1911-25		1 80			20	716B.	3
3315	Trans. triple gear shaft	1909-25				15	MH	715AR	3
3316	Trans. triple gear riveting pin	1909-25				doz. 05		720	24
3317	Trans. driven gear	1909-25				70	MH	713	1
3318	Trans. driven gear key	1909-25			2 50		03	714	2
3320C	Trans. driven gear sleeve bushing	1909-25		1 50			20	712	2
3320D	Driven gear sleeve washer	1909-25		40	3 50		05	776	3
3321	Trans. driving plate assy	1909-25				3 25	MH	749	1
3323	Trans. driving plate screw	1909-25							
3325	Trans. driving plate rivet	1909-25	Order 3371				doz. 05	736	8
3327B	Trans. driving plate bush	1909-25					15	772	1
3328	Trans. clutch disc—small	1909-25		90	7 50		10	MH	727
3329	Trans. clutch disc—large	1909-25		90	7 50		10	MH	728
3331	Trans. gear shaft	1909-25				1 25	MH	723B.	1
3332	Trans. clutch disc drum	1909-25				1 25	MH	725B.	1
3333	Trans. clutch disc drum key	1909-25			3 50		05	726B.	1
3334	Trans. clutch disc drum set screw	1909-25			4 00		05	752	1
3336	Trans. clutch push ring	1909-25					35	MH	770

††When using short bushing in making repairs remove driving plate key.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
TRANSMISSION—Continued									
3337	Trans. clutch finger	1909-25				\$0 15	MH	732B	3
3337 1/2	Trans. clutch finger screw	1909-25		\$3 00		05		756	
3337B	Trans. clutch finger and screw	1909-25				20	MH	765	3
3338	Trans. clutch finger pin	1909-25				01		735	3
3340	Trans. clutch spring	1909-25				25		737	1
3341	Trans. clutch spring support	1909-25				10	MH	738	1
3342	Trans. clutch spring thrust ring pin	1909-25	\$0 25	1 50		03		739	1
3344	Trans. clutch shift	1909-25				50	MH	733	1

TRANSMISSION COVER

3362	Trans. cover bolt	1909-25		2 00	\$16 00	03		79	
3362B	Trans. cover bolt nut	1909-25	Order 2515						
3363	Trans. cover gasket (front)	1909-25	30	2 50		05	MH	872B	
3367	Trans. cover door screw	1909-25	15	1 00	7 50	02		430	6
3368	Universal ball cap (rear)	1909-25				30	MH	818	1
3369	Universal ball cap (front)	1909-25	7 50			80	MH	819D	1
3371	Universal ball cap screw	1909-25	25	1 75	15 00	03		731	2
3372	Universal ball cap bolt and nut	1909-25	Order 3362 and 2515						
3375	Trans. cover screw	1909-25	Order 3072						
†3376B	TRANS. COVER	1919-25				7 00	MH	826E	1
3377B	Trans. cover gasket	1909-25	80	7 00	pr	10	MH	885B	1
3378	Trans. cover door	1911-25				15	MH	1546D	1
3379B	Trans. cover door gasket	1911-25	40	3 50		05	MH	1547C	1
3380	Starter drive cover	1919-25				15	MH	1763	1
3381	Starter drive cover gasket	1919-25	20	1 50		03	MH	1764	1
3382	Trans. cover rear plate	1919-25	30			05	MH	1761	1
3383	Trans. cover front plate	1919-25	40			05	MH	1758	1

TRANSMISSION CONTROL

CLUTCH RELEASE

3400	Trans. clutch release ring	1909-25				20	MH	741	1
3402D	Clutch lever and shaft	1913-25				30	MH	1548	
3403	Clutch lever screw	1909-25	Order 3973						
3403B	Clutch lever screw nut	1909-25	Order 3066B						
3405	Clutch lever pin	1909-25		60		01		1553	1
3406B	Clutch release fork—RorL	1913-25				15	MH	4345	2
3406C	Clutch release fork pin	1913-25	Order 3405						
3411	Clutch lever clevis pin	1909-25	Order 2564						

TRANSMISSION BANDS

3413	TRANSMISSION BAND ASSEMBLY	1909-25				60	MH	838B	3
(Bands will be exchanged by dealers at 45 cents each)									
3415	Trans. band washer	1909-25	15	1 25		03		840	2
3416	Trans. band lining	1909-25		20 00		25	MH	1562	3
3416B	Trans. band lining—set of 3 inc. rivets—in carton	1909-25	8 00	70 00		1 00	MH	1564	1
3419	Trans. band adj. screw	1909-25		7 50		10		1533	1
3420	Trans. band adj. screw nut	1909-25	30	2 50		05		1532	1
3421B	Trans. band ear iron rivet	1909-25			\$2 00	05 doz		843	12
3422B	Trans. band brass rivet	1909-17			3 60	05 doz		844B	6
3423B	Trans. band brass rivet	1909-25			2 50	05 doz		845B	24
3425	Trans. band spring	1909-25	15	1 25		03		841B	3
3426	Trans. band adj. nut	1909-25	25	2 00		05		851	2

PEDALS AND CONTROLLER SHAFT

3427	Slow speed shaft	1909-25				15	MH	848B	1
3428	Slow speed notch	1909-25				25	MH	4327	1
3429	Slow speed notch pin	1909-25		60		01		1560	1
3432	Speed lever	1909-25				10	MH	862B	1
3434	Reverse pedal	1909-25				50	MH	4324	1
3435	Brake and rev. pedal shaft	1909-25				15	MH	849B	2
3436	Brake and rev. pedal support	1909-25				15		4325	2
3437	Brake and rev. support bolt	1909-25	25	2 00		05		1534	2
3437B	Brake and rev. support bolt nut	1909-25	Order 2515						
3439	Brake pedal	1909-25				50	MH	4323	1

†When ordered to replace cover on cars below 2044100 also order 3402D clutch lever and shaft.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Each	Fac. Status No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

TRANSMISSION CONTROL—Continued

PEDALS AND CONTROLLER SHAFT—Continued

3440	Clutch pedal	1909-25				\$0 50	MH	854B	1
3441	Pedal pin	1909-25							
3442	Clutch pedal support	1909-25				15		4326	1
3443	Clutch pedal support bolt	1909-25	\$0 25	\$2 00		05		1536	1
3443B	Clutch pedal support bolt nut	1909-25							
3445	Slow speed connection	1909-25				05		1540	1
3446	Slow speed con. lock nut	1909-25							
3447	Slow speed con. clevis	1909-25	40	3 50					
3448	Controller quadrant	1909-25	60	5 00		10		802	1
3449	Con.shaft with speed lever	1909-25				20	MH	309B	1
3450	Controller shaft bracket	1909-25				60	MH	1557	1
3452	Controller shaft bracket bolt	1909-25	25	2 00	\$15 00	03		315	4
3452B	Controller shaft bracket bolt nut	1909-25	15	1 25	9 00	02		316	4

HAND BRAKE

3455	Hand brake lever	1909-25				1 00	MH	1550	1
3456B	Hand brake lever pin	1909-25							
3457	Hand brake lever key	1909-17				03		874	1
3458	Hand brake lever pawl	1909-25				05		875	1
3459	Hand brake lever pawl pin	1909-25			50	01		876	1
3460	Hand brake lever pawl	1909-25				10	MH	877	1
3462	Hand brake lever pawl lift assembly	1909-25				10		4363	1
3463	Hand brake lever pawl lift spring	1909-25				02		888	1
3465	Hub brake lever	1909-25				15	MH	864	1
3466	Hub brake lever pin	1909-25							
3467	Hub brake lever clevis	1909-25							
3468	Hub brake pull rod—R	1909-25	2 50			30	MH	891B	1
3469	Hub brake pull rod—L	1909-25	2 50			30	MH	1513B	1
3470	Brake rod support—R	1909-25	60	5 00		10		1367C	1
3471	Brake rod support—L	1909-25	60	5 00		10		1398C	1
3472	Brake rod support bolt	1909-25		75	5 00	01		1308	2
3472B	Brake rod sup. bolt nut	1909-25							

STEERING GEAR

STEERING WHEEL AND GEAR CASE

3500C	Steering gear assy	1911-25				10 00	MH	5044	1
3501C	St. gear rim	1920-25				70		901C	1
3502	St. gear rim screw	1909-25				01		6849	4
3503D	St. gear spider	1920-25				50	MH	902C	1
3503E	St. gear spider and rim	1909-25				1 25	MH	995A2	1
3504	St. gear cover	1909-25				30	MH	5039	1
3505	St. gear cover screw	1909-25			50	01		910	1
3506	St. gear cover bushing	1909-25				15		914	1
3506B	St. gr. driv. pinion washer	1909-25				05		5026	1
3507	St. gr. int. gear case and bushing	1909-25				1 25	MH	5036	1
3509	St. gear quadrant	1909-25				15	MH	906B	1
3510	St. gear quadrant rivet	1909-25			50	01		5041	2
3511	St. gear wheel nut	1909-25	80	7 00		10		913	1

STEERING GEAR TUBING AND POST

3512C	St. gear tubing assy	1912-25				4 00	MH	5016	1
3513C	St. tubing flange screw	1913-25	15	1 00	7 50	03		5018	3
3514	St. tub. flange screw nut	1913-25	10	65	4 00	02		926	1
3516C	St. gear post	1912-21				1 75	MH	5043	1
3516D	St. gear post	1921-25				1 75	MH	5043B	1
3517	St. gear pinion	1909-25				15	MH	916	3
3518	St. gear pinion pin—short	1909-25				02		917	2
3518B	St. gear pinion pin—long	1921-25				02		918	1
3519	St. gear drive pinion	1909-25				30	MH	911	1
3520	St. gear drive pinion key	1909-25	20	1 00		03		909	1
3523	St. gear post castle nut	1909-25							

STEERING GEAR THROTTLE AND SPARK RODS

3524E	Throttle rod	1912-25				30	MH	5038	1
3525E	Spark rod	1912-25				30	MH	5037	1
3527	Spark & throttle rod spring	1909-25			1 00	02		935	2
3528	Spark & throttle rod collar	1909-25	15	1 00		02		936	2
3529	Spark & throttle rod pin	1909-25			50	01		937	5
3530	Spark rod lever	1909-25	80	6 00		10	MH	946	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. Status	No.	Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
STEERING GEAR—Continued									
STEERING GEAR THROTTLE AND SPARK RODS—Continued									
3531	Throttle rod lever	1909-25	\$0 80	\$6 00		\$0 10	MH	947	1
3532	Spark & throttle rod guide	1909-25				05		938	1
3534B	Commutator pull rod	1912-25				10	MH	2082	1
3535	Carburetor pull rod	1909-25	75			10	MH	1329	1
3536	Ball and socket joint	1909-21	85	6 00		10		1326	1
3537	Ball and socket joint nut	1909-21	15	7 50		10		1326	1
				1 00		02		1327	1

STEERING GEAR BRACKET

3539B	St. brkt. with bushing	1911-25	6 00			75	MH	996	1
3539C	St. brkt. with bushing—truck	1918-25	6 00			75	MH	TT996	1
3540	Brkt. bolt and nut—long	1909-25							
3541	Brkt. bolt and nut—short	1911-25							
3544	St. brkt. felt washer	1909-25							
3545	St. brkt. bushing	1909-21				02		943	1
3545B	St. brkt. bushing	1921-25				20		944-5027	1
3546	St. brkt. block	1909-25				10		944	1
3546B	St. brkt. block—Truck	1918-25				10		945	1
3547	St. gear ball arm	1909-25				10		TT945	1
3548	St. gear ball arm key	1909-25	25	1 50	\$12 00	40	MH	929B	1
3549	St. brkt. dust cap—Truck	1918-25				03		930	1
						05		TT5044	1

BODY PARTS

BODY BRACKETS

3601B	Body brkt. on body	1910-25				10		1624	6
3601C	Body brkt.—front—R	1921-25				20		7267B	1
3601D	Body brkt.—front—L	1921-25				20		7268B	1
3601E	Body bracket—rear	1913-25				05		5650	2
3601F	Body bracket—rear—R	1921-25				20		7137C	1
3601G	Body bracket—rear—L	1921-25				20		8001B	1
3602E	Body brkt. con. bolt	1916-25			2 00	63		2431	6
3602F	Body brkt. con. bolt nut	1916-25							

Order 2719

FLOOR BOARDS

3624E	Front floor rubber mat	1915-25	8 50			90	MH	7299	1
3626C	Floor board with plate (first)	1915-25				50	MH	4200	
3627C	Floor board with plate (second)	1915-25				50	MH	4201	
3628B	Floor board with plate (third)	1915-25				65	MH	7104	
3630	Floor board forward plate for pedals	1909-25				10	MH	1400C	1
3632	Floor board rear plate for pedals	1909-25				10	MH	1095C	1
3633	Floor board plate for side lever	1909-25				05	MH	1094B	1

DASH

3634D	Dash	1913-14				7 00		5336	1
3634E	Dash	1915-16				5 00		7462	1
3634H	Dash—(steel)	1917-25				2 50	MH	8754B	1
3634J	Dash—steel	1923-25				2 50	MH	8754C	1
3638B	Dash shield	1919-22				10		5432B	2
3639	Dash weatherstrip—side	1917-22				05		8747	1
3639B	Dash weatherstrip—top	1917-22				15		8752R	1
††3640C	Dash brkt.—left	1917-22				20		8722	1
*3640D	Dash brkt.—left	1923-25	1 25			15		8722B	1
††3641C	Dash brkt.—right	1917-22				20		8721	1
††3641D	Dash brkt.—right	1923-25	1 25			15		8721B	1
3642B	Dash brkt. to dash bolt	1917-22				03		8740	4
3642C	Dash brkt. to dash nut	1917-22							
3653B	Dash to body brkt. bolt	1915-25				15		1 00	
3653C	Dash to body brkt. nut	1915-25				03		4248	2
3654	Dash to body gasket	1918-25				05	MH	8769	

Order 3514

Order 4805C

LICENSE BRACKETS

3660C	Lamp & license brkt. assy	1915-21	2 00			25	MH	7506AR	1
3660D	Lamp & license brkt. assy	1915-21	2 00			25	MH	7505	1
†3660E	Lamp & license brkt. support assy	1923-25				75	MH	7506B	1
†3661	Lamp & license brkt. sup.	1923-25				30	MH	8767B	1
3664	Front license bracket	1921-25				10	MH	4934	1

††When used on 1911-16 cars redrill frame.

†Used on Touring Cars and Roadster without starter and demountable rims.

*Used with steel dash.

‡Used with steel dash.

†Used on Touring Car and Roadster with starter without demountable rims.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. No.	No. Req. per Car	
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
BODY PARTS—Continued									
CUSHIONS									
3667E	Front seat cushion	1909-21				\$ 6 00	MH	8076A	1
3667F	Front seat cushion	1921-25				6 00	MH	8076B	1
3670D	Rear seat cushion	1909-21				6 50	MH	7032A	1
3670E	Rear seat cushion	1921-25				6 50	MH	7032B	1
3676B	Rear floor mat	1911-21				1 00		1606B	1
3676C	Rear floor mat	1921-25				1 00		1606C	1
3680	Pedal shield	1924				15		1096	1
**3681	Deck lock key	1916-25	\$ 1 35			10		9484	1
				\$ 7 00					2

SPRINGS

FRONT SPRING

3800	Front spring	1909-25	22 50			2 50	MH	332	1
3801	First leaf (main leaf)	1909-25	6 00			80		2943	1
3802B	Second leaf	1909-25	4 00			45		2935	1
3803B	Third leaf	1916-25	3 00			40		2936	1
3804B	Fourth leaf	1916-25	2 50			30		2937	1
3805B	Fifth leaf	1916-25	2 00			25		2938	1
3806B	Sixth leaf	1916-25	1 50			20		2939	1
3807B	Seventh leaf	1916-25	1 25			15		2947	1
3808	Front spring clip	1909-20				20		325C	2
3809	Front spring clip nut	1909-25							
3810	Front spring clip bar	1921-25	2 00			25		342	1
3811	Front spring tie bolt	1909-25	20	1 50		04		1362	1
3811B	Front spring tie bolt nut	1909-25	15	1 00		02		1363	1
3813B	Front spring hanger	1909-25	1 75	15 00		20		246C	2
3814	Front spring hanger bar	1909-25	40			05		7648	2
3815	Spring hanger nut	1909-25							
3818	Front spring perch—right	1909-19				80	MH	274A	1
3818B	Front spring perch—right	1909-25	4 00			50	MH	274B	1
3819	Front spring perch—left	1909-19				80	MH	275A	1
3819B	Front spring perch—left	1919-25	4 00			50	MH	275B	1
3820	Front spring perch bush	1909-25	25	2 00	15 00	05		230	4
3821	Front spring perch nut	1909-21							
3821B	Front spring perch nut	1921-25				05		240	1
3823	Front spring pad	1909-25	\$ 0 45	4 00		05		262	1

REAR SPRING

3824	REAR SPRING	1909-25				6 50	MH	333	1
*3824B	REAR SPRING	1922-25				6 75	MH	388	1
†3824C	Rear spring	1923-25				5 00	MH	384	1
3825	First leaf (main leaf)	1909-17				1 50		361A	1
3825B	First leaf (main leaf)	1918-25				1 35		355	1
*3825C	First leaf (main leaf)	1922-25				1 35		389	1
3826	Second leaf	1909-17				1 25		362A	1
3826B	Second leaf	1918-25	10 00			1 10		362B	1
*3826C	Second leaf	1922-25				1 10		391	1
3827	Third leaf	1909-17				1 10		363A	1
3827B	Third leaf	1918-25	8 50			95		363B	1
*3827C	Third leaf	1922-25				95		392	1
†3827D	Third leaf	1923-25				75		379	1
3828	Fourth leaf	1909-17				95		364A	1
3828B	Fourth leaf	1918-25	7 50			85		364B	1
*3828C	Fourth leaf	1922-25				85		393	1
†3828D	Fourth leaf	1923-25				60		380	1
3829	Fifth leaf	1909-17				80		365A	1
3829B	Fifth leaf	1918-25				75		365B	1
*3829C	Fifth leaf	1922-25	\$ 6 50			75		394	1
†3829D	Fifth leaf	1923-25				45		381	1
3830	Sixth leaf	1909-17				75		366A	1
3830B	Sixth leaf	1918-25	5 00			60		366B	1
*3830C	Sixth leaf	1922-25				60		395	1
†3830D	Sixth leaf	1923-25				35		382	1
3831	Seventh leaf	1909-17				70		367A	1
3831B	Seventh leaf	1918-25	3 50			45		367B	1
*3831C	Seventh leaf	1922-25				45		396	1
3832B	Eighth leaf	1909-25	3 00			35		368B	1
*3832C	Eighth leaf	1922-25				35		397	1
*3832D	Ninth leaf	1922-25				30		398	1
3833	Rear spring clip	1909-25				20		326	2
*3833B	Rear spring clip	1922-25				20		1737	2
3834	Rear spring clip nut	1909-25							
3835	Rear spring clip bar	1909-25				05		329	2
3837	Rear spring tie bolt	1909-25	20	1 50		05		1352	1
3837B	Rear spring tie bolt nut	1909-25	15	1 00		02		1353	1

†Used on Touring Cars and Roadster without starter and demountable rims.

**Used on Coupe 1916-24, Roadster 1923-24.

*Nine-leaf spring for Sedan.

††Six-leaf spring for Roadster.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

SPRINGS—Continued

REAR SPRING—Continued

*3838	Rear spring tie bolt	1922-25		\$ 2 00		\$0 05	1355	1
†3838B	Rear spring tie bolt	1923-25		1 50		03	383	1
3840B	Rear spring hanger	1909-25	\$2 25	20 00		25	91 1/2 C.	2
3841	Rear spring hanger bar	1909-25	40	20 00		05	7649	1
3842	Rear spring pad	1909-25				05	94	2
3843	Rear spring perch	1909-25	3 50			40 MH	2804	2
3844	Rear spring perch bush	1909-25	35	3 00		05	172	4
3845	Rear spring perch nut	1909-25		4 00		05	174	2
3846	Spring perch oiler	1917-25	35	3 00		05	2944	4
3847B	Front spr'g clamp assembly with bolt and nut	1916-25	75	6 00		10	2953	2
3848	Rear spr'g clamp assembly with bolt and nut	1909-17	75	6 00		10	376	2
3848B	Rear spr'g clamp assembly with bolt and nut	1918-25	75	6 00		10	378	2
3850	REAR SPRING	1909-16				9 00 MH	1704	1

STARTING CRANK

3901	Starting crank handle	1909-22				15	520	1
3902	Starting crk. handle bolt	1909-22	60	5 00		10	521	1
3903	Starting crank sleeve	1909-22	60	4 00		10	523	1
3905	Starting crk. ratchet pin	1909-25	25	2 00		05	4491	1
3906	Starting crank ratchet	1909-25	1 50			20 MH	528B	1
3908	Starting crank spring	1909-25	20	1 00		03	626	1
3909	Starting crk handlespring	1915-22	15	1 00		02	5911	1
3910	Starting crank assy.	1909-25				40 MH	5931	1

RADIATOR—THERMO SYPHON

3925	Radiator	1909-16				15 00 MH	1100C	1	
3925B	Radiator	1917-23				16 00 MH	8700B	1	
3925C	Radiator less shell	1917-23				15 00 MH	8736B	1	
3925D	Radiator	1923-25				16 00 MH	8700D	1	
3925E	Radiator—less shell	1923-25				15 00 MH	8736E	1	
3926	Radiator cap	1909-25	1 25	11 50		15	MH 8714	1	
3927	Radiator cap gasket	1909-25				02	1117	1	
3928	Radiator pad	1909-19				05	MH 1105	2	
3929	Radiator stud	1909-19				05	1162A	2	
3929B	Radiator stud	1919-25	45	4 00	\$35 00	05	1162B	2	
3929C	Radiator stud nut	1909-25	20	1 50	12 00	03	1154	2	
3930	Radiator stud spring	1909-25							
3931 1/2	Radiator stud washer nut	1909-25	Order 2742	20	1 50	12 00	03	1161	2
3932	Radiator rod	1909-23		1 00		15	MH 1111B	1	
3932B	Radiator rod	1923		1 00		15	MH 1111C	1	
3932C	Radiator rod	1923-25		1 00		15	MH 1111D	1	
3934	Radiator rod nut	1909-25	Order 3066B			25	MH 1121	1	
3939	Outlet connection pipe	1909-25		2 00					
3940	Outlet connection cock	1909-25	Order 3079			25	MH 1121	1	
3944	Outlet connection hose	1909-25	90	7 50		10	MH 507B	2	
3945	Outlet con. hose clip	1909-25	30	2 50		05	554B	4	
3947B	Radiator shell	1917-23				1 00	MH 8737B	1	
3947C	Radiator shell	1923-25		7 50		1 00	MH 8737C	1	
3975	Rad. stud spring upper thimble	1919-25		1 50		02	1115	1	
3976	Rad. stud spring lower thimble	1919-25		2 00		03	1114	1	
3977	Radiator apron	1923-25				50	MH 8016	1	

RADIATOR FAN

3960	Fan and pulley assembly	1909-20				1 25	MH 619	1
3961	Fan blade	1909-20				10	611	4
3961B	Fan blade rivets	1909-20			1 50 doz.	05	1566	16
3961C	Fan blade assembly	1920-25	2 00			25	MH 620	1
3962B	Dr. fan pulley with bush	1920-25	6 00			70	MH 618B	1
3963	Fan drive pulley	1909-20				25	MH 602A	1
3963B	Fan drive pulley	1920-25	2 50			30	MH 602B	1
†3964	Fan belt—23' fabric	1909-16	2 75	25 00	220 00	35	MH 609A	1
†3964C	Fan belt—26' fabric	1917-20	2 75	25 00	220 00	35	MH 609B	1
†3964E	Fan belt—rubber	1920-25	2 75	25 00	220 00	35	MH 609C	1
3966	Fan shaft	1909-20				25	MH 606A	1
3966B	Fan shaft	1920-25	1 75	12 50		20	MH 606B	1
3967	Fan bracket	1909-16	3 00			40	MH 604A	1
3967B	Fan bracket	1917-25	2 50			30	MH 604B	1
3968	Fan bracket bolt	1909-25	85	7 50		10	605	1
3970	Fan grease cup	1909-25	85	7 00		10	601	1
3973	Fan adjusting screw	1909-25	15	1 00		02	645	1

*Nine-leaf spring for Sedan. †Six-leaf spring for Roadster.
 ‡Quantity prices will apply on any assortment of these three belts.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				

RADIATOR FAN—Continued

3973B..	Fan adjusting screw nut.....	1909-25							
3974..	Fan driven pulley bush.....	1917-20				\$0 15		8757A.....	1
3974B..	Fan driven pulley bush.....	1920-25	\$1 00			15		8757B.....	2
3980..	Fan pulley plug.....	1920-25	25	\$ 2 00		03		633.....	1
3981..	Fan pulley gasket.....	1920-25	15	90		02	MH.....	634.....	1
3982..	Fan shaft cap.....	1920-25	10	90		02		635.....	1
3983..	Fan shaft felt washer.....	1920-25	15	1 00		02		637.....	1
3984..	Fan blade screw.....	1920-25							
3985..	Fan blade screw washer.....	1920-25						652.....	4
3986..	Fan shaft nut.....	1920-25							

Order 3066B

Order 3261C

Order 2719

MUFFLER

4025B..	Muffler assembly.....	1909-25				2 25	MH.....	1200C.....	1
4026B..	Muffler head—front.....	1917-20				35		1202C.....	1
4026C..	Muffler head—front.....	1921-25				10		1202D.....	1
4027..	Muffler shell—outer.....	1909-25				25		1203.....	1
4028..	Muffler shell—middle.....	1909-25				20		1204.....	1
4029..	Muffler shell—inner.....	1909-20				20		1205.....	1
4030..	Muffler rod.....	1909-17				10		1206A.....	3
4030B..	Muffler rod.....	1917-20				10		1206B.....	1
4031..	Muffler rod nut.....	1909-20							
4032..	Muffler head retainer.....	1921-25				02		1210.....	1
4033..	Muffler head retainer bolt and nut.....	1921-25							
4035..	Muffler head bolt washer.....	1921-25				05		925.....	1
4037B..	Long exhaust pipe.....	1909-20				1 25	MH.....	1214A.....	1
4037C..	Long exhaust pipe.....	1920-25				1 40	MH.....	1214B.....	1
4040B..	Muffler head—rear.....	1917-21				35		1201D.....	1
4040C..	Muffler head—rear.....	1921-25				20		1201E.....	1
4041B..	Muffler head to frame bolt and nut.....	1921-25							

Order 2503F

Order 4819B and 3514

Order 3074 and 2515

HOOD

4050..	Hood.....	1909-16				8 00	MH.....	1300.....	1
4050B..	Hood.....	1917-23				6 00	MH.....	8726.....	1
4050C..	Hood.....	1923-25				6 00	MH.....	8726B.....	1
4051..	Hood handle.....	1909-25				05		1314.....	2
4052..	Hood clip.....	1909-16				10		1310.....	4
4052B..	Hood clip.....	1917-25		4 00		05		8731.....	4
4053..	Hood clip spring.....	1909-16				02		1311.....	4
4053B..	Hood clip spring.....	1917-25	15	1 00		02		8734.....	4
4056B..	Hood block—left.....	1917-23	2 50			30		8742.....	1
4056C..	Hood block—left.....	1923-25	2 50			30		8742B.....	1
4057B..	Hood block—right.....	1917-23	2 50			30		8741.....	1
4057C..	Hood block—right.....	1923-25	2 50			30		8741B.....	1
4060C..	Hood pad (on dash).....	1917-22	70	5 00		08	MH.....	8711AR.....	2
4060D..	Hood pad (on rad. shell).....	1917-25	1 35	10 00		15	MH.....	8710.....	1
4060E..	Hood pad (on dash).....	1923-25	70	5 00		08	MH.....	8711B.....	2
4061B..	Hood clasp (on dash).....	1917-20	40	3 50		05		8720AR.....	1
4061C..	Hood clasp (on dash) screw.....	1917-23				02		8763.....	2
4061D..	Hood clasp (on dash).....	1920-23	35	2 50		05		8720BR.....	1
4061E..	Hood clasp (on dash).....	1923	35	2 50		05		8720C.....	1
4061F..	Hood clasp (on dash).....	1923-25	35	2 50		05		8720D.....	1
4073..	Hood bl support—front R.....	1917-23				05		8743.....	1
4073B..	Hood bl support—frt—R.....	1923-25				05		8743B.....	1
4074..	Hood bl support—front L.....	1917-23				05		8744.....	1
4074B..	Hood bl support—frt—L.....	1923-25				05		8744B.....	1
4075..	Hood bl support—rear R.....	1917-23				05		8745.....	1
4075B..	Hood bl support—rear—R.....	1923-25				05		8745B.....	1
4076..	Hood bl support—rear L.....	1917-23				05		8746.....	1
4076B..	Hood bl support—rear—L.....	1923-25				05		8746B.....	1

CARBURETOR

FORD CARBURETOR MODEL ("NH")

6200B..	Carburetor.....	1920-25	40 00			4 50	MH.....	553A4.....	1
6201..	Float with lever.....	1920-25	2 00			25		6333B.....	1
6202B..	Float chamber and bushing asy.....	1920-25				50		6318B.....	1
†6202C..	Float chamber.....	1923-25				30		4802F.....	1
6203..	Float chamber gasket.....	1920-25				03		555B.....	1
6204..	Spray nozzle gasket.....	1920-25			50	01		4820B.....	1
6205..	Mixer chamber gasket.....	1920-25				02		6367B.....	1
6206..	Throttle lever.....								
6206B..	Aux. throttle lever.....								
6207B..	Mixer chamber.....	1920-25				2 50		6343R.....	1

Order 6070

Order 6077

†Used with mixln2 chamber having slots at bottom.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
CARBURETOR—Continued								
FORD CARBURETOR MODEL ("NH")—Continued								
6208	Adj. needle clamp nut	1920-25				\$0 05	4812B	
6209	Throttle plate	1920-25				02	4517B	
6210	Float lever pin	1920-25				01	6320B	
6211	Float chamber screw	1920-25				05	6284	
6212	Float valve seat	1920-25	\$0 40			05	6321B	
6213	Spray needle assembly	1920-25	1 00			15	6335B	1
6214B	Spray nozzle	1920-25	1 50			20	6341C	
6215	Air passage vent plug	1920-25				10	6273R	
6216	Drain valve plug Assy	1916-25				10	6329	
6217	Throttle lever stop screw			Order 6064				
6218	Aux. throttle lever spring			Order 6076				
6219	Float valve seat gasket	1920-25				01	6322C	
6220	Gasoline inlet needle	1920-25		Order 4453A				
†6221	Drain valve body	1923-25				15	6328D	
KINGSTON CARBURETOR (MODEL "L-4")								
6150	Carburetor	1921-25	40 00			4 50	MH 553A1	1
6151	Drain valve body	1921-25				15	6328C	
6152	Float chamber	1921-25				50	4802E	
6153	Mixing chamber	1921-25				2 50	6340G	
6154	Carb. inlet elbow			Order 6055				
6155	Float with lever	1921-25	3 00			40	6333G	1
6156	Float chamber gasket	1921-25				05	555D	
6157	Mix chamber gasket	1921-25				05	6367E	
6158	Float valve seat gasket	1921-25				03	6322F	
6159	Constant air supply lever Assy	1921-25				30	6327D	
6160	Throttle lever Assy	1921-25				30	4836D	
6161	Spray needle assembly	1921-25		Order 6115				
6162	Drain valve body clamp nut	1921-25				05	6395	
6163	Mix. chamber nut	1921-25				10	4810C	
6164	Constant air supply spring			Order 6125				
6165	Spray needle sleeve	1915-25				20	4812C	
6166	Float lever pin	1915-25				02	6320C	
6167	Constant air supply plate	1921-25		Order 6068				
6168	Throttle plate	1921-25		Order 6209				
6169	Drain valve plug Assy	1915-25				10	6329B	
6170	Throttle lever adj. screw			Order 6120				
6171	Air valve stop Assy	1921-25				15	6397	
6172	Float valve seat	1921-25				20	6321E	
6173	Air valve shaft Assy	1921-25				20	6381B	
6174	Air valve	1921-25				30	6355B	
6175	Gasoline valve	1921-25	2 00			30	6324D	1
FORD CARBURETOR PARTS (MODEL "G")								
4451A	Float with lever	1914-21				25	6333AR	1
4452A	Spray needle assembly	1914-21	1 00			15	6335AR	1
4453A	Gasoline inlet needle	1914-21	1 00			15	6324A	1
6041	Mix chamber	1914-20				2 50	6340AR	
6042	Mix chamber top	1912-14-20				40	4801R	
6043	Mix chamber top screw	1912-20				02	4808R	
6044	Mix chamber top gasket	1914-20				01	6317R	
6044B	Mix chamber bottom gasket	1912-20				03	6367AR	
6045	Mix chamber nut	1912-20				07	4810AR	
6046	Float chamber & bush	1914-20				50	6318AR	
6047	Float lever pin	1914-20				03	6320AR	
6048	Float valve seat	1914-20				10	6321AR	
6049	Float valve seat gasket	1914-20				01	6322A	
6051	Spray needle clamp nut	1912-20				05	4812AR	
6052	Spray nozzle	1914-20				30	6341AR	
6053	Spray nozzle gasket	1912-14-20			\$0 50	01	4820AR	
6055	Gas inlet elbow	1913-20	1 00			15	4859	
6057	Low speed tube with nut	1915-20				15	6360R	
6058	Low speed tube retaining screw	1912-14-20				03	4814R	
6060	Low speed boss screw	1912-14-20				03	4816R	
6061	Strangling tube	1912-14-20				15	4817R	
6062	Strangling tube retainer	1912-14-20				02	4818R	
6064	Throttle lever stop screw	1911-21				02	4520A	
6065	Throttle lever clamp scr.	1911-19				02	4521AR	
6068	Throttle plate	1912-14-20				10	4517AR	
6070	Throttle lever	1912-14-20				10	4836B	
6070B	Throttle lever—over-size	1912-14-20				10	4836AR	
6071	Throttle lev. adj. lock nut	1911-20				02	4528R	
6074	Aux. throttle plate	1915-20				03	6337AR	

†Used with mixing chamber having slots at bottom.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			

CARBURETOR—Continued

FORD CARBURETOR PARTS (MODEL "G")—Continued

6076	Aux. throttle lever spring	1914-20				\$0 02	6342A	
6077	Aux. throttle lever assy.	1914-21				15	6327A	
4463	Float lever holding screw nut	1912-19				02	4805AR	
4464	Float lever holding screw	1913-19				03	4853AR	
6081A	Drain valve plug assy.							

Order T-6216

Parts for 1909-13 Carburetors supplied by Holley Kerosene Carburetor Co., Detroit, Mich.

KINGSTON CARBURETOR PARTS (MODEL "L-2")

6101A	Carburetor float assy.	1917-21				60	6333FR	1
6102	Throttle lever	1913-20				30	4836CR	
6103A	Constant air supply lever	1913-20				30	6327CR	
6104	Gas valve cap	1910-16				20	3005	
6105A	Air valve cap	1915-16				30	6357AR	
6105B	Air valve cap	1917-20				30	6357BR	
6106A	Float chamber	1917-20				1 00	4802DR	
6107A	Mix chamber	1917-20				2 50	6340FR	
6108	Mix chamber gasket	1913-16				15	6367CR	
6108A	Mix chamber gasket	1917-20				05	6367DR	
6109	Throttle gate							
6110A	Constant air supply gate	1915-20				10	6337CR	
6111	Mix chamber nut	1913-20				10	4810BR	
6114	Gas valve retainer nut	1910-16				10	3027	
6115	Spray needle assembly	1910-21				40	6335D	1
6118A	Float to lever screw	1917-20				03	4853B	
6120	Throttle lever adj. screw	1913-20				0 03	4520B	
6121	Throttle lev. clamp screw	1910-20				03	4521BR	
6122	Gas valve operating lever shaft	1913-16				15	6320DR	
6123	Air valve shaft	1915-20				20	6381AR	
6124A	Spray needle sleeve							
6125	Constant air supply spring	1913-20				05	6342C	
6126	Float valve seat	1915-16				20	6321CR	
6126A	Float valve seat	1917-20				20	6321DR	
6127A	Gasoline valve	1917-21				30	6324CR	
6128	Air valve	1915-20				30	6355AR	
6129	Float valve seat gasket	1915-16				03	6322DR	
6129A	Float valve seat gasket	1917-20						

Use 6068

Order 6165

Order 6049

Parts for 1909-16 Carburetors supplied by Bryne Kingston Co., Kokomo, Ind.

CARBURETOR ATTACHMENTS

4127A	Carburetor adj. rod brkt.	1909-22				05	1357 R	1
4129A	Carb. adjusting rod	1909-25				10	MH 7920	1
4130	Carb. flange bolt	1909-25						
4130B	Carb. flange bolt nut	1909-25						
4134	Carb. flange gasket	1909-25						
4431	Carb. priming rod	1909-25				05	MH 2000	1
4582	Carb. hot air pipe	1912-25				20	MH 686	1
4583	Priming bell crank	1919-25				05	MH 7691	1
4585	Priming rod plate—Coupe	1919-20				10	7664	1
4586	Priming rod plate—Sedan	1919-20				10	7665	1
4587B	Priming rod—17 1/4"	1919-22	1 00			15	MH 6629BR	1
4588B	Priming rod—13 1/4"	1919-22	1 00			15	MH 6627AR	1
*4588C	Priming rod—16 1/4"	1922	1 00			15	MH 6630AR	1
†4588D	Priming rod—13 1/4"	1923-25	1 00			15	MH 6627B	1
†4588E	Priming rod—17 1/4"	1923-25	1 00			15	MH 6629C	1
*4588F	Priming rod—16 1/4"	1923-25	1 00			15	MH 6630B	1
4589	Priming rod—20 1/2"	1919-25				05	MH 8797B	1
4589B	Priming rod—14 1/2"	1922-25				05	MH 8797A	1

Order 3072

Order 3066B

\$0 20

\$1 50

3 50

15 00

FENDERS

FENDERS

4800B	Front fender—right	1917-23	35 00			4 00	MH 7976	1
4800C	Front fender—right	1923-25	35 00			4 00	MH 7976B	1
4801B	Front fender—left	1917-23	35 00			4 00	MH 7977	1
4801C	Front fender—left	1923-25	35 00			4 00	MH 7977B	1
4802F	Rear fender—right	1917-25	30 00			3 50	MH 8850	1
*4802G	Rear fender—right	1922-25	32 50			3 75	MH 7730	1
†4802H	Rear fender—right	1923-25	35 00			4 00	MH 8850B	1
4803F	Rear fender—left	1917-25	30 00			3 50	MH 8851	1
*4803G	Rear fender—left	1922-25	32 50			3 75	MH 7731	1
†4803H	Rear fender—left	1923-25	35 00			4 00	MH 8851B	1

*For Tudor and Fordor Sedan.

†For Coupe.

‡Used with steel dash.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot	Each			
FENDERS—Continued									
FENDER IRONS									
4804D	Rear fender iron—R. & L. —T. C.	1913-25	.. \$1 50				\$0 20	5405	2
4804E	Rear fender iron—right Cp. & Rbt.	1913-23					60	5563AR	1
4804F	Rear fender iron—left— Cp. & Rbt.	1913-23					60	5390AR	1
4804G	Rear fender iron—R. or L.—Sedan	1916-17					25	8154A	2
4804K	Fender iron—R. or L.— Sedan	1918-25					15	8154B	2
4804L	Rear fender iron—T. C.	1921-25					10	7395	21
4804-M	Rear fender iron—right	1923-25	5 50				60	5563B	1
4804-N	Rear fender iron—left	1923-25	5 50				60	5390B	1
4809	Front fender iron—R or L	1909-25	5 50				60	343	2

FENDER BOLTS, NUTS AND BRACKETS

4805B	Rear fender iron bolt	1915-25	20	\$1 20	\$9 00		03	7171	6
4805C	Rear fender iron bolt nut	1915-25	15	1 00	6 00		02	341	
4806B	Fender eye bolt	1909-25		4 50			05	1942	4
4806C	Fender eye bolt washer	1909-25		50	2 50		01	1943	4
4806D	Fender eye bolt nut	1909-25							
4808	Front fender iron bolt (side)	1910-25	20	25	2 00	13 00	03	1323	2
4808B	Front fender iron bolt (bottom)	1910-25		25	2 00	13 00	03	347	2
4808D	Front fender iron bolt nut	1910-25							
4808C	Front fender apron to frame bolt	1915-25		15	1 25	8 00	03	4088	4
4808E	Front fender apron to frame bolt nut	1915-25							
4850	Frt. fender apron brkt.—R	1917-25					10	8854	1
4851	Frt. fender apron brkt.—L	1917-25					10	8855	1
4852	Frt. fender iron brkt.—R	1915-25					10	7984	1
4853	Frt. fender iron brkt.—L	1915-25					10	7998	1
4854	Rear fender iron bracket	1915-25					15	7483	2
4855	Rear fdr to R.B. shield bkt	1915-25					05	7994	2

RUNNING BOARD AND SHIELDS

4812	Running board—R.	1909-25					1 25	MH	5418	1
4813	Running board—L.	1909-25					1 25	MH	5480	1
4814C	R. B. shield—R.	1917-25					2 40	MH	7986	1
*4814D	R. B. shield—L.	1917-25					2 40	MH	7747	1
*4815C	R. B. shield—L.	1917-25					2 40	MH	7987	1
*4815D	R. B. shield—L.	1922-25					2 40	MH	7748	1
4816	R. B. truss rod—front with nuts	1909-21					35	MH	5804	1
4817	R. B. truss rod—rear with nuts	1909-21					35	MH	5805	1
4817B	Truss rod nut	1909-21	20	1 50			03	339	4	
4818B	R. B. bracket assy.	1909-20					1 10		2926	2
4819	R. B. to rear fender bolt.	1921-25	15	1 25			03	1344B	4	
4819B	R. B. to rear fender bolt.	1909-25	20	1 50	10 00		03	8161	4	
4819C	R. B. to rear fender nut.	1909-25								
4819D	R. B. to rear fender nut.	1909-25								
4820	R. B. to front fender bolt and nut	1909-20								
4820C	R. B. to front fender bolt	1921-25								
4821	R. B. to shield clamp	1919-25					05	5478		

RUNNING BOARD—TRUCK

4830	Running board—R. or L.	1918-25					50	MH	TT5418	2
4831	R. B. bracket	1918-25					35		TT2926	4
4832	R. B. bracket brace	1918-25					15		TT2927	2
4833	R. B. bracket rear brace	1918-25					30		TT2929	1
4834	R. B. bracket—rear	1918-25					35		TT2925	
4835	R. B. bracket and brace assy.—frt.	1918-25					50		TT2928	
4836	R. B. bracket and brace assy.—rear	1918-25					1 10		TT2930	

FORD SPARK COIL

5000	Coil (includes switch)	1909-22					8 65	MH	1383	1
5001	Coil (less switch)	1909-25					7 90	MH	1383B	1
5002	Coil box with cover	1914-22					2 25	MH	5858	1
5003	Coil box with cover	1919-25	14 00				1 50	MH	5858B	1

*For Four-door Sedan.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Each	Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				
5004	Coil box cover	1915-25				\$0 25	7910	1	
5005B	Switch cover	1918-22				10	5835B	1	
5006	Switch plug	1914-22	\$ 0 20	\$ 1 50		05	5815A	1	
5007	Coil unit	1914-25	14 50	140 00		1 60	MH 5845	4	
5008	Vibrator	1914-25	50	4 00	\$30 00	10	6797	4	
5008B	Vibrator and lower bridge assy.	1924-25	75	5 00		10	6737B	4	
5009	Vibrator bridge	1914-25	70	6 00	52 00	10	6702	4	

FORD SPARK COIL—Continued

SWITCH

5010	Switch assembly (on coil)	1914-22				60	MH 5873	1
5012	Ignition switch (on instrument board)	1919-25	8 00			1 00	MH 7675E	1
5013B	Switch key—give serial number	1919-25	50	4 50	40 00	10	5815C	1
5014	Starting switch (on floor bd)	1919-25	4 50			55	MH 8792	1
5014B	Starting switch bracket bolt—long	1920-25		2 00		03	8760	1
5014C	Starting switch brkt assy	1923-25	2.50			30	8696	1
5014E	Starting switch cover and plunger assy.	1923-25	1 50			20	8698	1
5015	Starting switch plunger extension	1919-25	50			10	8793	1

AMMETER

5016	Ammeter	1919-25	5 50	45 00		65	MH 7680	1
5017	Ammeter lens & rim	1919-25	1 50			20	8105	1
5017B	Ammeter lens	1919-25	40	3 00		05	8121	1

STARTER DRIVE

5018	Starter drive	1919-25	36 00			4 00	1883	1
5019	Starter drive head	1919-25	4 00			50	2007	1
5020	Starter drive key	1919-25	15	1 00	7 50	02	1751	1
5021	Starter drive shaft & gear	1919-25				3 50	2026	1
5022	Starter drive spring	1919-25	2 50	20 00		35	2006	1
5023	Starter drive shaft spring screw	1919-25		2 25	21 00	03	1983	1
5024	Starter drive head spring screw	1919-25	30	2 50	22 50	05	1781	1
5025	Starter drive spring screw lock washer	1919-25		50	4 00	01	1782	2

WIRING

5026	Spark plug wire 14 1/4'	1909-25	70	6 50		10	MH 1365	1
5027	Spark plug wire (also magneto to coil) 10 1/2'	1909-25	65	6 00		10	MH 1366	1
5028	Spark plug wire, 7'	1909-25	60	5 00		10	MH 1376	2
5030	Commutator wire	1909-22	7 50	70 00		80	MH 7502AR	1
*5030B	Commutator wire	1922-25	9 00	85 00		1 00	MH 7502C	1
5031	Com. wire (starter type)	1919-25	10 00	95 00		1 00	MH 7502B	2
5033B	Com wire term. retainer	1921-25				01	2124	2
5033C	Wire on dash clip	1919-25				01	7688	7
5034	Ammeter to cutout wire—Sedan 33'	1919				15	MH 7683A	1
5035	Ammeter to cutout wire—Sedan 49'	1919-25	1 80			20	MH 7683B	1
5036	Ammeter to cutout wire—Coupe 23'	1919				15	MH 7684A	1
5037	Ammeter to cutout wire—Coupe 41'	1919-25	1 25			15	MH 7684B	1
5038	Ammeter to ignition switch wire	1919-25	80			10	MH 7681	1
5039	Gen. to cutout wire	1919	1 25			15	MH 7687	1
5040	Terminal block to switch wire	1919-25	60			10	MH 8894B	1
5041	Lighting wire	1919-25				90	MH 7682B	1
5041B	Lighting wire—truck	1921-25				1 00	MH TT 7682	1
*5041C	Lighting wire	1922-25	4 50			50	MH 7661	1
5042	Switch wire—Sedan	1919-25	6 50			75	MH 7685B	1
5043	Switch wire	1919-25	6 00			70	MH 7686B	1
*5043B	Switch wire	1922-25	3 50			40	MH 7660	1
5044	Terminal block	1919-22				05	1950AR	1

*Used on cars without starter, with switch on instrument panel.

Of the net amount at which part marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

LIST PRICE

Part No.	Name of Part	Year	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot			
WIRING—Continued								
45044B...	Terminal block.....	1923-25	\$0 60	\$5 00		\$0 10	1950B.....	1
*5044C...	Terminal block.....	1922				05	1951AR.....	1
*45044D...	Terminal block.....	1923-25	60	5 00		10	1951B.....	1
5045	Terminal block to dash screw.....	1919-25				01	2073.....	2
5046	Battery to switch cable—28 1/4".....	1919-25	7 00			80	MH. 1889B.....	1
5046C...	Battery to switch cable—truck.....	1921-25	7 00			80	MH. TT1889.....	1
5047	Battery to switch cable—34".....	1920				75	MH. 1889C.....	1
5047B...	Battery to switch cable support—truck.....	1920-25	75			10	2116.....	1
5047C...	Battery to switch cable support.....	1920-25	75			10	2112.....	1
5047D...	Battery to switch cable support bush.....	1920-25				05	2113.....	1
5047E...	Battery to switch cable sleeve.....	1921-25				05	2120.....	1
5048	Ground cable—20".....	1919				70	MH. 1890A.....	1
5049B	Ground connector.....	1919-25	2 50			30	MH. 1890B.....	1
5050	Ground cable—11 1/2".....	1920				60	MH. 1890C.....	1
5051	Switch to motor cable.....	1919-25				50	MH. 1891.....	1
5051B...	Switch to motor cable sleeve.....	1921-25	2 50			30	2119.....	1
5052	Battery cable terminal bolt.....	1919-25		1 50		02	1937.....	2
5052B...	Battery cable terminal bolt nut.....	1919-25		75		01	1938.....	2

CUT-OUT

5055	Cut-out (electric).....	1919-25	8 00	70 00		1 00	MH. 7677B.....	1
------	-------------------------	---------	------	-------	--	------	----------------	---

STARTER PARTS

5056	Motor mount'g gasket.....	1919-25	15	1 20	\$11 00	02	MH. 1768.....	
5057	Gen. head gasket.....	1919-25	10	60	3 50	02	MH. 1774.....	
5058	Gen. m'n't'g short screw.....	1919-25	20	1 50	12 00	03	MH. 1755.....	
5059	Bendix cover screw.....	1919-25		50	4 00	01	1765.....	
5060	Term. blk. to wire screw.....	1919-25		50	4 50	01	2015.....	
5061	Ammeter to plate screw.....	1919-25		50	4 00	01	5819.....	
5062	Motor mounting screw.....	1919-25	15	1 00	7 50	02	5510.....	

STARTING MOTOR AND PARTS

5099	Starting motor.....	1919-25	135 00			15 00	MH. 1877.....	
45100	Armature.....	1919-25	45 00			5 00	1940.....	
45101	Cover band.....	1919-25	75	5 00		10	1801C.....	
5102	Brush end bracket.....	1919-25				30	1868.....	
5103	Bracket assy. mounting.....	1919-25				1 30	2037.....	
5104	Brush.....	1919-25		17 00	140 00	20	1806.....	
5105	Shaft rear bushing.....	1919-25				35	1759.....	
5106	Shaft front bushing.....	1919-25		7 50		10	1789.....	
5107	Field coil assembly.....	1919-25				2 50	1871.....	
5108	Brush holder assembly.....	1919-25	4 00			45	1864B.....	
5109	Terminal outer insulator.....	1919-25	15	1 00	7 50	02	1795.....	
45110	Terminal inner insulator.....	1919-25		50	3 50	01	1794.....	
5112	Terminal nut.....	1919-25	20	1 50	12 00	03	1791.....	
45113	Field screw.....	1919-25	15	1 00	8 00	02	1788.....	
45114	Brush end bracket to yoke screw.....	1919-25		75	4 00	01	1808.....	
5115	Brush tension spring.....	1919-25	25	2 00		05	1809.....	
5116	Terminal washer.....	1919-25		50		01	1792.....	
5117	Terminal inner steel washer.....	1919-25		50		01	1798.....	
5118	Motor yoke assembly.....	1919-25				3 50	1852.....	

GENERATOR AND PARTS

5119	Generator.....	1919-25	135 00			15 00	MH. 1879.....	
45120	Armature (less bearings).....	1919-25	40 00			4 50	1925.....	
5121	Small bearing.....	1919-25	10 00	95 00	850 00	1 10	1838.....	
5122	Large bearing.....	1919-25	11 00	105 00	950 00	1 25	1841.....	
5123	Terminal bolt.....	1919-25		1 50		03	1836.....	
5124	Brush end bracket.....	1919-25				25	1894.....	
5125	Large brush.....	1919-25	1 35	12 00	110 00	15	1844.....	
5126	Small brush.....	1919-25	1 35	11 50	100 00	15	1845.....	

†Used with steel dash. †Also for generator. †Armature may be exchanged with dealer at \$4.00.
 *Used on cars without starter, with switch on instrument board.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot				

GENERATOR AND PARTS—Continued

5127	Large bearing disc	1919-25		\$ 2 00		\$0 03		1847
5128	Small bearing felt	1919-25	\$0 15	1 00			02	2033
5130	Head	1919-25					50	2044
5131B	Small brush holder	1919-25	90	8 00	\$70 00		10	1821
5132B	Brush holder ring	1919-25					03	1996
5132C	Brush holder assembly	1919-25		37 50			40	1865
5132D	Brush holder assembly less small brush holder	1919-24		27 50			30	1920
5133	Terminal outer insulator	1919-25	15	1 00	8 00		03	1827
5134	Terminal nut	1919-25	15	1 00	8 00		03	1818
5134B	Brush holder stud nut	1919-25		75	5 00		01	6754
5135	Oiler	1919-25		4 00			05	1837
5136	Pinion to shaft pin	1919-25		50	4 00		01	1750
5137	Pinion	1919-25	3 00				35	1752
5138	Small brg. felt retainer	1919-25		1 00			02	1832
5139	Large brush spring	1919-25	30	2 50	20 00		05	1967
5140	Small brush spring	1919-25	30	1 50	20 00		05	1988
5141B	Small brush holder stud	1919-25	10	80	7 00		02	1823C
5142	Terminal washer	1919-25		50			01	1831
5142B	Small brush holder stud washer	1919-25		30	2 00		01	2058
5143	Field winding assembly	1919-25	14 00			1 50	50	1978
5144	Brush to terminal wire	1919-25		3 00			05	1851
5145	Gen. yoke assembly	1919-25				3 00	00	1887

BATTERY BRACKET AND PARTS

5150	Bracket assembly	1919-23				75	MH	8841AR	1
5150B	Battery bracket assy.	1923-25				75	MH	8841B	1
5151	Clamp bolt	1919-25		2 00	10 00		03	8846	
5151B	Clamp bolt nut	1919-25							
5152	Clamp	1919-23				05		8844AR	
5152B	Battery clamp	1921-25	40			05		8844B	2
5153	Battery support angle—truck	1921-25	1 25			15		TT8816	1
5154	Battery box support—truck	1921-25	1 75			20		TT8817	
5155	Battery clamp support—rear—truck	1921-25	1 75			20		TT8818	1
5156	Battery clamp support—front—truck	1921-25	1 75			20		TT8819	1
5158	Battery box—less cover	1921-25				75		7671	1
5159	Battery box cover assy.	1921-25	5 00			60		5491	1
5160	Battery box cover door	1921-25				10		5493	

BATTERY (FORD)

5175	Battery	1919-25				16 50	MH	7670	1
5176	Battery case assy.	1919-25	11 00			1 25		5434	
5177	Cell connector	1919-25	80			10		5435	
5178	Cell cover	1919-22				30		5436AR	
5178B	Cell cover	1921-25	1 50			20		5436B	
5178C	Cell cover	1923-25	1 50			20		5436C	3
5179	Terminal post gasket	1919-22				01		5437AR	
5179B	Terminal post gasket	1921-25		60		01		5437B	
5179C	Terminal post gasket	1923-25		60		01		5437C	
5180	Rubber jar	1919-25	5 50			60		5438	
5181	Terminal post nut	1919-22	30	2 50	20 00	05		5439AR	
5181B	Terminal post nut	1921-25	30	2 50	20 00	05		5439B	
5182	Negative group assy.	1919-22				2 00		5440AR	
5182B	Negative group assy.	1921-25	16 00			1 70		5440B	1
5183	Positive group assy.	1919-22				2 00		5441AR	
5183B	Positive group assy.	1921-25	16 00			1 70		5441B	
5184	Filler plug with gasket	1919-22	1 00	9 00		15		5444AR	
5184B	Filler plug with gasket	1921-25	1 00	9 00		15		5444B	
5184C	Filler plug	1923-25	75	5 00		10		5442C	
5185	Plate separator	1919-25		2 00	17 50	05		5445	
5186	Positive plate	1919-22				25		5427AR	
5186B	Positive plate	1921-25				25		5427B	
5187	Negative plate	1919-22				25		5428AR	
5187B	Negative plate	1921-25				25		5428B	
5188	Negative terminal post	1919-22	1 75			20		5425AR	
5188B	Negative terminal post	1921-25	1 25			15		5425B	
5189	Positive terminal post	1919-22	1 75			20		5426AR	
5189B	Positive terminal post	1921-25	1 25			15		5426B	
5190	Terminal—negative	1909-25	1 20	10 00		15		1929B	
5191	Terminal—positive	1909-25	1 20	10 00		15		2049	
M6022	Battery Sealing Compound		10 lb.			per lb.		13	
M1051	Electrolyte								

SPARK PLUGS

5201	Spark plug "Ford" (Champion)	1909-24	4.50 net.	40.00 net.		160		1386A3	4
5203B	Spark plug porcelain "Ford" (Champion)	1909-24	2.20 net.	20.00 net.		130		3760C	4

*Used with steel battery box.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Co, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	LIST PRICE			Tax Status	Fac. No.
		Lots of 10 per lot	Lots of 100 per lot	List Price Each		

REPAIR TOOLS

1349	Hub cap wrench	\$1 00		\$0 15	MH	1349
1387	Adjustable wrench	3 50		40		1387
1903	Pliers			25		1903
1917	Double end wrench		\$12 00	15		1917
2335	Spark plug and cyl. head bolt wrench			40		5893
2336	Tool roll			20		1979
2337	Oil can	1 50		20		1384
2338	Tire pump	10 00		1 10	MH	1368
2340	Tire irons, each			15		4069
2343	Jack	11 00		1 25	MH	3389
TT4069	Tire iron (large)			40		
5Z-152	Rear axle housing bolt nut wrench	3 00		40		
5Z-153	Socket wrench for crank shaft bearing nut	4 00		50		
5Z-154	Body bracket con. bolt R. & L. wrench			30		
5Z-155	3/8" L socket wrench	3 50		45		
5Z-156	Crank shaft bearing bolt wrench	3 00		45		
5Z-157	Con. rod cap bolt nut L wrench (Cyl. No. 4)	3 00		40		
5Z-158	D S housing stud nut wrench for H ¹ nut	3 00		45		
5Z-159	Connecting rod T wrench	4 50		55		
5Z-160	3/8" T socket wrench	4 30		50		
5Z-161	Body bracket connecting bolt T wrench, front and center	3 60		45		
5Z-162	Large cam gear lock nut wrench			75		
5Z-165	Drive shaft pinion T wrench	5 00		60		
5Z-193	Spindle cone adjusting open end wrench	3 00		35		
5Z-195	3/8" open end wrench	2 00		25		
5Z-196	Rear axle entering wrench			30		
5Z-204	Exhaust pack nut open end wrench	8 00		90		
5.Z-206	Rear axle nut and rear spring perch nut double open end wrench			80		
5Z-206R	Rear axle nut open end wrench			55		
5Z-209	Connecting rod clamp screw wrench	4 00		45		
5Z-210	Fly wheel cap screw wrench	5 00		60		
5Z-212	Body bracket connecting bolt holding open end wrench			25		
5Z-232	Spindle arm bushing driver			40		
5Z-249	Generator third brush adj. wrench—single end			15		
5Z-280	Valve grinder	5 00		60		
5Z-285	H ¹ hex. brace wrench	5 00		60		
5Z-287	Rear wheel puller assembly			80		
5Z-289	H ¹ brace socket wrench			65		
5Z-290	Piston ring squeezer			30		
5Z-314	Transmission clutch disc drum puller	5 50		65		
5Z-319	Valve spring lifter			30		
5Z-323	Bendix shaft head puller	4 50		60		
5Z-324	Trans. band ratchet wrench	3 00		40		
5Z-325	Con. rod cap bolt nut brace wrench with universal joint for No. 4 connecting rod	16 00		1 80		
5Z-326	Small time gear and trans. driven gear puller			1 70		
5Z-361	Large time gear puller			6 50		
5Z-362	Cam gear puller (3-spoke design)			6 00		
5Z-445	Transmission band clamp			15		
5Z-457	Valve seat reamer—Old No. 20Z-340			3 00		
5Z-806	Generator third brush adj. wrench—double end			20		
5Z-815	C. S. center bearing bolt T socket wrench			55		
5Z-817	Carburetor to flange and generator to cyl. block double end socket wrench			50		
5Z-821	Large time gear lock nut open end wrench			50		
5Z-829	Trans. band, diff. housing oil plug and C. C. drain plug double end ratchet wrench	4 00		50		
20Z-340-1	Valve seat reamer cutter			1 50		
21Z-356	Valve seat reamer handle			1 50		

REPAIR TOOLS—TRUCK

5Z-288	Rear wheel puller assembly			1 00		
TT3389X	Jack			2 40	MH	
TT5893X	Spark plug, rim nut and cylinder head bolt wrench			40		

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	Fac. No.	No. Req. per Car
			Lots of 10 per lot	Lots of 100 per lot	Each			
COTTER PINS								
		Fac. No.					Fac. No.	
1/4" x 1' cotter pins		421	1/4" x 1/2" cotter pins				66	
1/4" x 1/2" cotter pins		753	1/4" x 3/4" cotter pins				544	
1/4" x 1' cotter pins		82	1/4" x 1" cotter pins				88	
Price, per dozen					\$0 03			
Price, per gross					20			
Price, per thousand					50			

FORD SPECIALTIES

	Lots of 10 per lot	Lots of 100 per lot	Lots of 1000 per lot	Each	
**4095BX... Emergency kit				\$1 50	
7962ARX... Tire repair kit	\$ 2 40	\$22 00		30	
7962BX... Tire repair kit (small)	1 80	15 00		20	
M-111... Black touch-up enamel 1/2 pt.				11 00	
M-165... Black enamel (air-dry) 1 qt.				11 00	
5761X... Dash lamp	5 50	50 00	\$475 00	60	MH
5773X... Dash lamp cap				10	
18257X... Windshield wiper	8 00	75 00	600 00	1 00	MH
17343X... Windshield wiper nut				02	
18259X... Rear view mirror Assy. (closed cars)	11 00	100 00	900 00	1 25	MH
7853X... Rear view mirror Assy. (open cars)	11 00	100 00	900 00	1 25	MH
18253X... Rear view mirror only	5 50	45 00		65	

ELECTRIC HORN

6432BRX... Electric horn complete	13 50		1 50	MH
6432CX... Electric horn complete—battery type	15 00		1 60	MH
7918X... Electric horn terminal wire 9'			05	MH
7917BX... Electric horn to switch wire 35 1/2'			10	MP
8028X... Horn switch assembly	2 50		30	MH
6437CX... Battery horn bracket			10	

ELECTRIC HEADLAMPS

6511HX... Headlamp assembly			pr	5 50	MH
6511KX... Headlamp assembly			pr	5 50	MH
6594AX... Door assembly—used with 6511DX				60	
6594HX... Door assembly with refracting lens	5 50			65	MH
6575X... Door-less lens	3 10	28 50		40	
6589X... Switch assembly—with screws				30	MH
8650X... Headlamp and horn switch assembly				40	MH
8892ARX... Dimmer resistance coil with wires				50	MH
*8892BX... Dimmer assembly				50	MH
*8890X... Dimmer cover				10	
6572AX... Headlamp bulb—9 volt—18 c.p.—double contact—used with magneto without dimmer	1915-18	27 50		30	
6572HX... Headlamp bulb—6-8 volt—bright, 21 c.p. dim, 6/10 c.p.—double contact—double filament—used with T6576HX lens	1922-25	36 00		40	
6572KX... Headlamp bulb—6-8 volt—21 c.p.—double contact—used with dimmer T8892X without starter or dimmer T7320X with starter and T6576HX lens	1922-25	30 00		35	
6578X... Door lens gasket				03	
6576HX... Headlamp lens—refracting—in carton (Pair)		45 00		50	
6592X... Plug—with thimble		7 50		10	
6590X... Reflector assembly	6 00			75	
6585BX... Reflector (dimmer type)				90	
6580X... Focusing screw				03	
6591X... Focusing screw spring				01	
6574X... Bolt socket	1 25			15	
6574BX... Head lamp plug socket				15	
6586X... Reflector spring				05	
7487X... Switch to terminal wire—11 1/4" long				05	MH
7489X... Lamp to lamp wire—40" long				10	MH
7490X... Lamp to ground wire—10 1/4" long				05	MH
2122X... Head lamp wire bushing				03	
4082X... Head lamp and tail lamp wire bushing				01	

*Used on cars without starter with switch on instrument panel.

†Not subject to regular discount. ††In lots of 100 or more allow regular discount.

*CConsists of 1 spark plug, 2 head lamp bulbs and 1 tail lamp bulb in carton.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE		Tax Each Status
			Lots of 10 per lot	Lots of 100 per lot	

SIDE AND TAIL LAMPS

6561X	Side oil lamp, per pair		pr.	\$4 50	MH
6568X	Tail lamp			2 50	MH
6568BX	Oil tail lamp	1923-25		2 50	MH
7649X	Electric tail lamp assembly			\$8 00	90 MH
18786CX	Electric tail lamp and license brkt. assy.			9 00	1 00 MH
6484AX	Tail lamp red lens	1915-25			15
6484BX	Electric tail lamp red lens			\$10 00	15
6484CX	Elec. tail lamp red lens (celluloid)	1923-25			03
6484DX	Oil tail lamp side lens (red)	1924-25			10
6405CX	Electric tail lamp, white lens				15
6405EX	Oil tail lamp door lens (white) Edmunds & Jones design	1924-25			15 MH
6405FX	Oil tail lamp door lens (white) J. W. Brown design	1924-25			15
6406X	Electric tail lamp white lens retainer	1923			05
6406BX	Elec. tail lamp body and lens retainer	1923-25			05
6520X	Bulb (tail lamp and headlamp dimmer) 6-8 volt—2 1/4 c.p.—single contact	1919-25		1 80	20
6495X	Electric tail lamp bulb socket				15
6495DX	Elec. tail lamp bulb socket assy.	1923-25			15
6414BX	Elec. tail lamp gasket	1923-25			02
6426X	Tail lamp wire terminal	1923-25			01
2107X	Tail lamp wire clip				01
2108X	Tail lamp wire spring				03
6409X	Tail lamp wire bushing assembly				03
6410X	Tail lamp wire bushing support				01
TT8821X	Tail lamp to ground wire assembly				15 MH
6599X	Side oil and tail lamp fount				50
6956X	Side oil lamp door				50
6957X	Tail lamp door				50
6957BX	Tail lamp door				50
6966X	Tail lamp white lens and frame				20
6460X	Lamp burner				25
6483X	Side oil lamp door lens				15
6392X	Lamp wick				05

TOURING CAR AND TORPEDO WINDSHIELDS—1915-22

7840ARX	Windshield assembly				†10 50 MH
7818BX	W/S hinge assembly—right	1917-22			40
7819BX	W/S hinge assembly—left	1917-22			40
7820BX	W/S frame assembly—upper	1917-22			1 50
7822BX	W/S upper half assembly	1917-22			†4 50 MH
7823ARX	W/S lower half assembly	1915-22			†5 25 MH
7802ARX	W/S lower frame only	1915-22			1 00
7803ARX	W/S lower frame filler block	1915-22			20
7839X	W/S frame filler block	1915-17			15
7888ARX	W/S block (frame filler)—upper	1917-22			20
7810X	W/S hinge bolt	1915-16			03
7845ARX	W/S bracket—right	1915-22			50
7845BX	W/S bracket—right	1919-22			50
7846ARX	W/S bracket—left	1915-22			50
7846BX	W/S bracket—left	1919-22			50
7824ARX	W/S glass clamp	1915-22			02
7887X	W/S frame—upper	1917-22			75
3827X	W/S top snap loop	1915-22			02
1154X	W/S hinge bolt nut	1915-22			
2449BX	W/S glass clamp screw	1915-22			
2257BX	W/S hinge to frame screw	1915-22			01
292X	W/S hinge spring				02
7851ARX	W/S upper glass stop—nickel	1915-22			20
7852ARX	W/S lower glass stop—nickel	1915-22			20
7808X	W/S hinge thimble	1915-22			03
7827AX	W/S glass—upper	1915-22			†3 00
7828X	W/S glass—lower	1915-22			†3 50

Order 3929C

Order 2742

TOURING CAR AND ROADSTER WINDSHIELDS—1922-24

7836X	Anti-rattler (windshield)	1922-25			15
6645X	Bolt (W/S bracket to instrument panel)	1922-25			03
7837X	Bracket (windshield) assembly—R. H.	1922-25			60 MH
7838X	Bracket (windshield) assembly—L. H.	1922-25			60 MH

†Includes lamp.

‡Not subject to regular discount.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE		Tax Status
			Lots of 10 per lot	Each of 100 per lot	

TOURING CAR AND ROADSTER WINDSHIELDS—1922-24—Continued

*7891X	Bracket (side oil lamp)	1922-25		\$0 30	
9066X	Channell (windshield) center	1922-25		35	MH
7816X	Cone (W/S frame)	1922-25		10	
7802BX	Frame (windshield) assembly—lower	1922-25		1 00	
7887CX	Frame (windshield) assembly—upper	1922-25		1 00	
7888BX	Filler (windshield upper frame)—lower	1922-25		05	
7847X	Filler (windshield upper frame)—upper	1922-25		05	
7803BX	Filler (windshield lower frame)	1922-25		10	
7827BX	W/S glass—upper	1922-25		12 75	
9534X	W/S glass—lower	1922-25		13 00	
7825X	Nut (windshield clamp stud wing)	1922-25		15	
7842X	Nut (windshield cone lock)	1922-25		02	
1307X	Nut (windshield bracket to instrument panel bolt) lower	1922-25		02	
7851BX	Retainer (windshield glass) upper	1922-25		15	
7852BX	Retainer (windshield glass) lower	1922-25		15	
7826X	Stud (windshield frame clamping)	1922-25		03	
7833X	Washer (windshield clamp stud nut)	1922-25		01	
7840BX	Windshield assembly	1922-25		11 50	MH
7822CX	Windshield (upper half) ass'y.	1922-25		14 75	MH
7823BX	Windshield (lower half)	1922-25		15 00	MH
*8064X	Windshield bracket to body bolt	1922-25		02	

TOURING CAR TOPS—1915-22

7940ARX	Touring car top complete	1915-22		* 27 00	MH
6882ARX	T. C. storm curtain—R. H.	1915-22		2 00	MH
6883ARX	T. C. storm curtain—L. H.	1915-22		2 00	MH
4966BRX	T. C. side curtain—R. H.	1915-22		2 50	MH
4967BRX	T. C. side curtain—L. H.	1915-22		2 50	MH
6894ARX	T. C. center deck complete	1915-22		7 00	MH
6815ARX	T. C. side quarter pad	1915-22		1 00	
6940ARX	T. C. back stay and curtain assembly	1915-22		3 00	MH
3897X	T. C. wood bow	1913-17		60	
8973ARX	T. C. front and rear extension rib	1918-22		30	
8974ARX	T. C. front and rear upright rib	1918-22		30	
4596X	T. C. bow separator—male	1913-17		05	
4597X	T. C. bow separator—female	1913-17		05	
6832X	T. C. bow separator	1918-22		05	
6860BRX	T. C. front extension rib socket—R. H.	1918-22		1 00	
6861BRX	T. C. front extension rib socket—L. H.	1918-22		1 00	
3884BRX	T. C. rear extension rib socket—R. H.	1918-22		1 00	
3885BRX	T. C. rear extension rib socket—L. H.	1918-22		1 00	
6862BRX	T. C. front upright rib socket—R. H.	1918-22		1 00	
6863BRX	T. C. front upright rib socket—L. H.	1918-22		1 00	
3882BRX	T. C. rear upright rib socket—R. H.	1918-22		1 00	
3883BRX	T. C. rear upright rib socket—L. H.	1918-22		1 00	
7831ARX	Curtain to windshield hook	1915-22		02	
7832X	Curtain to body hook	1915-22		02	
8992X	Rib socket cotter	1918-22		02	
3924ARX	T. C. top to windshield strap assembly	1915-22		25	MH
3629ARX	T. C. rear strap assembly complete	1913-21		40	MH
3629BRX	Stay strap assembly	1921-22		40	MH
6829BX	T. C. extension support—upper	1918-22		10	
6830BX	T. C. extension support—lower	1918-22		05	
8937X	T. C. top snap fastener—single	1917-22	3 50	05	
8938X	T. C. top snap fastener—double	1917-22	3 50	05	
3314ARX	T. C. top prop rest with strap	1913-22		60	
3858X	T. C. top prop rest arm	1913-21		25	
3624X	T. C. bow socket to seat iron japanned nut	1913-22		03	
6682X	Curtain celluloid 20" x 50"—.015 thick (old No. 3383X)	1913-22		1 50	
4981ARX	Touring car top visor	1920-22		50	
8940X	Curtain fastener eyelet	1917-22		75	01
8943X	Curtain fastener eyelet washer	1917-22		50	01

TOURING CAR TOPS—1922-25

3573X	Brace (top extension)—R. H.	1922-25		25	
3574X	Brace (top extension)—L. H.	1922-25		25	
**3588X	Top clamping bracket assembly	1922-25		20	
*6902X	Glove fastener button	1922-25		02	
††6940BRX	Curtain (rear) assembly	1922		2 50	MH
6940CX	Curtain (rear) assembly	1922-25		2 30	MH
††4966CRX	Curtain (rear side) assembly—R. H.	1922		2 00	MH
4966DX	Curtain (rear side) assembly—R. H.	1922-25		1 75	MH
††4967CRX	Curtain (rear side) assembly—L. H.	1922		2 00	MH
4967DX	Curtain (rear side) assembly—L. H.	1922-25		1 75	MH
6882BX	Curtain (front side) assembly—R. H.	1922-25		1 75	MH
6883BX	Curtain (front side) assembly—L. H.	1922-25		1 85	MH

†Not subject to regular discount.

**Also used on 1922 Roadster Top.

††Used on tops with straight side quarters.

*Used on cars without starter.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents the excise tax.

LIST PRICE

Part No.	Name of Part	Year	Lots of 10 per lot	Lots of 100 per lot	Each	Tax Status
TOURING CAR TOPS—1922-25—Continued						
††6894BRX	Deck (top) assembly	1922			\$6 50	MH
6894CX	Deck (top) assembly	1922-25	\$60 00		6 50	MH
**6903X	Eyelet (side curtain rear glove fastener)	1922-25			02	
**6904X	Fastener (rear curtain glove)	1922-25			02	
**7831BX	Hook (curtain to windshield)	1922-25			02	
6815BX	Pad (top side quarter) assembly	1922-25			1 00	
**3314BX	Rest (prop) and strap assembly	1922-25			40	
8975X	Rib (top) center and rear	1922-25			30	
8973BX	Rib (top) front	1922-25			30	
8974BX	Rib (top) center ext.	1922-25			30	
**3548X	Screw (front socket fastener)	1922-25			doz. 05	
8660CX	Socket (top rib) front—R. H.	1922-25	8 00		1 00	
6861CX	Socket (top rib) front—L. H.	1922-25	8 00		1 00	
3882CX	Socket (top rib) center—R. H.	1922-25	9 00		1 00	
3883CX	Socket (top rib) center—L. H.	1922-25	9 00		1 00	
††3884CRX	Socket (top rib) rear—R. H.	1922			1 25	
3884DX	Socket (top rib) rear—R. H.	1922-25	9 00		1 00	
††3885CRX	Socket (top rib) rear—L. H.	1922			1 25	
3885DX	Socket (top rib) rear—L. H.	1922-25	9 00		1 00	
6862CX	Socket (top rib) center ext.—R. H.	1922-25	8 00		1 00	
6863CX	Socket (top rib) center ext.—L. H.	1922-25	8 00		1 00	
6844BX	Top center strainer	1922-25			40	
6846X	Top quarter strainer	1922-25			40	
**3629CX	Strap (stay)	1922-25			20	MH
**6901X	Stud (rear curtain glove fastener)	1922-25			02	
3551X	Center support on rear socket	1922-25			05	
3564X	Center ext. support—on center socket	1922-25			05	
3572X	Center ext. to brace support	1922-25			05	
7940BX	Top assembly	1922-25	†250 00		†27 00	MH
**4981BX	Visor (top) assembly	1922-25			75	
**6905X	Washer (side curtain rear glove fastener)	1922-25			02	

TORPEDO TOP PARTS—1915-22

7941ARX	Torpedo top complete	1915-22			†22 00	MH
4971X	Torpedo top—second and third wood bows	1914-18			50	
6929X	Torpedo top—first bow	1915-18			50	
8772X	Rib—upright	1918-22			60	
8988X	Rib—front extension	1918-22			30	
8989X	Rib—rear extension	1918-22			30	
6870AX	Torp. bow socket—upright—(R. H.)	1915-18			1 25	
6870BX	Torp. rib socket—upright—(R. H.)	1918-22			1 00	
6871AX	Torp. bow socket—upright—(L. H.)	1916-18			1 25	
6871BX	Torp. rib socket—upright—(L. H.)	1918-22			1 00	
6872AX	Torp. bow socket—front extension—(R. H.)	1915-18			1 00	
6872BX	Torp. rib socket—front extension—(R. H.)	1918-22			1 00	
6873AX	Torp. bow socket—front extension—(L. H.)	1915-18			1 00	
6873BX	Torp. rib socket—front extension—(L. H.)	1918-22			1 00	
4907AX	Torp. bow socket—rear extension—(R. H.)	1913-18			1 00	
4907BX	Torp. rib socket—rear extension—(R. H.)	1918-22			1 00	
4908AX	Torp. bow socket—rear extension—(L. H.)	1913-18			1 00	
4908BX	Torp. rib socket—rear extension—(L. H.)	1918-22			1 00	
6937AX	Torp. side curtain—rear—(R. H.)	1915-22			1 50	MH
6938AX	Torp. side curtain—rear—(L. H.)	1915-22			1 50	MH
6935AX	Torp. side curtain—front—(R. H.)	1915-22			2 00	MH
6936AX	Torp. side curtain—front—(L. H.)	1915-22			2 00	MH
6950AX	Torp. back curtain assembly	1915-22			2 50	MH
6965AX	Torp. center deck complete	1915-22			4 50	MH
6806AX	Torp. side quarter pad	1914-22			60	
3877X	Torp. prop rest with strap	1913-22			60	
4955AX	Torp. top visor	1920-22			50	

†ROADSTER TOP—1922-25

6935BX	Curtain (front side) assembly—R. H.	1922-25			1 25	MH
6936BX	Curtain (front side) assembly—L. H.	1922-25			1 35	MH
6937BX	Curtain (rear side) assembly—R. H.	1922-25			90	MH
6938BX	Curtain (rear side) assembly—L. H.	1922-25			90	MH
6950BX	Rear curtain assembly	1922-25			2 30	MH
6965BX	Top deck assembly	1922-25	32 00		3 50	MH
6806BX	Top side quarter pad assembly	1922-25			60	
8988BX	Top rib—front	1922-25			30	
8989BX	Top rib—center and rear	1922-25			30	
4907CX	Top rib socket, rear—R. H.	1922-25	9 00		1 00	
4908CX	Top rib socket, rear—L. H.	1922-25	9 00		1 00	
6872CX	Top rib socket, front	1922-25	8 00		1 00	
6870CX	Top rib socket, center—R. H.	1922-25	8 00		1 00	
6871CX	Top rib socket, center—L. H.	1922-25	8 00		1 00	
7941BX	Top assembly	1922-25	†200 00		†22 00	MH

†Not subject to regular discount.

**Also used on 1922-25 Roadster Top.

††For additional 1922-25 Roadster top parts see 1922-25 Touring Car top parts marked with a double asterisk (**). ††Used on tops with straight side quarters.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Price List of Parts for Model T One Ton Truck

Part No.	Name of Part	Year	LIST PRICE			Tax	Fac. Req. No.	No. per Car
			Lots of 10 per lot	Lots of 100 per lot	Each Model			
REAR AXLE								
1000	Rear axle assembly	1918-25			\$110 00	MH.. TT..	95	1
1001	Axle housing—right	1918-25			15 00	MH.. TT..	4	1
1002	Axle housing—left	1918-25			15 00	MH.. TT..	5	1
1003	Axle housing bolt	1918-25			05	.. TT..	52	13
1003B	Axle housing bolt nut	1918-25						
1004	Axle housing cap	1918-25						
1005	Axle housing cap gasket	1918-25		1 50		35 MH.. TT..	133	1
1006	Axle housing cap screw	1918-25		4 00		02 MH.. TT..	134	1
1007	Axle housing cap screw lock wire	1918-25				05 .. TT..	7	4
1008	Axle housing gasket—upper	1918-25		1 00		01 .. TT..	140	1
1009	Axle housing gasket—lower	1918-25		3 00		02 MH.. TT..	138	1
1010	Axle brake housing plate—right	1918-25				05 MH.. TT..	139	1
1011	Axle brake housing plate—left	1918-25				35 MH.. TT..	147	1
1012	Axle housing drain plug	1918-25				05 .. TT..	148	1
1013	Axle shaft	1918-25			4 00	MH.. TT..	2818	2
1014	Axle shaft cotter	1918-25			05	.. TT..	165	2
1015	Axle shaft nut	1918-25	90	8 00		10 .. TT..	166	2
1016	Axle shaft washer	1918-25	25	2 00		03 .. TT..	135	2
1017	Axle shaft dust cap	1918-25				03 .. TT..	56	2
1018	Axleshaft inner ball bear. assy.	1918-25			5 00	.. TT..	125	2
1019	Axleshaft outer roller bearing	1918-25	9 00		1 00	.. TT..	253	2
1020	Axleshaft outer R. B. sleeve—R.	1918-25	3 00			35 .. TT..	170	1
1020B	Axleshaft outer R. B. sleeve—L.	1918-25	3 00			35 .. TT..	161	4
1021	Axle shaft bearing felt	1918-25	1 20	10 00		15 .. TT..	143	2
1022	Axle shaft bearing retainer	1918-25				05 .. TT..	20	2
1023	Axleshaft bear. retainer washer	1918-25		1 50		02 .. TT..	23	2
1024	Axleshaft felt retainer assembly	1918-25	1 50			20 .. TT..	144	1
1025	Axle shaft felt retainer cup	1918-25				03 .. TT..	145	2
1026	Axle shaft felt retainer plate	1918-25				03 .. TT..	146	2
1027	Diff. gear	1918-25			1 15	MH.. TT..	13	2
1028	Diff gear case R. or L. half	1918-23			2 50	MH.. TT..	11A	2
1028B	Differential gear case—R. or L. half	1923-25			2 50	MH.. TT..	11B	2
1029	Diff gear case bolt	1918-25						
1031	Diff. gear lock ring	1918-25				02 .. TT..	118	2
1032	Diff. pinion	1918-25				50 MH.. TT..	14	2
1033	Diff. pinion shaft	1918-23				20 MH.. TT..	15A	1
1033B	Differential spider	1923-25			1 50	MH.. TT..	15B	1
DRIVE SHAFT								
1034	Drive shaft	1918-25			7 00	MH.. TT..	87	1
1036	D. S. tube assembly	1918-25			10 00	MH.. TT..	153	1
1037	D. S. tube flange gasket	1918-25		15	1 25	02 MH.. TT..	194	1
1038	D. S. tube flange screw	1918-25						
1039	D. S. felt	1918-25						
1040	D. S. felt container	1918-25			80	10 .. TT..	109	1
1041	D. S. to worm coupling	1918-19				03 .. TT..	110	1
1041B	D. S. to worm coupling	1920-25				70 .. TT..	85A	1
1042	D. S. to worm coupling pin	1918-25				70 .. TT..	85B	1
						01 .. TT..	86	2
WORM								
1043	Worm—7/8 to 1	1918-25			6 00	MH.. TT..	16A	1
1043B	Worm—5/8 to 1	1918-25			6 00	MH.. TT..	16B	1
1044	Worm gear—7/8 to 1	1918-25			10 00	MH.. TT..	12A	1
1044B	Worm gear—5/8 to 1	1918-25			10 00	MH.. TT..	12B	1
1045	Worm cotter	1918-25						
1046	Worm roller bearing	1918-25			6 50	75 .. TT..	108	2
1047	Worm roller bearing retainer	1918-25				02 .. TT..	106	2
1048	Worm roller bearing sleeve	1918-25	10 00		1 20	.. TT..	107	2
1049	Worm roller bear. housing screw	1918-25				03 .. TT..	101	2
1050	Worm thrust bearing collar	1918-25				80 .. TT..	114	1
1051	Worm thrust ball and sep. assy.	1918-25	5 00		60	.. TT..	123	1
1052	Worm thrust bearing plate	1918-25			15	.. TT..	22	1
1053	Worm thrust bearing retainer	1918-25	1 25		15	.. TT..	111	1
1054	Worm thrust bear. retainer nut	1918-25						
1055	Worm thrust bear. retainer pin	1918-25			50	01 .. TT..	112	1
BRAKE PARTS								
1056	Brake shoe	1918-25			1 50	MH.. TT..	2814	2
1057	Brake shoe lining, each	1918-25	2 00		25	MH.. TT..	58	4
1058	Brake shoe lining rivet	1918-25			doz.	.. TT..	68	40
1059	Brake shoe spring	1918-25	40		05	.. TT..	67	2
1060	Brake shoe bolt	1918-25	80	7 00		10 .. TT..	59	2
1060B	Brake shoe bolt nut	1918-25						
1061	Brake expander	1918-25			40	MH.. TT..	61	2

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE			Tax Status	No. Fac. Req. Model No.	No. per Car
			Lots of 10 per lot	Lots of 100 per lot	Each			
REAR AXLE—Continued								
BRAKE PARTS—Continued								
1062	Brake expander lever	1918-25			\$0 15	MH. TT.	62	2
1064	Brake expander adj. collar	1918-25			15	TT.	175	2
1065	Brake expander bushing	1918-25			10	TT.	173	2
1066	Brake expander pin	1918-25			01	TT.	7	2
1067	Brake expander link	1918-25			08	MH. TT.	176	4
1068	Brake expander link pin	1918-25			03	TT.	177	8
1069	Brake rod	1918-25			30	MH. TT.	119	2
1070	Brake rod support—right	1918-25	\$0 60	5 00	10	TT.	120	2
1071	Brake support—left	1918-25	60	5 00	10	TT.	121	1
1072	Brake rod support bolt	1918-25		1 00	02	T.	7181	2
1072B	Brake rod support bolt nut	1918-25						
								Order 3088E

RADIUS ROD								
1073	Rear radius rod—right	1918-25			3 00	MH. TT.	152	1
1073B	Rear radius rod—left	1918-25			3 00	MH. TT.	158	1
1074	Rear radius rod bolt—front	1918-25		7 50	10	TT.	84	1
1075	Rear radius rod bolt—rear	1918-25		7 50	10	TT.	83	4
1075B	Rear radius rod bolt nut	1918-25						Order 2828
1076	Universal joint bushing	1918-25			60	TT.	69	1

SPRINGS

1077	Rear spring—right or left, each	1918-25			4 00	MH. TT.	333	2
1078	Spring leaf No. 1	1918-25	8 00		90	TT.	334	2
1079	Spring leaf No. 2	1918-25	4 00		50	TT.	362	2
1080	Spring leaf No. 3	1918-25	3 50		45	TT.	363	2
1081	Spring leaf No. 4	1918-25	3 00		40	TT.	364	2
1082	Spring leaf No. 5	1918-25	2 80		35	TT.	365	2
1083	Spring leaf No. 6	1918-25	2 50		30	TT.	366	2
1084	Spring leaf No. 7	1918-25	2 30		25	TT.	367	2
1085	Spring leaf No. 8	1918-25			20	TT.	368	2
1086	Spring leaf No. 9	1918-25			20	TT.	331	2
1087	Spring bushing	1918-25			20	TT.	332	2
1088	Spring clip	1918-25			45	TT.	326	2
1089	Spring clip nut	1918-25			05	TT.	327	2
1091	Spring clip plate	1918-25			20	TT.	329	4
1092	Spring tie bolt	1918-25			15	TT.	330	2
1093	Spring tie bolt nut	1918-25						Order 1089
1094	Spring tie bolt cotter	1918-25			*doz. 05	TT.	328	2
1095	Spring clamp	1918-25	75		10	TT.	375	2
1096	Spring clamp bolt	1918-25		2 00	03	TT.	376	2
1096B	Spring clamp bolt nut	1918-25						Order 3514
1097	Spring perch	1918-25			90	MH. TT.	2804	4
1098	Spring perch nut	1918-25						Order 1015
1099	Spring perch cotter	1918-25						Order 1014
1100	Spring perch bushing	1918-25			35	TT.	172	2
1101	Spring perch bushing spacer	1918-25			05	TT.	169	4
1102	Spring hanger assembly	1918-25			30	TT.	91	4

WHEELS

1105B	Rear wheel—dem.—Kelsey	1919-25			15 00	MH. TT.	7698	2
1105C	Rear wheel—dem.—Hayes	1919-25			15 00	MH. TT.	7698B	2
1105D	Rear wheel—dem.—less rim and hub—Kelsey	1919-25			6 50	MH. TT.	2817AR	2
1105E	Rear wheel—dem.—less rim and hub—Hayes	1919-25			6 50	MH. TT.	2817BR	2
1105H	Rear wheel complete—dem.	1924-25			14 00	MH. TT.	7968E	
1105J	Rear wheel—less rim	1924-25			10 00	MH. TT.	2815F	
1105K	Rear wheel—less rim and hub	1924-25			5 75	MH. TT.	2817C	
1106C	Dem. rim only—Hayes	1919-25			3 50	MH. TT.	8774B	2
1106G	Dem. rim only—Kelsey	1922-25			3 50	MH. TT.	8774C	2
1106D	Dem. rim retainer ring—Kelsey	1922-25			45	MH. TT.	178	2
1106E	Dem. rim and flange assy.	1924-25			2 75	MH. TT.	8774D	
							TT189	
1106G	Dem. rim flange	1924-25			90	TT.	189	
1107B	Clamp and nut assy.—Kelsey	1919-25	1 00		15	MH. TT.	8807	12
1107C	Clamp	1924-25			10	MH. TT.	8831D	
1108B	Clamp bolt	1919-25	40	3 50	05	TT.	8832	12
1108C	Clamp bolt	1924-25			05	TT.	8832B	
1108D	Clamp nut	1924-25			05	TT.	8834B	
1109	Rear wheel complete, less tire	1918-25			16 50	MH. TT.	99	2
1109B	Rear wheel—solid tire design—less hub and tire	1919-25			12 25	MH. TT.	2816	2
1110	Rear wheel com., with solid tire	1918-25				MH. TT.	7645	2
1111	Rear hub	1918-25	20 00		2 25	MH. TT.	40	2
1112	Rear hub flange	1918-25			40	MH. TT.	149	2

*\$0.25 gross, \$0.75 per thousand.

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.

Part No.	Name of Part	Year	LIST PRICE				Tax	Fac. No.	No. per Car	
			Lots of 10	Lots of 100	Each	Status				
			per lot	per lot		Model				
WHEELS—Continued										
1113	Rear hub brake drum	1918-25				\$1 25	MH	TT	3	2
1114	Rear hub bolt	1918-25	\$0 40	\$3 50		05		TT	28	12
1114B	Rear hub bolt nut	1918-25		1 50		02		TT	29	12
1116	Rear hub cap	1918-25	2 25			25	MH	TT	150	2
1117	Rear hub key	1918-25		2 50		03		TT	26	2
1118	Rear hub felt	1918-25	75	5 50		10		TT	162	2

FRAME

1119	Frame assembly	1918-25				25 00	MH	TT	300	1
1120	Side member—right	1918-25				9 00		TT	301	1
1121	Side member—left	1918-25				9 00		TT	302	1
1122	Front cross member	1918-25				1 00		TT	303	1
1123	Rear cross member	1918-25				4 00		TT	304	1
1124	Front corner bracket—right	1918-25				15		TT	305	1
1125	Front corner bracket—left	1918-25				15		TT	306	1
1125B	Front end spacer—right	1918-25				15		TT	319	1
1125C	Front end spacer—left	1918-25				15		TT	318	1
1126	Rear cross member gusset plate	1918-25				25		TT	307	2
1127	Rear cross member reinforcement	1918-25				35		TT	325	2

TRANSMISSION CONTROL

1133	Speed lever	1918-25				10	MH	TT	862	1
1134	Control shaft with speed lever	1918-25				60	MH	TT	1557	1

Of the net amount at which parts marked "MH" are billed to purchasers who purchase direct from the Ford Motor Company, 40/41 represents the price of the goods and 1/41 represents excise tax.




Ford Emergency Kit \$1.50

A Metal Box containing
 2 Head Lamp Bulbs.
 1 Tail Lamp Bulb.
 1 Spark Plug
 1 Tire Repair Outfit.



Ford Adjustable Rear View Mirror \$1.25

Finished in black enamel. Easily installed and easily adjusted to the desired position. Held in rigid adjustment by single adjusting nut.



Ford Windshield Wiper \$1.00

Finished in black enamel with polished white metal handle. Two-ply rubber wiper is held firmly against glass. Easily installed.



Ford Dash Light \$0.60

Complete with bulb, connection wire and screws for attaching. Finished in black enamel. A neat and serviceable lamp.

Ford Touch-up Black 1/2 pint bottle \$1.00

Dries quickly leaving a high gloss finish. Cannot be excelled for touching up rusted or scratched spots. Supplied in 1/2 pint bottles with 1-inch brush vulcanized into the bottle cap.



Ford Black Enamel 1 qt. can \$1.00

A high grade black enamel for refinishing Ford cars. Complete instructions for applying on label.

This enamel is especially prepared for owners who desire to refinish their cars. One quart is sufficient for either body or chassis.

**Ford Products for Ford Cars
 Sold by all authorized Ford
 Dealers**

